



647732 US (28/08/2025)

MT 625 H 75K ST5 S1
MT 625 H 75K COMFORT ST5 S1

OPERATOR'S MANUAL
(ORIGINAL MANUAL)

IMPORTANT

Carefully read and understand this instruction manual before using this machine.

It contains all information relating to operation, handling and equipment, as well as important recommendations to be followed.

This document also contains precautions for use, as well as information on the service and routine maintenance required to ensure the machine's continued reliability and safety of use.

WHENEVER YOU SEE THIS SYMBOL, IT MEANS:



NOTE! BE CAREFUL! YOUR SAFETY, THAT OF OTHERS, OR THE SAFETY OF THE MACHINE IS AT RISK.

- This manual has been produced based on the equipment list and technical characteristics given at the time of its design.
- The machine's equipment level depends on the options chosen and the country of sale.
- Depending on the machine's options and the date of sale, certain equipment or functions described in this manual may not be present on this machine.
- Descriptions and figures are nonbinding.
- MANITOU reserves the right to change its models and their equipment without being required to update this manual.
- The MANITOU network, consisting exclusively of qualified professionals, is available to answer all your questions.
- This manual is an integral part of the machine.
- It is to be kept in its storage location at all times for ease of reference.
- Give this manual to the new owner if the machine is resold.

CALIFORNIA PROPOSITION 65 WARNINGS

WARNING

This product can expose you to lead which is known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to www.P65Warnings.ca.gov

WARNING

Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65Warnings.ca.gov/diesel

SILICA DUST HAZARD

Exposure to crystalline silica (found in sand, soil and rocks) has been associated with silicosis, a debilitating and often fatal lung disease. Comply with all applicable rules and regulations for the workplace. Wear approved respiratory protection or use water spray or other means if there is no other way to control the dust.

A Silica rule "29 CFR 1929.1153" by the U.S. Occupational Safety and Health (OSHA) indicates a significant risk of chronic silicosis for workers exposed to inhaled crystalline silica over a working lifetime. Refer to the rule for more information regarding exposure limits and hazard prevention.



1 st EDITION	28/01/2019	
UPDATE	31/10/2019	2-6 – 2-9 ; 2-12 ; 2-14 ; 2-18 – 2-21 ; 2-32 ; 2-33 – 2-35 ; 2-37 – 2-39 ; 2-42 ; 2-43 ; 2-45 – 2-54 3-9 ; 3-10 ; 3-23 4-5 – 4-7 ; 4-9 – 4-11
	26/03/2021	1-6 ; 1-10 ; 1-15 ; 1-25 ; 1-26 2-6 ; 2-7 ; 2-11 ; 2-18 ; 2-19 ; 2-28 ; 2-29 ; 2-31 ; 2-32 3-4 ; 3-7 ; 3-8 ; 3-13 ; 3-28 ; 3-29 ; 3-37
	29/10/2024	1-1 – 1-34 2-23 ; 2-36 3-9 ; 3-11
	28/08/2025	0-0 1-1 – 1-34 2-42 3-20 ; 3-23 ; 3-28

MANITOU BF SA Public limited company with a board of directors.

Headquarters : 430 rue de l'Aubinière - 44150 Ancenis - France

Authorized capital : 39 548 949 €

857 802 508 RCS Nantes

Tel.: +33 (0) 2 40 09 10 11

www.manitou.com

This brochure is provided for information only. Any reproduction, copy, representation, recording, transfer, distribution, etc., in whole or in part, in any format whatsoever, is prohibited. The diagrams, drawings, images, comments and indications found in this documentation, and the organization of the document itself, are intellectual property of MANITOU BF. Any violation of the above is subject to civil and criminal penalties. The logos and visual identity of the company are property of MANITOU BF and may not be used without express formal authorization. All rights reserved.

Clause regarding database usage restrictions

Connected Manitou machines are equipped with boxes that collect technical data on the machines (such as geo-tracking data or data on component operation). This data, which is organized, processed and enhanced by algorithms and expertise proprietary to Manitou, constitutes a protected database under article L.341-1 of the Intellectual Property Code.

It is strictly forbidden to have access to all or part of this database and to use the data (including in the event of accidental access) without explicit prior authorization from Manitou. In the event that Manitou authorizes a Manitou machine user to access all or part of this database, Manitou, as producer of this database, cedes to the user only a right to personal, non-exclusive, nontransferable use of the database, and only by access to an information technology platform hosted by a server owned or controlled by Manitou.

In any case, the following are strictly prohibited:

- any extraction, reproduction, representation, reuse through provision to the public, distribution, transfer, permanent or temporary, on any medium, by any means, and in any form whatsoever, of all or of a qualitatively or quantitatively substantial part of the contents of this database.
- any extraction, reproduction, representation, reuse through provision to the public, distribution, transfer, repeated or systematic of qualitatively or quantitatively insubstantial parts of the content of the database during operations manifestly exceeding normal use of the database by the user of the machine for his own needs,
- any use of means to bypass technical protection measures for databases or software source code embedded in the boxes, in keeping with article L.331-5 of the Intellectual Property Code.

1 - OPERATING AND SAFETY INSTRUCTIONS

2 - DESCRIPTION

3 - MAINTENANCE

4 - OPTIONAL ADAPTABLE ATTACHMENTS FOR THE RANGE



1 - OPERATING AND SAFETY INSTRUCTIONS

1 - OPERATING AND SAFETY INSTRUCTIONS

INSTRUCTIONS TO THE COMPANY MANAGER **1-4**

THE SITE	1-4
THE OPERATOR	1-4
THE MACHINE	1-4
A - SUITABILITY OF THE MACHINE FOR THE TASK	1-4
B - ADAPTING THE MACHINE TO USUAL ENVIRONMENTAL CONDITIONS	1-4
C - MODIFYING THE MACHINE.	1-5
D - FRENCH ROAD TRAFFIC RULES.	1-5
E - MACHINE CAB PROTECTION.	1-5
INSTRUCTIONS	1-6
MAINTENANCE	1-6

INSTRUCTIONS FOR THE OPERATOR **1-8**

FOREWORD	1-8
GENERAL INSTRUCTIONS	1-8
A - OPERATOR'S MANUAL.	1-8
B - AUTHORIZATION FOR USE IN FRANCE.	1-8
C - MAINTENANCE	1-8
D - TIRES	1-9
E - MODIFYING THE MACHINE.	1-9
F - LIFTING PEOPLE.	1-9
OPERATING INSTRUCTIONS UNLADEN AND LADEN	1-10
A - BEFORE STARTING UP THE MACHINE	1-10
B - AVAILABLE IN THE DRIVER'S CAB.	1-10
C - ENVIRONMENT	1-10
D - VISIBILITY	1-11
E - STARTING THE MACHINE	1-12
F - OPERATING THE MACHINE	1-12
G - STOPPING THE MACHINE.	1-14
H - DRIVING THE MACHINE ON THE PUBLIC HIGHWAY.	1-15
INSTRUCTIONS FOR HANDLING A LOAD	1-18
A - CHOICE OF ATTACHMENTS	1-18
B - WEIGHT OF LOAD AND CENTER OF GRAVITY	1-18
C - LONGITUDINAL STABILITY INDICATOR.	1-18
D - TRANSVERSE ATTITUDE OF THE MACHINE.	1-19
E - PICKING UP A LOAD ON THE GROUND	1-19
F - PICKING UP AND PUTTING DOWN A HIGH LOAD ON TIRES	1-20
G - PICKING UP AND PUTTING DOWN A HIGH LOAD ON STABILIZERS.	1-22
H - PICKING UP AND PUTTING DOWN A SUSPENDED LOAD.	1-24
I - TRAVELING WITH A SUSPENDED LOAD.	1-24
INSTRUCTIONS FOR USE AS A LOADER	1-25
A - LOADING	1-25
B - BACKFILLING.	1-25
INSTRUCTIONS FOR USING THE MOBILE ELEVATING WORK PLATFORM	1-26
A - AUTHORIZATION FOR USE	1-26
B - SUITABILITY OF THE PLATFORM FOR THE JOB	1-26
C - PROVIDED ON THE PLATFORM	1-26
D - USING THE PLATFORM.	1-27
E - ENVIRONMENT	1-28
F - MAINTENANCE	1-28
INSTRUCTIONS FOR USING THE RADIO-CONTROL	1-29
HOW TO USE THE RADIO-CONTROL.	1-29
PROTECTIVE DEVICES.	1-29

MACHINE MAINTENANCE INSTRUCTIONS **1-30**

GENERAL INSTRUCTIONS	1-30
PLACING THE JIB SAFETY WEDGE	1-30
FITTING THE WEDGE	1-30
REMOVING THE WEDGE	1-30
FITTING THE WEDGE	1-30
REMOVING THE WEDGE	1-30
MAINTENANCE	1-31
MAINTENANCE LOGBOOK	1-31
LUBRICANT AND FUEL LEVELS	1-31
HYDRAULICS	1-31
ELECTRICITY	1-31
WELDING ON THE MACHINE	1-31
WASHING THE MACHINE	1-32
TRANSPORTING THE MACHINE	1-32

PROLONGED MACHINE SHUTDOWN **1-32**

INTRODUCTION	1-32
PREPARATION OF THE MACHINE	1-32
DEF (Diesel Exhaust Fluid) TANK	1-32
PROTECTING THE ENGINE	1-33
MACHINE PROTECTION	1-33
RETURNING THE MACHINE TO SERVICE	1-33

DISPOSING OF THE MACHINE **1-34**

RECYCLING OF MATERIALS	1-34
METALS	1-34
PLASTICS	1-34
RUBBER	1-34
GLASS	1-34
ENVIRONMENTAL PROTECTION	1-34
WORN OR DAMAGED PARTS	1-34
USED OIL	1-34
USED BATTERIES	1-34

INSTRUCTIONS TO THE COMPANY MANAGER

THE SITE

Proper management of the machine's area of travel will reduce the risk of accidents:

- ground not unnecessarily uneven or obstructed,
- no excessive slopes,
- pedestrian traffic controlled, etc.

THE OPERATOR

- Only qualified, authorized personnel can use the machine. This authorization is given in writing by the appropriate person in the establishment where the machine is to be used and must be carried permanently by the operator.

⚠ IMPORTANT ⚠

Experience has shown that there are a number of inappropriate ways in which the machine might be operated. Such foreseeable misuse, of which the main examples are listed below, are strictly forbidden.

- The foreseeable abnormal behavior resulting from ordinary negligence, but not from any intentional misuse of the equipment.

- The reflex reactions of a person in the event of a malfunction, incident, fault, etc. during operation of the machine.

- Behavior resulting from application of the "principle of least effort" when performing a task.

- For certain machines, the foreseeable behavior of such persons as: apprentices, teenagers, handicapped persons, trainees tempted to drive a machine, operators tempted to operate a machine to win a bet, in competition or for their own personal experience.

The person in charge of the equipment must take these criteria into account when assessing whether or not a person will make a suitable driver.

THE MACHINE

A - SUITABILITY OF THE MACHINE FOR THE TASK

- MANITOU has ensured that this machine is suitable for use under the standard operating conditions defined in this operator's manual, with a **STATIC TEST COEFFICIENT OF 1.25** and a **DYNAMIC TEST COEFFICIENT OF 1**, as specified in harmonized standard **EN 1459** for variable reach machines.
- Before commissioning, the facility manager must make sure that the machine is appropriate for the work to be done, and perform certain tests (in accordance with applicable legislation).

B - ADAPTING THE MACHINE TO USUAL ENVIRONMENTAL CONDITIONS

⚠ IMPORTANT ⚠

Lubricants are filled in the factory for average climatic use, i.e.: -15 °C (4,9 °F) to +35 °C (95 °F).

For operation under more severe climatic conditions, before starting up, drain all circuits then fill using lubricants suitable for the ambient temperatures.

The same applies to the coolant.

⚠ IMPORTANT ⚠

The machines are designed for outdoor use under normal atmospheric conditions and indoor use in suitably aerated and ventilated premises. It is prohibited to operate the machine in areas which presents a risk of fire or which are potentially explosive (e.g. refineries, fuel or gas depots, stores of flammable products, etc.).

Specialized equipment is available when operating in these areas (ask your dealer for information).

- Our machines are designed to be used within a temperature range of -18 °C (-0.4°F) to +43 °C (109.4°F).
- In addition to the standard equipment fitted on your machine, many options are available, such as: road lighting, stop lights, rotating beacon light, reverse lights, front worklight, rear worklight, lifting structure worklight, etc. (depending on machine model).
- The operator must take into account the operating conditions to specify the machine's signaling and lighting equipment. Consult your dealer.
- Take into account the climatic and atmospheric conditions of the operation site. Consult your dealer for the suitability of lubricants and frost protection.
- Take into account the fire risk associated with use in dusty and flammable conditions (e.g. straw, flour, sawdust, organic waste, etc.).
- A machine operating in an area without fire extinguishing equipment must be equipped with an individual extinguisher. Solutions exist, consult your dealer.

Our machines comply with Directive 2014/30/EU (2015/208/EU for our type-approved "TRACTOR" machines) concerning electromagnetic compatibility (EMC), (UK : Electromagnetic Compatibility Regulations 2016) and with the corresponding harmonized standard EN 12895. Their correct operation is no longer guaranteed if they are used within areas in which the electromagnetic fields exceed the limit specified by this standard (20 V/m).

- Directive 2002/44/EC requires company managers to not expose their employees to excessive vibration doses. There is no recognized code of measurement for comparing the machines of different manufacturers. The actual doses received cannot therefore be measured under actual operating conditions at the user's premises.
- The following are some tips for minimizing these vibration doses:
 - Select the most suitable machine and attachment for the intended use.
 - Adapt the seat adjustment to the operator's weight (**depending on machine model**) and maintain it in good condition, as well as the cab suspensions. Inflate the tires in accordance with recommendations.
 - The seat is an essential way of reducing the vibrations transmitted to the operator. In the event of seat replacement, please contact MANITOU.
 - Ensure that the operators adapt their operating speed to suit the conditions on site.
 - As far as possible, arrange the site in such a way as to provide a flat running surface and remove obstacles and harmful potholes.

C - MODIFYING THE MACHINE



Modifying the structure and settings of the various components of your machine (hydraulic pressure, taring of limiters, engine speed, sensors, addition of extra equipment, addition of counterweights, unapproved and unauthorized attachments, alarm systems, etc.) yourself is strictly prohibited. In this case, the manufacturer cannot be held responsible.

D - FRENCH ROAD TRAFFIC RULES

(or see current legislation in other countries)

- Only one EC declaration of conformity is issued. It must be kept in a safe place.
- The road traffic rules for the machines are subject to the provisions of the highway code, according to the following categories:
 - Construction machinery (MT range): public works vehicle not predominantly for use on roads (point 6.9 of Article R.311-1 of the French Highway Code). The machine must have a 25 disc displayed on the rear of the machine and an operating license plate.
 - Non-type-approved "Tractor" machinery for agricultural work: (point 6.2 of Article R.311-1 of the French Highway Code). The machine must be fitted with an operating license plate.
 - Type-approved "Tractor" machinery for agricultural work: Agricultural tractor type T1a (point 5.1.1 of Article R.311-1 of the French Highway Code). The machine must be licensed.

SPECIAL INSTRUCTIONS APPLICABLE TO TYPE-APPROVED "TRACTOR" MACHINES

- All approved machines are supplied with a "Tractor" certificate of compliance with Regulation 167/2013, to be retained by the owner, and a page of administrative details together with a CNIT number (national type approval code) for registration at the prefecture.
- The owner of the machine is responsible for carrying out the necessary procedures for obtaining the vehicle registration document within the time limit defined by the regulations.
- The operator must hold a category B driver's license, unless granted an exemption.
- The machine must be driven on the public highway in accordance with the instructions given in the manual supplied with the machine (Gross weight, Gross combination weight, towing load, axle loads, maximum speeds, etc. according to the type/version). The operator must be in possession of the machine's registration document.



When towing a trailer or agricultural equipment, the traveling speed of the machine is limited to 25 km/h.

In this case, a "25" disc must be affixed to the rear of the convoy.

E - MACHINE CAB PROTECTION

- All machines comply with standard ISO 3471 Roll-over Protective Structures (ROPS)
- All machines comply with standard ISO 3449 Falling-Object Protective Structures (FOPS) (Level I or II) (↖ 2 - DESCRIPTION OF STICKERS AND PLATES)
- The windows used on our machines comply with standard ECE-R43 Operator Protective Structures (OPS).
- Approved "TRACTOR" machines also comply with the regulations:
 - (appendix 1322/2014-OCDE Code 4).
 - (appendix 1322/2014-OCDE Code 10).



Structural damage or overturning, a modification, changes or a poorly executed repair can reduce the protective efficiency of the cab, canceling its compliance.

Do not perform welding or drilling on the cab structure.

Consult your dealer to determine the limits of this structure without canceling its compliance.

INSTRUCTIONS

- The operator's manual must always be in good condition, in the language of the operator and placed in the storage compartment provided.
- The operator's manual and any plates or stickers which are no longer legible or are damaged, must be replaced immediately.

MAINTENANCE

⚠ IMPORTANT ⚠

Refer to chapter: MACHINE MAINTENANCE INSTRUCTIONS.

⚠ IMPORTANT ⚠

Your machine must be periodically inspected to ensure its continued compliance.

The frequency of this inspection is defined by the legislation in force in the country in which the machine is used.

- Maintenance or repairs other than those detailed in Part: 3 - MAINTENANCE must be carried out by qualified personnel (consult your dealer) and in the necessary safety conditions to preserve the health of the operator and any third party.
- Example for France "The manager in charge of the establishment using a machine must open and maintain a maintenance log for each machine (order of March 2, 2004) and undergo a general periodic inspection every 6 months (order of March 1, 2004)".

INSTRUCTIONS FOR THE OPERATOR

FOREWORD

⚠ IMPORTANT ⚠

The risk of accident while using, servicing or repairing this machine can be reduced if you follow the safety instructions and preventive measures detailed in this instruction manual.

Failure to respect the safety and operating instructions, or the instructions for repairing or servicing your machine may lead to serious, even fatal accidents.

⚠ IMPORTANT ⚠

In order to reduce or prevent any danger with a MANITOU-approved attachment, follow the instructions in paragraph: 4 - ADAPTABLE ATTACHMENTS AVAILABLE ON THE RANGE: INTRODUCTION.

- Only the operations and maneuvers described in these operator's manual must be performed. The manufacturer cannot predict all possible risky situations. Consequently, the safety instructions given in the operator's manual and on the machine itself are not exhaustive.
- At all times, as an operator, you must envisage, within reason, the possible risk to yourself, to others or to the machine when you use it.
- The operator is responsible for the machine in all circumstances, regardless of whether he is present in the driver's cab.

GENERAL INSTRUCTIONS

A – OPERATOR'S MANUAL

⚠ IMPORTANT ⚠

Carefully read and understand this operator's manual before operating this machine.

- The operator's manual must always be in good condition, in the language of the operator and placed in the storage compartment provided.
- Any operations or maneuvers not described in the operator's manual are proscribed.
- Follow the safety advice and the instructions described on the machine's stickers.
- Familiarize yourself with the machine on the ground where it will be operated.
- You must replace the instruction manual, as well as any plates or stickers, if they are no longer legible or are missing or damaged.

B - AUTHORIZATION FOR USE IN FRANCE

(or see current legislation in other countries).

- Only qualified, authorized personnel can use the machine. This authorization is given in writing by the appropriate person in the establishment where the machine is to be used and must be carried permanently by the operator.
- The operator is not empowered to authorize the driving of the machine by another person.

C - MAINTENANCE

- If the operator sees that the machine is not in good working order or does not comply with the safety instructions, he must inform his manager of this immediately.
- The operator is prohibited from carrying out any repairs or adjustments himself, unless he has been trained for this purpose. He must keep the machine properly cleaned if this is his responsibility.
- The operator must carry out the daily maintenance (↖ 3 - MAINTENANCE) before using the machine in his place of work.
- The operator is responsible for deciding and adjusting the frequency and type of the cleaning needed to prevent the risk of fire ensuing from the build-up of flammable material(s). The operator should pay special attention to all the areas of the machine where these high-risk materials are likely to accumulate (e.g. engine compartment, under the lifting structure, above the axles, inside the chassis, etc.).

D - TIRES

⚠ IMPORTANT ⚠

Do not use the machine if the wheels are damaged or excessively worn, because this could put your own safety or that of others at risk, or cause damage to the machine.

- The operator must ensure tires are suitable for the nature of the ground (see contact surface with the ground for the tires in the chapter: 2 - DESCRIPTION: TIRES). Optional solutions are available, please consult your dealer.
 - SAND tires.
 - FARM tires.
 - Snow chains.
- The machine's four tires must be the same brand, the same dimensions, the same structure (radial or diagonal) and the same usage category (normal, snow or special), and must have the same degree of tread wear.
- In the event of tire replacement, use tires authorized by MANITOU that are the same type and dimensions. Using different tires voids the machine's type approval and you may be liable.
- If you are replacing just one of the machine's tires (e.g. because it is damaged), we recommend choosing a tire with the same degree of wear as the remaining tires so as not to damage the transmission's kinematic chain.

⚠ IMPORTANT ⚠

Do not use the machine if the tires are damaged or excessively worn, because this could put your own safety or that of others at risk, or cause damage to the machine itself.


The fitting of foam inflated tires is prohibited and is not guaranteed by the manufacturer unless with prior authorization.

E - MODIFYING THE MACHINE

- ⚠ INSTRUCTIONS TO THE COMPANY MANAGER: ⚠ C - MODIFYING THE MACHINE.

F - LIFTING PEOPLE

- The use of working equipment and load lifting attachments to lift people is:
 - either forbidden
 - or authorized exceptionally and under certain conditions (⚠ regulations in force in the country in which the machine is used).
- The pictogram posted at the operator station reminds you that:
 - Left-hand column
 - It is forbidden to lift people, with any kind of attachment, using a non PLATFORM-fitted machine.
 - Right-hand column
 - With a PLATFORM-fitted machine, people can only be lifted using platforms designed by MANITOU for this purpose.
- MANITOU sells equipment specifically designed for lifting people (OPTION PLATFORM-fitted machine; contact your dealer).



A - BEFORE STARTING UP THE MACHINE

- Perform the daily maintenance operations (< 3 - MAINTENANCE).
- Make sure that the driver's cab is clean, particularly the floor and floor mat. Check that no movable object may hinder the operation of the machine.
- Make sure the lights, turn signals and windshield wipers are working properly.
- Make sure the rear-view mirrors are in good condition, clean and properly adjusted.
- Make sure the horn works.

B - AVAILABLE IN THE DRIVER'S CAB

- Whatever his experience, the operator is advised to familiarize himself with the position and operation of all the controls and instruments before operating the machine.
- Wear clothes suitable for driving the machine, avoid loose clothing.
- Make sure you have the appropriate protective equipment for the task to be performed.
- Prolonged exposure to high noise levels may cause hearing problems. It is recommended to wear ear muffs to protect against excessive noise.
- Always face the driver's cab access when getting in and out of the lift truck and use the handle(s) provided for this purpose. Do not jump out of the machine.
- Remain alert at all times when using the machine. Do not listen to the radio or music using headphones or earphones.
- Never operate the lift truck when hands or feet are wet or soiled with greasy substances.
- For increased comfort, adjust the seat to your requirements and adopt the correct position in the driver's cab.




Under no circumstances must the seat be adjusted while the machine is moving.

- The operator must always be in his normal position in the driver's cab: Arms and legs, and generally any part of the body, should be kept inside the driver's cab of the machine.
- The safety belt must be worn and adjusted to the operator's size.
- The control units must never be used for any other than their intended purposes (e.g. Climbing onto or down from the machine, coat hanger, etc.).
- If the control components are fitted with a forced operation (lever lock) device, it is forbidden to leave the cab without first putting these controls in neutral.
- It is prohibited to carry passengers either on the machine or in the cab.


C - ENVIRONMENT

- Comply with site safety regulations.
- If you have to use the machine in a dark area or work at night, make sure it is equipped with work lights.
- During handling operations, make sure that no one is in the way of the machine and its load.
- Do not allow anybody to come near the working area of the machine or pass beneath an elevated load.
- The maximum slope on which the machine can be used in relation to the capacity of the brake is 20%.
- When using the lift truck on a transverse slope, before lifting the lifting structures, observe the instructions given in the paragraph: INSTRUCTIONS FOR HANDLING A LOAD: D - TRANSVERSE ATTITUDE OF THE MACHINE.
- Traveling on a longitudinal slope:
 - Drive and brake gently.

- Moving without load: Forks or attachment facing downhill.



- Moving with load: Forks or attachment facing uphill.



- Take into account the machine's dimensions and its load before trying to negotiate a narrow or low passageway.
- Never move onto a load bridge without having first checked:
 - That it is suitably positioned and made fast.
 - That the unit to which it is connected (wagon, truck, etc.) will not shift.
 - That this bridge is prescribed for the total weight of the machine, laden or unladen.
 - That this bridge is prescribed for the size of the machine.

- Never move onto a foot bridge, floor or freight lift, without being certain that they are suitable for the weight and size of the machine, laden or otherwise, and without having checked that they are in sound working order.
- Be careful in the area of loading bays, trenches, scaffolding, soft ground and manholes.
- Make sure the ground is stable and firm under the wheels and/or stabilizers before lifting or removing the load. If necessary, add appropriate wedging under the stabilizers.
- Make sure that the scaffolding, loading platform, pilings or ground is capable of bearing the load.
- Never stack loads on uneven ground, they may tip over.

⚠ IMPORTANT ⚠

If the load or the attachment must remain above a structure for a prolonged period of time, there is the risk that it will bear on the structure as the lifting structure descends due to cooling of the oil in the cylinders.

To eliminate this risk:

- Regularly check the distance between the load or the attachment and the structure and readjust this if necessary.

- If possible use the machine at an oil temperature as close as possible to ambient temperature.

- In the case of work near to overhead lines, ensure that the safety distance is sufficient between the machine's working area and the overhead line.

⚠ IMPORTANT ⚠

Do not operate this machine during thunderstorms, snowstorms, periods of frost, or in hazardous weather conditions.

⚠ IMPORTANT ⚠

You must consult your local electrical supplier.

You could be electrocuted or seriously injured if you operate or park the machine too close to power lines.

In the event of high winds, do not carry out handling work that jeopardizes the stability of the machine and its load, particularly if the load catches the wind badly.

- Prevent the fire risk associated with use in dusty and flammable conditions (e.g. straw, flour, sawdust, organic waste, etc.).

D - VISIBILITY

- The safety of people within the machine's working area, as well as that of the machine itself and the operator, are dependent on good operator visibility of the machine's immediate surroundings in all situations and at all times.
- This machine has been designed to allow good operator visibility (direct or indirect by means of rear-view mirrors) of the immediate surroundings of the machine while driving with no load and with the boom in the transport position.
- Special precautions must be taken if the size of the load restricts visibility towards the front:
 - moving in reverse,
 - site layout,
 - assisted by a person directing the operation (while standing outside the machine's area of travel), making sure to keep this person clearly in view at all times,
 - in any case, avoid reversing over long distances.
- Certain special accessories may require the machine to travel with the boom in the raised position. In such cases, visibility on the right hand side is restricted, and special precautions must be taken:
 - site layout,
 - assisted by a person directing the operation (while standing outside the machine's area of travel).
 - replacement of a suspended load by a load on a pallet.
- If visibility of your road is inadequate, ask someone to assist by directing the operation (while standing outside the machine's area of travel), making sure to keep this person clearly in view at all times.
- Keep all components affecting visibility in a clean, properly adjusted state and in good working order (e.g. windshields, windows, windshield wipers, windshield washers, driving lights and worklights, rear-view mirrors).

E - STARTING THE MACHINE

SAFETY INSTRUCTIONS

⚠ IMPORTANT ⚠

The machine must only be started up or maneuvered when the operator is sitting in the driver's cab with seat belt fastened and adjusted.

- Never try to start the machine by pushing or towing it. Such an operation may cause severe damage to the transmission. If necessary, towing requires the transmission to be put in neutral (< 3 - MAINTENANCE).
- If using an emergency battery for start-up, use a battery with the same characteristics and respect battery polarity when connecting it. Connect at first the positive terminals before the negative terminals.

⚠ IMPORTANT ⚠

Failure to respect polarity between batteries can cause serious damage to the electrical circuit.

The electrolyte in the battery may produce an explosive gas. Avoid flames and generation of sparks close to the batteries.

Never disconnect a battery while it is in charge.

INSTRUCTIONS

- Check the closing and locking of the hood(s).
- Check that the cab door is closed.
- Firmly press and hold down the brake pedal.
- Turn the ignition key to position (I) to switch on the machine and the engine preheat system.
- Check that the forward/reverse selector is in neutral, and that the manual parking brake is on.
- Check the fuel level on the dashboard gauge.
- Check the DEF (diesel exhaust fluid) level on the dashboard gauge. (depending on machine model)
- Turn the ignition key to position (III) for no longer than 15 seconds. The engine should then start. Release the ignition key and let the engine run at idling speed.
- Preheat the engine between each start attempt.
- Make sure all the signal lights on the control instrument panel are off.
- Do not use a machine that is non-compliant.
- Check all control instruments when the engine is warm and at regular intervals during use, so as to quickly detect any faults and to be able to correct them without any delay.
- If an instrument does not show the correct display, stop the engine and immediately carry out the necessary operations.

F - OPERATING THE MACHINE

SAFETY INSTRUCTIONS

⚠ IMPORTANT ⚠

We would like to draw the operators' attention to the risks involved in using the machine, in particular:

- Risk of losing control.

- Risk of loss of lateral and frontal stability of the machine.

The operator must remain in control of the machine.

In the event of the machine overturning, do not try to leave the cab during the incident.

YOUR BEST PROTECTION IS TO STAY FASTENED IN THE CAB.

- Observe the company's traffic regulations or, by default, the public highway code.
- Do not carry out operations which exceed the capacities of your machine or attachment.
- Always drive the machine with the forks or attachment in the transport position, i.e., at 300 mm (11.81 in) from the ground, the boom retracted and the forks carriage sloping backwards.
- Only carry loads which are balanced and properly anchored to avoid any risk of a load falling off.
- Ensure that pallets, cases, etc. are in good order and suitable for the load to be lifted.
- Familiarize yourself with the machine on the terrain where it will be used.
- Ensure that the brakes are working properly.
- The loaded machine must not travel at speeds in excess of 12 km/h (7.46 mph).
- Drive smoothly at an appropriate speed for the operating conditions (land configuration, load on the machine).
- Do not use the hydraulic boom controls when the machine is moving.
- Never change the steering mode whilst driving.
- Ensure that visibility is adequate.
- Do not maneuver the machine with the boom in the raised position unless under exceptional circumstances and then with extreme caution, at very low speed and using gentle braking.
- Take bends slowly.

- In all circumstances make sure you are in control of your speed.
- On damp, slippery or uneven terrain, drive slowly.
- Brake gently, never abruptly.
- Only use the machine's forward/reverse selector from a stationary position and never do so abruptly.
- Do not drive with your foot on the brake pedal.
- Always remember that hydrostatic type steering is extremely sensitive to movement of the steering wheel, so turn it gently and not jerkily.
- Never leave the engine on when the lift truck is unattended.
- Do not leave the cab when the machine has a raised load.
- Look where you are going and always make sure you have good visibility along the route.
- Use the rear-view mirrors frequently.
- Drive around obstacles.
- Never drive on the edge of a ditch or steep slope.
- It is dangerous to use two machines simultaneously to handle heavy or bulky loads, since this operation requires particular precautions to be taken. It must only be used exceptionally and after risk analysis.
- The ignition switch has an emergency stop mechanism in case of an operating anomaly occurring in the case of machines not fitted with a punch-operated cut-out.

INSTRUCTIONS

- Always drive the machine with the forks or attachment in the transport position, i.e., 300 mm from the ground, the telescopic arm retracted and the forks carriage sloping backward.
- For machines with gearboxes, use the recommended gear (↩ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS).
- Select the steering mode appropriate for the use and/or working conditions (↩ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS) (depending on machine model).
- Deactivate the parking brake.
- Shift the forward/reverse selector to the selected direction of travel and accelerate gradually until the machine moves off.

⚠ IMPORTANT ⚠

Starting and moving the machine on a slope may be a real hazard.

If the machine is parked or stopped, adhere scrupulously to the following instructions for moving it:

- Press the brake pedal.

- Release the parking brake.

- Engage the appropriate gear. (depending on machine model)

- Select forward or reverse direction.

- Ensure that there is no one or anything impeding the movement of the machine.

- Release the brake pedal and accelerate the engine.

The use of the machine loaded or with a trailer increases the risk. In this case, remain extremely vigilant.

Each braking system operates independently.

In an emergency, use the brake pedal and/or the manual parking brake to immobilize the machine.

With the engine off, release the manual parking brake only after restarting the engine and making sure that the brake pedal is functional.

G - STOPPING THE MACHINE

SAFETY INSTRUCTIONS

- Never leave the ignition key in the machine during the operator's absence.
- When the machine is stationary, or if the operator has to leave his cab (even for a moment), place the forks or attachment on the ground, apply the parking brake and place the forward/reverse selector in neutral.
- Make sure that the machine is not stopped in any position that will interfere with the traffic flow and at less than one meter from the track of a railway.
- In the event of prolonged parking on a site, protect the machine from bad weather, particularly from frost (check the level of antifreeze), and close and lock all the machine accesses (doors, windows, cowls, etc.).

INSTRUCTIONS

- Park the machine on level ground.
- When parking on slopes of less than 15%, position the machine perpendicular to the slope.
- The slope must not exceed 15%.
- Press and hold the brake pedal.
- Set the forward/reverse selector to neutral.
- Activate the parking brake.
- Release the brake pedal.
- The machine must be stationary before leaving the driver's cab.
- Fully retract the telescopic arm.
- Lower the forks or attachment to rest on the ground.
- When using an attachment with a grab or jaws, or a bucket with hydraulic opening, close the attachment fully.
- Before stopping the machine after intensive work, leave the engine idling for a few moments to allow the coolant and oil to lower the temperature of the engine and transmission. Do not forget this precaution, in the event of frequent stops or warm stalling of the engine, or else the temperature of certain parts will rise significantly due to the stopping of the cooling system, with the risk of badly damaging such parts.
- Stop the engine with the ignition switch and remove the key.
- Lock all the openings to the machine (doors, windows, cowls, etc.).
- Turn the battery cut-off to the "OFF" position in accordance with the recommendations (↖ 2 - DESCRIPTION).

H - DRIVING THE MACHINE ON THE PUBLIC HIGHWAY

(or see current legislation in other countries)

FRENCH ROAD TRAFFIC RULES

- The driving of non-type-approved "Tractor" machines on the public highway is subject to the provisions of the French Highway Code relating to special machines, defined in Article R.311-1 of the French Highway Code, in category B of the Equipment Order of November 20, 1969, which determines the procedures applicable to special machines. The machine must be fitted with an operating license plate.
- The driving of type-approved "Tractor" machines on the public highway is subject to the provisions of the French Highway Code relating to agricultural tractors, defined in Article R.311-1 of the French Highway Code. The machine must be licensed.
- The machine must be driven on the public highway in accordance with the instructions given in the manual supplied with the machine (Gross weight, Gross combination weight, towing load, axle loads, maximum speeds, etc. according to the type/version). The operator must be in possession of the machine's registration document.
- The operator must hold an HGV license, unless granted an exemption.
- When towing a trailer or agricultural equipment, the travel speed of the machine is limited to 25 km/h. In this case, a "25" disc must be affixed to the rear of the convoy.

GERMAN ROAD TRAFFIC RULES

⚠ IMPORTANT ⚠

For machines with the "Allgemeine Betriebserlaubnis" (general operating permit or ABE, in accordance with Article 20 of the StVZO "Straßenverkehrs-Zulassungsordnung"), follow the instructions below:

- Disconnect the reversing sound alarm before using a machine with a general operating permit (ABE) on the public highway.

⚠ IMPORTANT ⚠

Always reconnect the sound alarm before handling on private roads.

- Before you use the machine for handling operations on private roads:
 - Make sure that the machine's reversing sound alarm is connected and working properly.
 - Perform a functional test by putting the machine into reverse gear.
 - The audible alarm sounds.
 - Do not use the machine if the audible alarm is not working. Check the audible alarm's connection and repeat the test. Consult your dealer if the problem persists.

SAFETY INSTRUCTIONS

- Operators driving on the public highway must comply with current highway code legislation.
- The machine must comply with current road legislation. If necessary, there are optional solutions. Contact your dealer.

INSTRUCTIONS

- Make sure the revolving light is in place, switch it on and verify its operation.
- Make sure the lights, turn signals and windshield wipers are working properly.
- Check the cleanliness of the machine's mudguards.
- Check the general cleanliness of the machine before driving on public roads.
- Switch off the worklights if the machine is fitted with them.
- Select the steering mode "HIGHWAY TRAFFIC" (↔ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS) (depending on machine model).
- Fully retract the telescopic arm and set the attachment approximately 300 mm (11.81 in) off the ground.
- Put the frame leveling in the central position, i.e., the transverse axis of the axles parallel to the frame (depending on the machine model).
- Fully raise the stabilizers and turn the shoes inwards (depending on the machine model).

⚠ IMPORTANT ⚠

Never coast in neutral (forward/reverse selector or gear lever in neutral or transmission cut-off button pressed) to preserve the machine's engine brake.

Failure to observe this instruction on a slope will lead to excessive speed, which may make the machine uncontrollable (steering, brakes) and cause serious mechanical damage.

DRIVING THE MACHINE WITH A FRONT-MOUNTED ATTACHMENT

- You must comply with current regulations in your country, covering the possibility of driving on the public highway with a front-mounted attachment on your machine.
- If road legislation in your country authorizes circulation with a front-mounted attachment, you must at least:
 - Protect and report any sharp and/or dangerous edges on the attachment (↖ 4 - ADAPTABLE ATTACHMENTS AVAILABLE ON THE RANGE).
 - The attachment must not be loaded.
 - Make sure that the attachment does not mask the lighting range of the forward lights.
 - Make sure that current legislation in your country does not require other obligations.

OPERATING THE MACHINE WITH A TRAILER

- For using a trailer, observe the regulations in force in your country (maximum travel speed, braking, maximum weight of trailer, etc.).
- Do not forget to connect the trailer's electrical equipment to that of the machine.
- The trailer's braking system must comply with current legislation.
- If pulling a trailer with assisted braking, the tractor machine must be equipped with a trailer braking mechanism. In this case, do not forget to connect the trailer braking equipment to that of the machine.
- The vertical force on the towing hook must not exceed the maximum authorized by the manufacturer (consult the manufacturer's plate on your machine).
- The authorized gross vehicle weight must not exceed the maximum weight authorized by the manufacturer (↖ 2 - DESCRIPTION: SPECIFICATIONS).

IF NECESSARY, CONSULT YOUR DEALER.

INSTRUCTIONS FOR HANDLING A LOAD

A - CHOICE OF ATTACHMENTS

- Only attachments approved and authorized by MANITOU can be used on its machines.
- Make sure the attachment is suitable for the work to be done (◀ 4 - ADAPTABLE ATTACHMENTS AS OPTIONS ON THE RANGE).
- If the machine is equipped with the single sideshift attachment OPTION (TSDL), use only the authorized attachments (◀ 4 - ADAPTABLE ATTACHMENTS AS OPTIONS ON THE RANGE).
- Make sure the attachment is correctly installed and locked onto the machine carriage.
- Make sure that your machine attachments are working properly.
- Comply with the load chart limits for the machine for the attachment used.
- Do not exceed the rated capacity of the attachment.
- Never lift a slung load without the attachment provided for the purpose, as there is a risk of the sling slipping (◀ INSTRUCTIONS FOR HANDLING A LOAD: H - PICKING UP AND PUTTING DOWN A SUSPENDED LOAD).
- Do not handle loads suspended by straps directly on the forks (e.g.:big bags), as there is a risk of shearing on sharp edges. Use an attachment designed for this purpose.



B - WEIGHT OF LOAD AND CENTER OF GRAVITY

- Before picking up a load, you must know its weight and its center of gravity.
- The longitudinal position of the center of gravity in relation to the heel of the forks (Fig. B1) is defined on the load chart for your machine (◀ 2 - DESCRIPTION: DIMENSIONS AND LOAD CHARTS). For loads with center of gravity exceeding this distance, contact your dealer.
- For irregular loads, determine the transverse center of gravity before any handling (fig. B2) and set it in the longitudinal axis of the machine.

⚠ IMPORTANT ⚠

It is forbidden to handle a load heavier than the effective capacity defined on the machine load chart.

For loads with a moving center of gravity (e.g. liquids), take account of the variations in the center of gravity in order to determine the load to be handled and be extra vigilant and careful to limit these variations as far as possible.





C - LONGITUDINAL STABILITY INDICATOR

⚠ IMPORTANT ⚠

Always watch this device during handling operations.

- Letters and angle indicator (fig. C1) allow to read and respect load capacities of the lifttruck according to the load chart (◀ 2 - DESCRIPTION: LOAD CHART).
- When the device is in limit stability, it is forbidden to perform so-called «AGGRAVATING» movements, these being:
 - A - Extending the boom.
 - B - Lowering the boom.
- Perform movements to relieve aggravation in the following order (fig. C2): if necessary, raise the boom (1), retract the boom as far as possible (2) and lower the boom (3) to release the load.



D - TRANSVERSE ATTITUDE OF THE MACHINE

Depending on machine model

The transverse attitude is the transverse slope of the frame with respect to the horizontal. Raising the boom reduces the machine's lateral stability. The machine's transverse attitude must be set with the boom in the down position as follows:

1 - MACHINE WITHOUT FRAME LEVELING USED ON TIRES



- Position the machine so that the bubble in the level is between the two lines (↖ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS).

2 - MACHINE WITH FRAME LEVELING USED ON TIRES

- Correct the tilt using the hydraulic control and check the horizontality with the spirit level. The bubble of the level must be between the two lines (↖ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS).

3 - MACHINE USED ON STABILIZERS

- Set the two stabilizers on the ground and raise the two front wheels of the machine (fig. D1).
- Correct the tilt using the stabilizers (Fig. D2) and check the horizontality with the spirit level. The bubble of the level must be between the two lines (↖ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS). In this position, the two front wheels must be off the ground.



E - PICKING UP A LOAD ON THE GROUND

- Approach the machine perpendicular to the load, with the boom retracted and the forks in a horizontal position (fig. E1).
- Adjust the fork spacing and centering relative to the load to ensure stability (Fig. E2) (optional solutions exist, consult your dealer).
- Never lift a load with a single fork.





⚠ IMPORTANT ⚠

Beware of the risks of trapping or squashing limbs when manually adjusting the forks.

- Move the machine forward slowly (1) and bring the forks up to the stop in front of the load (Fig. E3). If necessary, slightly lift the boom (2) while picking up the load.
- Bring the load into the transport position.
- Tilt the load far enough backward to ensure stability (loss of load on braking or going downhill).

FOR A NON-PALLETIZED LOAD

- Tilt the carriage (1) forwards and move the machine slowly forwards (2), to insert the fork under the load (Fig. E4) (chock the load if necessary).
- Continue to move the machine (2) forward, tilting the carriage (3) (fig. E4) backward to position the load on the forks and check the load's longitudinal and lateral stability.



F - PICKING UP AND PUTTING DOWN A HIGH LOAD ON TIRES






⚠ IMPORTANT ⚠

You must not raise the boom if you have not checked the transverse attitude of the machine (← INSTRUCTIONS FOR HANDLING A LOAD D - TRANSVERSE ATTITUDE OF THE MACHINE).

REMINDER: Make sure that the following operations can be performed with good visibility (← OPERATING INSTRUCTIONS UNLADEN AND LADEN: D - VISIBILITY).






PICKING UP A HIGH LOAD ON TIRES

- Ensure that the forks will easily pass under the load.
- Raise and extend the boom (1) (2) until the forks are at the level of the load. If necessary, move the machine (3) forward (fig. F1), driving very slowly and carefully.
- Always remember to keep the distance necessary for inserting the forks under the load, between the stack and the machine (fig. F1) and use the shortest possible length of boom.
- Insert the forks under the load as far as they will go by alternately extending and lowering the boom (1) or, if necessary, moving the machine forward (2) (fig. F2). Activate the parking brake and place the forward/reverse selector in neutral.
- Lift the load slightly (1) and tilt the carriage (2) backwards to stabilize the load (Fig. F3).
- Tilt the load sufficiently backward to ensure its stability.
- Monitor the longitudinal stability indicator (← INSTRUCTIONS FOR HANDLING A LOAD: C - LONGITUDINAL STABILITY INDICATOR). If it is overloaded, set the load back down in the place from which it was picked up.
- If possible, lower the load without moving the machine. Raise the boom (1) to release the load, retract (2) and lower the jib (3) to set the load into transport position (fig. F4).
- If this is not possible, reverse the machine (1), maneuvering very gently and carefully to release the load. Retract (2) and lower the boom (3) to bring the load into the transport position (fig. F5).



PUTTING DOWN A HIGH LOAD ON TIRES

- Approach the load in the transport position in front of the stack (Fig. F6).
- Activate the parking brake and place the forward/reverse selector in neutral.
- Raise and extend the boom (1) (2) until the load is above the stack, while monitoring the longitudinal stability indicator (← INSTRUCTIONS FOR HANDLING A LOAD: C - LONGITUDINAL STABILITY INDICATOR). If necessary, move the lift truck (3) forward (fig. F7), driving very slowly and carefully.
- Place the load in a horizontal position and put it down on the pile by lowering and retracting the boom (1) (2) in order to position the load correctly (Fig. F8).
- If possible, release the forks by alternately retracting and raising the boom (1) (Fig. F9). Then set the forks into transport position.
- If this is not possible, reverse the machine (1), maneuvering very slowly and carefully to release the forks (fig. F10). Then set the forks into transport position.



G - PICKING UP AND PUTTING DOWN A HIGH LOAD ON STABILIZERS

Depending on machine model

⚠ IMPORTANT ⚠

You must not raise the boom if you have not checked the transverse attitude of the machine (← INSTRUCTIONS FOR HANDLING A LOAD D - TRANSVERSE ATTITUDE OF THE MACHINE).

REMINDER: Make sure that the following operations can be performed with good visibility (← OPERATING INSTRUCTIONS UNLADEN AND LADEN: D - VISIBILITY).

The stabilizers are used to optimize the machine's lifting performance (← 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS).

POSITIONING THE STABILIZERS WITH THE FORKS IN TRANSPORT POSITION (UNLADEN AND LADEN)

- Set the forks in transport position in front of the elevation.
- Stay far enough away to allow the boom to be raised.
- Activate the parking brake and place the forward/reverse selector in neutral.
- Set the two stabilizers on the ground and lift the two front wheels of the machine (fig. G1), while maintaining its transverse stability.

RAISING THE STABILIZERS WITH THE FORKS IN TRANSPORT POSITION (UNLADEN AND LADEN)

- Raise both stabilizers fully and at the same time.

LOWERING THE STABILIZERS WITH JIB UP (UNLADEN AND LADEN)

⚠ IMPORTANT ⚠

This operation must be exceptional and performed with great care.





- Raise the boom and retract the telescopes completely.
- Set the machine in position in front of the elevation (fig. G2), moving very slowly and carefully.
- Activate the parking brake and place the forward/reverse selector in neutral.
- Move the stabilizers very slowly and gradually as soon as they are close to the ground or in contact with it.
- Lower the two stabilizers and lift the two front wheels of the machine (fig. G3). During this operation, transverse attitude must be permanently maintained: the bubble in the level must be kept between the two lines.

SETTING THE STABILIZERS WITH THE BOOM UP (UNLADEN AND LADEN)

⚠ IMPORTANT ⚠





This operation must be exceptional and performed with great care.

- Keep the boom raised and retract the telescopes completely (Fig. G3).
- Move the stabilizers very slowly and gradually as soon as they are in contact with the ground and when they leave the ground. During this operation, transverse attitude must be permanently maintained: the bubble in the level must be kept between the two lines.
- Raise both stabilizers completely.
- Deactivate the parking brake and reverse the machine (1) very slowly and carefully to release it and lower the forks (2) into transport position (fig. G4).






PICKING UP A HIGH LOAD ON STABILIZERS

- Ensure that the forks will easily pass under the load.
- Check the position of the machine with respect to the load and make a test run, if necessary, without picking up the load.
- Raise and extend the boom (1) (2) until the forks are at the level of the load (Fig. G5).
- Bring the forks to the stop in front of the load by alternately extending and lowering the boom (1) (Fig. G6).
- Lift the load slightly (1) and tilt the carriage (2) backwards to stabilize the load (Fig. G7).
- Monitor the longitudinal stability indicator (⚠ INSTRUCTIONS FOR HANDLING A LOAD: C - LONGITUDINAL STABILITY INDICATOR). If it is overloaded, set the load back down in the place from which it was picked up.
- If possible, lower the load without moving the machine. Raise the boom (1) to release the load, retract (2) and lower the jib (3) to set the load into transport position (fig. G8).



SETTING DOWN A HIGH LOAD ON STABILIZERS

- Raise and extend the boom (1) (2) until the load is above the elevation (fig. G9), while monitoring the longitudinal stability indicator (⚠ INSTRUCTIONS FOR HANDLING A LOAD: C - LONGITUDINAL STABILITY INDICATOR).
- Position the load horizontally and release it by lowering and retracting the boom (1) (2) to position the load correctly (Fig. G10).
- Free the forks by alternately retracting and raising the boom (3) (Fig. G11).
- If possible, set the boom in transport position without moving the machine.



H - PICKING UP AND PUTTING DOWN A SUSPENDED LOAD

⚠ IMPORTANT ⚠

Failure to follow the above instructions may lead the machine to lose stability and overturn.

MUST be used with a machine equipped with an operational hydraulic movement cut-off device.

CONDITIONS OF USE

- The length of the sling or the chain shall be as short as possible to limit swinging of the load.
- Lift the load vertically along its axis, never by pulling sideways or lengthways.

HANDLING WITHOUT MOVING THE MACHINE

- Whether on stabilizers or on tires, the lateral attitude must not exceed 1% and the longitudinal attitude must not exceed 5%: the bubble of the level must be held at "0".
- Ensure that the wind speed is not higher than 10 m/s (32,8 fps).
- Ensure that there is no one between the load and the machine.

I - TRAVELING WITH A SUSPENDED LOAD

- Before moving, inspect the terrain in order to avoid excessive slopes and cross-falls, bumps and potholes, or soft ground.
- Ensure that the wind speed is not higher than (36 km/h 22,36 mph)
- The machine must not travel at more than 0.4 m/s (1.5 km/h (0.93 mph), i.e. one quarter walking speed).
- Drive and stop the machine gently and smoothly to minimize swinging of the load.
- Carry the load a few centimeters above the ground (max. 30 cm (11.81 in) the shortest possible jib length. Do not exceed the offset indicated on the load chart. If the load begins to swing excessively, do not hesitate to stop and lower the jib to set down the load.
- During transport, the lift truck operator must be assisted by a person on the ground (standing a minimum of 3 m (9 ft 10 in) from the load), who will limit swinging of the load using a bar or a rope. Ensure that this person is always clearly in view.
- The lateral attitude must not exceed 5%: the bubble in the level must be kept between the two "MAX" marks.
- The longitudinal attitude must not exceed 15% with the load facing uphill and 10% with the load facing downhill.
- The boom angle must not exceed 45°.

INSTRUCTIONS FOR USE AS A LOADER

For agricultural-type machines (MLT range)

A - LOADING

⚠ IMPORTANT ⚠

You must not raise the boom if you have not checked the transverse attitude of the machine (← INSTRUCTIONS FOR HANDLING A LOAD D - TRANSVERSE ATTITUDE OF THE MACHINE).

REMINDER: Make sure that the following operations can be performed with good visibility (← OPERATING INSTRUCTIONS UNLADEN AND LADEN: D - VISIBILITY).

FILLING THE BUCKET

- Place the bottom of the bucket in a horizontal position, just in contact with the ground (1) (Fig. A1).
- Move forward gradually (2) while simultaneously raising the boom and tilting the bucket backwards (3), for improved filling and breakout (Fig. A1).
- Reverse the machine (1) very carefully and gently to free the bucket. Lower the boom (2) into the transport position (Fig. A2).

⚠ IMPORTANT ⚠

Tilt the bucket sufficiently back to avoid spilling product and ensure its stability (loss of product under braking).

LOADING A TRAILER

- Approach the side of the trailer in the transport position (Fig. A3).
- Raise and extend the boom (1) (2) until the bucket is above the trailer, while monitoring the longitudinal stability indicator (← INSTRUCTIONS FOR HANDLING A LOAD: C - LONGITUDINAL STABILITY INDICATOR) (fig. A4).
- Drive the machine forward (3) very carefully and gently so that the bucket empties its load in the center of the trailer (Fig. A4).
- Immobilize the machine with the brake pedal and put the reversing shift lever in neutral.

N.B.: Immobilizing the machine with the brake pedal means that the transmission should be in neutral. Failure to follow this recommendation may lead to overheating and damage to the brakes.







- Slowly discharge the product (4) (Fig. A4).
- Tilt the bucket backwards (1) and reverse the machine (2) very carefully and gently (Fig. A5).
- Retract (3) and lower the boom (4) into the transport position (Fig. A5).

B - BACKFILLING

- Place the bottom of the bucket in a horizontal position, just in contact with the ground (1) (Fig. B1).
- Drive forward gradually (2). Once filled, the bucket will act as a leveling blade (Fig. B1).

⚠ IMPORTANT ⚠

When driving, beware of trenches as well as recently excavated and/or backfilled ground.



INSTRUCTIONS FOR USING THE MOBILE ELEVATING WORK PLATFORM

For machines equipped with a MOBILE ELEVATING WORK PLATFORM

A - AUTHORIZATION FOR USE

- Operation of the platform requires further authorization in addition to that of the machine.

B - SUITABILITY OF THE PLATFORM FOR THE JOB

- Our machines fitted with mobile elevating work platforms are compliant with standard **EN 280** for Europe and standard **AS/NZS 1418.10:2011** for Australia, corresponding to the classification of Group C1 to C3 in accordance with this standard.
- MANITOU has ensured that this platform is suitable for use under the normal operating conditions provided in this operator's manual, with a STATIC test coefficient of 1.25 and a DYNAMIC test coefficient of 1.1 as specified in harmonized European standard **EN 280** for mobile elevating work platforms.
- Before commissioning, the company manager must make sure that the platform is appropriate for the work to be done, and perform certain tests (in accordance with current legislation).

C - PROVIDED ON THE PLATFORM

- Wear suitable clothing when using the platform, avoid loose-fitting garments.
- Never use the platform with hands or shoes that are wet or soiled with greasy substances.
- Remain alert at all times when using the platform. Do not listen to the radio or music using headphones or earphones.
- MANITOU strongly recommends wearing a safety harness attached to an attachment point in the platform. Wearing a safety harness or other personal protection equipment against falls may be compulsory. Comply with local, government and national regulations in force, employer's safety rules and work site regulations .
- The safety harness or other personal protection equipment against falls must comply with local, government, and national regulations in force. They must be inspected in accordance with the regulations in force.
- The control units must never be used for any other than their intended purposes (e.g. Climbing onto or down from the machine, coat hanger, etc.).
- Safety helmets must be worn.
- The operator must always be in his normal position in the driver's cab: it is prohibited to have arms or legs, or generally any part of the body, outside the platform.
- Ensure that materials loaded onto the platform (pipes, cables, containers, etc.) cannot fall out. Do not pile these materials to the point where it is necessary to step over them.

D - USING THE PLATFORM

- However experienced they may be, operators must acquaint themselves with the emplacement and operation of all control instruments prior to operating the platform.
- Check before use that the platform has been correctly assembled and locked onto the machine.
- Do not enter or exit the platform unless it is fully lowered.
- Always enter and exit the platform through the gate or using the sliding mid rails (depending on the model).
- Always enter and exit facing the interior of the platform.
- Always use both hands and one foot or both feet and one hand to enter and exit the platform.
- Make sure that the sliding intermediate cross members (depending on the model) are in the lower position and that the gate is properly closed (depending on the model) before using this platform.
- Do not attach the sliding mid rails in the high position.
- The platform should be operated in an area free of any obstructions or danger when it is lowered to the ground.
- The operator using the platform must be aided by someone on the ground with adequate training.
- You should stay within the limits set out in the platform load chart.
- The lateral constraints are limited (↩ 2 - DESCRIPTION: SPECIFICATIONS).
- It is strictly forbidden to suspend a load from the platform or the machine's boom without an attachment provided for the purpose (↩ INSTRUCTIONS FOR HANDLING A LOAD: H - PICKING UP AND PUTTING DOWN A SUSPENDED LOAD).
- The platform cannot be used as a crane or a lift for permanently transporting people or materials, nor as jacks or supports.
- The machine must not be moved with one (or more) person(s) on the platform.
- It is forbidden to transport people on the platform using the hydraulic controls in the machine's cab (except in case of rescue).
- The operator must not climb onto to off the platform when it is not on ground level (jib retracted and in the down position).
- The machine must not be fitted with unauthorized attachments that increase the windage of the assembly.
- Do not use ladders or improvised structures on the platform to gain extra height.
- Do not climb onto the rails of the platform to gain extra height.
- It is forbidden to use the platform on forks. The fork slots are only to, be used for storing the platform and not for lifting people under any circumstances.


E - ENVIRONMENT

- Respect a safety distance between power lines or live components and any part of the body, any conductive object or any part of the machine, unless the local, government and national applicable regulations, the safety rules of the employer or construction site regulations are more strict in terms of distance required.
- Allow for platform movement and swaying or sagging power lines.

⚠ IMPORTANT ⚠

It is forbidden to use the platform close to electricity cables. Maintain the specified safe distances.

RATED VOLTAGE (VOLTS)	SAFETY DISTANCE (FT-IN/METRES)
50 < U < 1000	7-6.55/2,30
1000 < U < 30000	8-2.42/2,50
30000 < U < 45000	8-6.36/2,60
45000 < U < 63000	9-2.23/2,80
63000 < U < 90000	9-10.11/3,00
90000 < U < 150000	11-1.85/3,40
150000 < U < 225000	13-1.48/4,00
225000 < U < 400000	17-4.66/5,30
400000 < U < 750000	25-11.02/7,90



⚠ IMPORTANT ⚠

It is strictly forbidden to use the platform when the wind speed exceeds 45 km/h (27.96 mph).

- To visually recognize this wind speed, refer to the empirical wind evaluation scale below:

BEAUFORT scale (wind speed at a height of 32-9,7 ft-in (10 m) on a flat site)							
Force	Type of wind	Speed (knots)	Speed (mph)	Speed (km/h)	Speed (m/s)	Effects on Land	Sea conditions
0	Calm	0 - 1	0 - 1	0 - 1	<0.3	Smoke rises vertically.	Sea is like a mirror.
1	Light air	1 - 3	1 - 3	1 - 5	0.3 - 1.5	Smoke indicates direction of wind.	Ripples with appearance of scale, no foam crests.
2	Light breeze	4 - 6	4 - 7	6 - 11	1.6 - 3.3	Wind felt on face, leaves rustle.	Short wavelets, but pronounced.
3	Gentle breeze	7 - 10	8 - 12	12 - 19	3.4 - 5.4	Leaves and small twigs in constant motion.	Very small waves, crests begin to break.
4	Moderate breeze	11 - 16	13 - 18	20 - 28	5.5 - 7.9	Wind raises dust and loose pieces of paper; small branches are moved.	Small waves, becoming longer, numerous whitecaps.
5	Fresh breeze	17 - 21	19 - 24	29 - 38	8 - 10.7	Small trees in leaf begin to sway.	Wavelets form on inland waters; moderate waves, taking longer form.
6	Strong breeze	22 - 27	25 - 31	39 - 49	10.8 - 13.8	Large branches in motion, whistling heard in overhead wires, umbrella use becomes difficult.	Larger waves forming, whitecaps everywhere, some spray.
7	Near gale	28 - 33	32 - 38	50 - 61	13.9 - 17.1	Whole trees in motion, inconvenience felt when walking against the wind.	Sea heaps up; white foam from breaking waves begins to be blown in streaks along the direction of the wind.
8	Gale	34 - 40	39 - 46	62 - 74	17.2 - 20.7	Wind breaks twigs off trees; impedes progress.	Moderately high waves of greater length; edges of crests begin to break into spindrift.
9	Strong gale	41 - 47	47 - 54	75 - 88	20.8 - 24.4	Wind damages roofs (chimneys, slates, etc.).	High waves, crests of waves begin to topple, streaks of foam; reduced visibility.
10	Storm	48 - 55	55 - 63	89 - 102	24.5 - 28.4	Seldom experienced inland; trees uprooted; considerable structural damage occurs.	Very high waves; white streaks of foam; reduced visibility.
11	Violent storm	56 - 63	64 - 72	103 - 117	28.5 - 32.6	Very rare, widespread damage.	Exceptionally high waves able to hide medium sized ships from view, reduced visibility.
12	Hurricane	64 +	72 +	118 +	32.7 +	Devastating damage.	Sea completely white; air filled with foam and spray, very reduced visibility.

F - MAINTENANCE

⚠ IMPORTANT ⚠

Your platform must be periodically inspected to ensure its continued compliance.

The frequency of this inspection is defined by the legislation in force in the country in which the platform is used.

In France, a general periodic inspection every 6 months (Decree of March 1, 2004).

INSTRUCTIONS FOR USING THE RADIO-CONTROL

For machines with RC radio control

HOW TO USE THE RADIO-CONTROL

SAFETY INSTRUCTIONS

⚠ IMPORTANT ⚠

It is prohibited to lift people in the platform using the radio-control.

It is prohibited to use the radio-control from the platform:

- This radio-control consists of electronic and mechanical safety elements. It cannot receive commands from another transmitter because the internal encoding is unique to each radio-control.

⚠ IMPORTANT ⚠

If it is used improperly or incorrectly, there is a risk of danger to:

- *The physical and mental health of the user or others.*
- *The machine and other neighboring items.*

Everyone working with this radio-control:

- *Must be qualified in line with current regulations and trained accordingly.*
- *Must follow this instruction manual as closely as possible.*

- The system is used to control the machine remotely via radio waves. Commands are also transmitted if the machine is out of sight (behind an obstacle or a building for example), this is why:
 - After stopping the truck and removing the key switch (only possible when it is stationary), always place the transmitter in a safe, dry place.
 - Before performing any installation, servicing or repair work, always switch off power sources (in particular, electric welding devices and electric head units on hydraulic distributors must be disconnected at each section).
 - Never remove or alter the safety devices (such as the hand-guard frame, key, emergency stop button, etc.).

⚠ IMPORTANT ⚠

Never drive the machine if it is not continuously and perfectly within view of the operator.

- Before leaving the transmitter, the operator must make sure that it cannot be used by an unauthorized third person: either by removing the key button from the transmitter or locking it in an inaccessible place.
- The user must ensure that the instruction manual is accessible at all times and that operators have read and understood it.

INSTRUCTIONS

- Take up position in a stable place with no risk of slipping.
- Before using the transmitter, make sure there is nobody within the working area.
- Only use the transmitter with its carrying device or installed correctly on the platform.

⚠ IMPORTANT ⚠

When you remove the transmitter, remove the accumulator and key button so that it cannot be used accidentally or deliberately by anyone else.

PROTECTIVE DEVICES

- The machine will be immobilized within a maximum of 450 milliseconds (approx. 0.5 second):
 - If the emergency stop button of the transmitter is pressed (50 milliseconds), or that of the machine.
 - If the transmission distance of the radio waves is exceeded.
 - If the transmitter is faulty.
 - If an interfering radio signal is received from elsewhere.
 - If the accumulator is removed from its housing in the transmitter.
 - If the battery reaches the end of its autonomy.
 - If the transmitter is switched off by turning the key switch to the off position.
- These protective devices are provided for the safety of personnel and property and must never be modified, removed or bypassed in any way whatsoever!
- The hand-guard frame prevents external action on a joystick (e.g. if the transmitter is dropped, or if the operator leans on a guard-rail).
- An electronic safety device prevents radio transmission from being initiated if the joysticks are not mechanically and electrically at rest and if the internal combustion engine speed selector is not set to idle.

⚠ IMPORTANT ⚠

In an emergency, press the transmitter emergency stop button immediately; then follow the manual's instructions (→ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS).

MACHINE MAINTENANCE INSTRUCTIONS

GENERAL INSTRUCTIONS

⚠ IMPORTANT ⚠

Carefully read and understand this operator's manual before any operation on this machine.

Carry out all repairs immediately, even if the repairs concerned are minor.

Repair all leaks immediately, even if the leak concerned is minor.

Be careful of the risk of burns and splashing (exhaust, radiator, engine, hydraulic oil, etc.).

- Make sure the area is adequately ventilated before starting up the machine.
- Wear clothes suitable for the maintenance of the machine. Avoid wearing jewelry and loose clothes. Tie back and protect your hair, if necessary.
- Stop the engine and remove the ignition key before carrying out any work.

PLACING THE JIB SAFETY WEDGE

- The machine is equipped with a boom safety wedge (↔ 2 - DESCRIPTION: INSTRUMENTS AND CONTROLS) that must be installed on the lifting cylinder rod when working beneath the boom.
- Boom retracted without forks or attachments.

ACCORDING TO INSTALLATION

FITTING THE WEDGE


- Fully raise the jib.
- Place the safety wedge 1 on the rod of the lifting cylinder and secure with the rod 2 and the pin 3.
- Slowly lower the jib then stop the hydraulic movements before it comes into contact with the wedge.

REMOVING THE WEDGE

- Fully raise the jib.
- Remove the pin and the rod.
- Return the safety wedge to the storage location provided on the machine.

⚠ IMPORTANT ⚠

Only use the wedge supplied with the machine.



ACCORDING TO INSTALLATION

FITTING THE WEDGE

- Fully raise the jib.
- Loosen the thumbwheels 1.
- Assemble the parts of the safety wedge 2 around the cylinder rod and lock with the pins 3.

NOTE: the stop flats 4 of the safety wedge must be located towards the bottom of the lifting cylinder 5.



- Slowly lower the jib then stop the hydraulic movements before it comes into contact with the wedge.

REMOVING THE WEDGE

- Fully raise the jib.
- Remove the pins 3.
- Put the parts of the safety wedge 2 back on the machine and lock them with the thumbwheels 1.
- Replace the pins 3 on the parts of the safety wedge.

⚠ IMPORTANT ⚠

Only use the wedge supplied with the machine.



MAINTENANCE

- Perform the periodic service (↩ 3 - MAINTENANCE) to keep your machine in good working order. Failure to perform periodic maintenance may invalidate the contractual warranty.

MAINTENANCE LOGBOOK

- The maintenance operations carried out in accordance with the recommendations given in section 3 - MAINTENANCE and the other inspection, servicing or repair operations or modifications performed on the machine shall be recorded in a maintenance logbook.
- The entry for each operation should include the date of the work, the names of the individuals or companies having performed them, the type of operation and its frequency, if applicable.
- If machine elements are replaced, the part numbers of these elements shall be indicated.

LUBRICANT AND FUEL LEVELS

- Use the recommended lubricants (never use contaminated lubricants).
- Do not fill the fuel tank when the engine is running.
- Only fill up the fuel tank in areas specified for this purpose.
- Do not fill the fuel tank to the maximum level.
- Do not smoke or approach the machine with a flame when the fuel tank is open or is being filled.

HYDRAULICS

- Any work on the load handling hydraulic circuit is forbidden except for the operations described in chapter: 3 - MAINTENANCE.
- Do not attempt to loosen unions, hoses or any hydraulic component with the circuit under pressure.



COUNTERBALANCE VALVE: *it is dangerous to change the setting or remove the counterbalance valves or safety valves which may be fitted to the cylinders of your machine.*

HYDRAULIC ACCUMULATOR: *dismantling hydraulic accumulators and their pipes which may be fitted on your machine is dangerous. Such operations must only be performed by approved personnel (consult your dealer).*

ELECTRICITY

- Do not short-circuit the starter relay to start the engine. If the forward/reverse selector is not in neutral and the parking brake is not on, the machine may suddenly start to move.
- Do not place metal items on the battery.
- Disconnect the battery before working on the electrical circuit.

WELDING ON THE MACHINE



Welding operations on the machine for the purposes of maintenance or repairs must only be carried out by people authorized by MANITOU.

- Disconnect the battery before any welding operations on the machine.
- When carrying out electric welding work on the machine, connect the negative cable from the equipment directly to the part being welded so as to avoid very high current passing through the alternator.
- Never carry out welding or work which gives off heat on an assembled tire. The heat would increase the pressure which could cause the tire to explode.
- If the machine is equipped with an electronic control unit, disconnect it before starting to weld so as to avoid the risk of causing irreparable damage to electronic components.

WASHING THE MACHINE

⚠ IMPORTANT ⚠

When washing with a high pressure cleaner, avoid the engine air intakes, the cylinder rod wiper seals, the hinges, the structural components and the electrical connections, etc.

- Clean the machine or at least the area concerned before any intervention.
- Remember to close and lock all openings on the machine (doors, windows, cowls, etc.).
- If necessary, protect against penetration of water, steam or cleaning agents, components susceptible of being damaged, particularly electrical components and connections and the injection pump.
- Clean the machine of any traces of fuel, oil or grease.

TRANSPORTING THE MACHINE

⚠ IMPORTANT ⚠

Transporting the machine involves real risks for the operator and others involved.

- Towing, winching, slinging or transporting the machine (⚠ 3 - MAINTENANCE).

PROLONGED MACHINE SHUTDOWN

INTRODUCTION

⚠ IMPORTANT ⚠

Procedures to follow for long duration standstill and for bringing back the machine into service must be performed by your dealership.

This period of long duration standstill must not exceed 12 months.

After 12 months, repeat the procedures for putting the machine back into service and long-term shutdown.

The recommendations below are intended to prevent the machine from being damaged when it is not used for a period of more than 3 months.

PREPARATION OF THE MACHINE

- Clean the machine thoroughly.
- Check and repair any fuel, oil, water or air leaks.
- Replace or repair any worn or damaged parts.
- Wash the painted surfaces of the machine in clear and cold water and wipe them.
- Touch up the paintwork if necessary.
- Lower the lifting structure fully.
- Retract the telescopic arms.
- Release the pressure in the hydraulic circuits.
- Shut down the machine.

DEF (Diesel Exhaust Fluid) TANK

Depending on machine model

- Drain down and rinse the DEF (Diesel Exhaust Fluid) tank.
- Replace the "DEF" (Diesel Exhaust Fluid) feed pump filter (⚠ 3 - MAINTENANCE).
- Slowly fill the tank with new DEF up to the bottom of the filler neck.
- Start up the machine to pressurize the circuit and bring it up to working temperature, then shut down the engine.
- If necessary, top up the tank.

PROTECTING THE ENGINE

- Contact your dealer to obtain the procedure for protecting the inside of the engine (use of protection product).
- Fill the tank with fuel (3 - MAINTENANCE).
- Replace the engine oil and oil filter (3 - MAINTENANCE).
- Replace the coolant (3 - MAINTENANCE).
- Leave the engine running at idling speed for a few minutes, then switch off.
- Run the engine for a short time so that the oil and cooling liquid circulate inside.
- Disconnect the battery and store it in a safe place away from the cold, after charging it to maximum capacity.
- Block the outlet with waterproof adhesive tape.
- Remove the drive belts and store them in a safe place.
- Disconnect the engine cut-off solenoid on the injection pump and carefully insulate the connection.

MACHINE PROTECTION

Place the machine on level ground.

- Set the machine on axle stands so that the tires are off the ground.
- Deactivate the parking brake (*depending on machine model*).
- Protect cylinder rods which will not be retracted from corrosion.
- Wrap the wheels.

N.B.: If the machine is to be stored outdoors, cover it with a waterproof tarpaulin.

RETURNING THE MACHINE TO SERVICE

IMPORTANT

Make sure the area is adequately ventilated before starting up the machine.

- Remove the waterproof adhesive tape from all the orifices.
- Remove the protection from the cylinder rods and wheels.
- Refit and reconnect the battery.
- Activate the parking brake and remove the axle stands.
- Perform the daily maintenance operations (3 - MAINTENANCE).
- Perform the weekly maintenance operations (3 - MAINTENANCE).
- Drain and clean the fuel tank (3 - MAINTENANCE).
- Fill the fuel tank with clean diesel filtered through the filler port.
- Replace the fuel filter (3 - MAINTENANCE).
- Replace the fuel pre-filter (3 - MAINTENANCE) (*depending on the model of machine*).
- Drain and rinse the DEF tank (*depending on the machine model*).
- Top up, slowly fill the tank with new "DEF" (Diesel Exhaust Fluid) up to the bottom of the filler neck (*depending on the machine model*).
- Refit and set the tension in the belts. (3 - MAINTENANCE).
- Turn the engine over with the starter, to allow the oil pressure to rise.
- Reconnect the engine cut-off solenoid.
- Lubricate the machine completely (3 - MAINTENANCE).
- Start up the machine, following the operating and safety instructions (OPERATING INSTRUCTIONS UNLADEN AND LADEN).
- Perform all the lifting structure's hydraulic movements up to the end position for each cylinder.

DISPOSING OF THE MACHINE



Consult your dealer before disposing of the machine.

RECYCLING OF MATERIALS

METALS

- Metals are 100% recoverable and recyclable.

PLASTICS

- Plastic parts are identified with a marking in accordance with current regulations.
- A limited range of materials is used to simplify the recycling process.
- The majority of the plastic components are made of "thermoplastic" plastics, which are easily recycled by melting, granulating or grinding.

RUBBER

- Tires and seals can be ground for use in cement manufacture or to obtain reusable granules.

GLASS

- Glass items can be removed and collected for processing by glaziers.

ENVIRONMENTAL PROTECTION

By entrusting the maintenance of your machine to the MANITOU network, the risk of pollution is limited and the contribution to environmental protection is made.

WORN OR DAMAGED PARTS

- Do not dump them in the countryside.
- MANITOU and its network have signed-up to a scheme of environmental protection through recycling.

USED OIL

- The MANITOU network organizes the collection and processing of used oil.
- By handing over your waste oil to MANITOU, the risk of pollution is limited.

USED BATTERIES

- Do not throw away batteries, as they contain metals that are harmful for the environment.
- Return them to the MANITOU network or any other approved collection point.

N.B.: MANITOU aims to manufacture machines that provide the best performance and limit polluting emissions.

2 - DESCRIPTION

2 - DESCRIPTION

<u>SAFETY PLATES AND STICKERS</u>	2-4
<u>IDENTIFICATION OF THE LIFT TRUCK</u>	2-8
<u>CHARACTERISTICS</u>	2-10
<u>TYRES</u>	2-12
<u>DIMENSIONS AND LOAD CHARTS</u>	2-14
<u>VISIBILITY</u>	2-16
<u>INSTRUMENTS AND CONTROLS</u>	2-18
<u>TOWING DEVICE</u>	2-44
<u>DESCRIPTION AND USE OF THE OPTIONS</u>	2-46


SAFETY PLATES AND STICKERS

⚠ IMPORTANT ⚠

Clean all stickers and safety plates so that they are legible.
Any safety plates and stickers which are illegible or damaged must be replaced.
Check that stickers and safety plates are present after replacing any spare parts.


EXTERNAL PLATES AND STICKERS

REF.	PART NO.	DESCRIPTION
1	234805	- Hydraulic coupling instruction MT 625 H COMFORT 75K ST5
2	296998	- Maniscopic safety instruction
3	24653	- Slings point
4	52563320	- Tie-down point
5	234798	- Hydraulic oil
6	288430	- Repairing instructions (on lift cylinder)
7	268491	- Brake fluid instruction
8	305405	- Diesel fuel
9	289013	- Towing instruction (OPTION)
10	307508	- Battery cut-off instruction
11	52631112	- Overall height (OPTION)
12	52588611	- Attachment and boom safety
13	52590031	- Attachment retaining shaft





STICKERS AND PLATES UNDER THE ENGINE HOOD



REF.	PART NO.	DESCRIPTION
1	244130	- Preheat rod (OPTION)
2	52506370	- Fuses
3	259398	- Water/diesel separator
4	52515083	- Anti-freeze
5	234797	- Air conditioning (OPTION) MT 625 H COMFORT 75K ST5
6	52589959	- Rotating fan safety



PLATES AND STICKERS IN THE CAB

REF.	PART NO.	DESCRIPTION
1	52611811	- Lubrication sheet
2	52509004	- Manipulator function sheet
3	241621	- Safety instruction sheet
5	52504055	- Fuse sheet MT 625 H COMFORT 75K ST5
	52515060	- Fuse sheet MT 625 H 75K ST5
6	52533603	- Relay sheet MT 625 H COMFORT 75K ST5
	52509862	- Relay sheet MT 625 H 75K ST5
7	294831	- Reset procedure sheet (For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")
8	319018	- Carriage lifting ring sheet (OPTION)
9	290439	- Boom head electrovalve function sheet (OPTION) MT 625 H COMFORT 75K ST5
10	290183	- Bucket instruction on telescope
11	297733	- Operating mode management instruction (For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")
12	52515381	- Main functions
13	265284	- Lifting ring on carriage (OPTION)
14	184276	- Steering selection
15	52580160	- Towing forbidden
16	239594	- Sound power level
17	52580168	- Cab compliance
19	52521685	- Diesel exhaust particle filter regeneration function sheet
20	52504251	- Consumption sheet
21	240805	- Reach chart sheet
24	52588617	- Seat belt
25	52588615	- Power line
26	52618158	- PROP 65 warning plomb
27	52618159	- PROP 65 Warning diesel engine exhaust
28	52628703	- CAN ICES-2 NMB-2
29	52588612	- Before starting or operating
30	52588614	- No riders
31	52588616	- Frame leveling warning
32	52651762	- Hydraulic controls activation (DEPENDING ON ASSEMBLY)





IDENTIFICATION OF THE LIFT TRUCK

As our policy is to promote a constant improvement in our products, our range of lift trucks may undergo certain modifications, without any obligation for us to advise our customers.

When you order parts, or when you require any technical information, always specify:

NOTE: For the owner's convenience, it is recommended that a note of these numbers is made in the spaces provided, at the time of the delivery of the lift truck.

For any further technical information regarding your lift truck refer to the chapter: CHARACTERISTICS.

LIFT TRUCK MANUFACTURER'S PLATE

"Designation" Désignation	
"Series" Série	
"Year of manufacture" Année de fabrication	
"Model year" Année modèle	
"Serial Number / Product Identification Number" Numéro de série / Numéro d'identification produit	
"Unladen mass" Masse à vide	
"Rated capacity" Capacité nominale	



ENGINE

"MODEL" Model	
"FAMILY" Family	
"POWER" Power	



HYDROSTATIC PUMP

"MODEL" Model	
"CODE" Code	
"E1" Identification	
"SERNO" Serial number	
"SPEC" Specification	



HYDROSTATIC MOTOR

"MODEL" Model	
"CODE" Code	
"E1" Identification	
"SERNO" Serial number	
"SPEC" Specification	




FRONT AXLE

Type	
Serial number	
MANITOU part No.	



REAR AXLE

Type	
Serial number	
MANITOU part No.	



CAB

"Constructeur" Manufacturer	
"Type Cabine" Cabin type	
"Numéro de série" Serial number	



BOOM

MANITOU Part No.	
Date of manufacture and manufacturer	



FRAME

Serial number/Product identification number	
---	--



ATTACHMENT MANUFACTURER'S PLATE

"MODELE" Model	
"N° série" Serial number	
"Année Fabrication" Year of manufacture	
"Masse à vide" Unladen weight	
"Centre de gravité" Centre of gravity	
"Capacité Nominale" Rated capacity	
"Pression service" Working pressure	



CHARACTERISTICS

ENGINE		
Type		KUBOTA V3307
Fuel		Diesel
Number of cylinders		4 in line
Suction		Supercharged
Injection system		Direct
Ignition sequence		1.3.4.2
Capacity	cu.in (cm ³)	203.27 (3331)
Bore and stroke	in (mm)	3.7 x 4.72 (94 x 120)
Compression ratio		17,5
Nominal speed laden	rpm	2600
Min. rpm unladen	rpm	895
Max. rpm unladen	rpm	2800
Power ISO 3046-1	hp - kW	75 - 55,4
Power SAE J 1995	hp - kW	75 - 55,4
Max. torque ISO 3046-1	ft-lbf (Nm)	195.45 (265) to 1400 rpm
Air filtration efficiency	mil (µm)	0.12 (3)
Type of cooling		By water
Fan		Puller

TRANSMISSION		
Hydrostatic pump		DANFOSS
- Type		Variable displacement piston motor
- Forward/reverse selector		Electro-hydraulic
- Number of forward speeds		2 (1 slow and 1 fast)
- Number of reverse speeds		2 (1 slow and 1 fast)
Main pump		
- MAX - MIN. displacement	cu.in/r (cm ³ /tr)	0 - 3.23 (0 - 53)
- MAX. flow rate	gpm (ℓ/min)	36.5 (138)
- Working pressure	psi (bar)	5076 (350)
Booster pump		
- Capacity	cu.in/r (cm ³ /tr)	0.73 (12)
- MAX. flow rate	gpm (ℓ/min)	8.2 (31)
- Boost pressure MAX. speed	psi (bar)	348 (24) (transmission in neutral)
Hydrostatic motor		DANFOSS
- Type		variable bi-directional
- MAX - MIN. displacement	cu.in/r (cm ³ /tr)	1.77 - 6.71 (29 - 110)
Transfer gear box		DANA
Front axle		DANA
- Differential		45% limited slip differential
Rear axle		DANA
- Differential		Without locking
Drive wheels		Permanent 4 WD
- 2/4 wheel drive control		No
Front tyres		SOLIDEAL/CAMSO
- Size		12-16,5 12PR SKS 532
- Pressure	psi (bar)	81.2 (5,6)
Rear tyres		SOLIDEAL/CAMSO
- Size		12-16,5 12PR SKS 532
- Pressure	psi (bar)	81.2 (5,6)

ELECTRIC CIRCUIT		
Battery		12 V - 110 Ah - 750 A EN
Alternator		12 V - 80 A
- Type		A5TA59 77C
Starter		12 V - 3 kW
- Type		M008T50672

SOUND AND VIBRATION		
Sound pressure level in the driver's cab LpA (as per standard EN 12053)	dB	76 (cab closed); xx (cab open)
Sound pressure (according to directive 2009/76)	dB	xx (cab closed); xx (cab open)
Sound pressure level ensured in the LwA environment (according to directive 2000/14/EC modified by directive 2005/88/EC)	dB	104 (measured); 104 (guaranteed)
Sound level in motion (according to directive 2009/63)	dB	xx
Average weighted acceleration on driver's body (as per standard EN 13059)	ft/s ² (m/s ²)	3.61 (1,1)
The average weighted acceleration transmitted to the driver's hand/ arm system (according to ISO 5349-2)	ft/s ² (m/s ²)	< 8.2 (2,5)
Standard seat vibration	ft/s ² (m/s ²)	xx (lightweight operator); xx (heavyweight operator)

BRAKE SYSTEM	
Service brake	Non-servo hydraulic brake
- Type of brake	Oil-immersed multi-disc brake
- Type of control	By foot on front axle
Parking brake	Low pressure hydraulic brake
- Type of brake	Oil-immersed multi-disc brake
- Type of control	Switch-operated electro-hydraulic

HYDRAULIC CIRCUIT		
Hydraulic pump		
- Type	with gears	
- Capacity	cu.in (cm ³)	1.92 (31,4)
- Max. rating capacity unladen	gpm (ℓ/min)	23.2 (87,9)
- Flow rate at 1600 rpm	gpm (ℓ/min)	13.3 (50,2)
Filtration		
- Return	mil (μm)	0.39 (10)
- Suction	mil (μm)	4.92 (125)
Maximum service pressure	psi (bar)	3408.4 (235)
- Telescoping circuit	psi (bar)	3408.4 (235) / 3408.4 (235)
- Lifting circuit	psi (bar)	3408.4 (235) / 3408.4 (235)
- Tilting circuit	psi (bar)	3553.4 (245) / 3553.4 (245)
- Attachment circuit	psi (bar)	3408.4 (235)
- Steering circuit	psi (bar)	2030.5 (140)

HYDRAULIC MOVEMENTS		
Longitudinal stability limiter and warning device (For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")	Electronic	
Lifting motions (boom retracted)		
- Unladen lifting	s - ft/min (m/min)	8 - 92.85 (28,3)
- Laden lifting	s - ft/min (m/min)	8 - 92.85 (28,3)
- Unladen lowering	s - ft/min (m/min)	5,4 - 137.47 (41,9)
- Laden lowering	s - ft/min (m/min)	5,3 - 140.09 (42,7)
Telescoping motions (boom raised)		
- Unladen extending	s - ft/min (m/min)	5,6 - 73.16 (22,3)
- Laden extending	s - ft/min (m/min)	5,9 - 77.1 (23,5)
- Unladen retracting	s - ft/min (m/min)	4,3 - 100.39 (30,6)
- Laden retracting	s - ft/min (m/min)	4 - 107.94 (32,9)
Tilting movements		
- Unladen digging	s - °/s	3,5 - 36,7
- Unladen discharging	s - °/s	3,6 - 35,6

SPECIFICATIONS AND WEIGHTS			
Speed of movement for lift truck in standard configuration on flat ground			
• Front unladen	• 1 Slow	mph (km/h)	4.35 (7)
	• 1 fast	mph (km/h)	15.53 (25)
• Rear unladen	• 1 Slow	mph (km/h)	4.35 (7)
	• 1 fast	mph (km/h)	15.53 (25)
Standard attachment			PFB 25N 1020 MT
- Weight of attachment (without forks)		lbs (kg)	176.4 (80)
- Weight of forks (each)		lbs (kg)	159.8 (72,5)
Rated capacity with standard attachment		lbs (kg)	5512 (2500)
Tipping load at maximum reach on tires		lbs (kg)	-
Distance from the centre of gravity of the load to the base of the forks		in (mm)	24.5 (600)
Standard lifting height		in (mm)	229.1 (5820)
Lift truck weight without attachment		lbs (kg)	10086 (4575)
Weight of lift truck with standard attachment			
- Unladen		lbs (kg)	10582 (4800)
- At rated load		lbs (kg)	16094 (7300)
Weight per axle with standard attachment (transport position)			
- Front unladen		lbs (kg)	5093 (2310)
- Rear unladen		lbs (kg)	5490 (2490)
- Front rated load		lbs (kg)	14661 (6650)
- Rear rated load		lbs (kg)	1433 (650)
Weight per axle with standard attachment (boom extended)			
- Front rated load		lbs (kg)	11552 (5240)
- Rear rated load		lbs (kg)	794 (360)
Drag strain on the coupling hook			
- Unladen (sliding)		lbf (daN)	7261 (3230)
- At rated load (transmission setting)		lbf (daN)	7981 (3550)
Breakout force with bucket (according to ISO 8313)		lbf (daN)	7704 (3427)



TYRES

		LOAD PER TYRE									
		PRESSURE		FRONT UNLADEN		FRONT LADEN		REAR UNLADEN		REAR LADEN	
		bar	psi	kg	lbs	kg	lbs	kg	lbs	kg	lbs
ALLIANCE	12-16,5 12PR SKS 532	5,6	81,2	1100	2425	3250	7165	1250	2756	350	772
	12-16,5 12PR HAULER SKS	5,6	81,2								
MICHELIN	305/70 R16,5 137A8 BIBSTEEL ALL TERRAIN	4,8	69,6								

		GROUND CONTACT PRESSURE										GROUND CONTACT AREA			
		PRESSURE		LOAD		HARD GROUND		SOFT GROUND		HARD GROUND		SOFT GROUND			
		bar	psi	kg	lbs	kg / cm ²	lbs / in ²	kg / cm ²	lbs / in ²	cm ²	in ²	cm ²	in ²		
SOLIDEAL/ CAMSO	12-16,5 12PR SKS 532	5,6	81,2	350	772	6,48	92,17	3,50	49,78	54	8,37	100	15,50		
				1100	2425	7,97	113,36	4,00	56,89	138	21,39	275	42,63		
				1250	2756	8,01	113,93	4,01	57,04	156	24,18	312	48,36		
				3250	7165	10,00	142,24	5,00	71,12	325	50,38	650	100,75		
SOLIDEAL/ CAMSO	12-16,5 12PR HAULER SKS	5,6	81,2	350	772	5,00	71,12	2,50	35,56	70	10,85	140	21,70		
				1100	2425	7,01	99,71	3,50	49,78	157	24,34	314	48,67		
				1250	2756	7,02	99,85	3,50	49,78	178	27,59	357	55,34		
				3250	7165	11,02	156,74	5,51	78,37	295	45,73	590	91,45		
MICHELIN	305/70 R16,5 137A8 BIBSTEEL ALL TERRAIN	4,8	69,6	350	772										
				1100	2425										
				1250	2756										
				3250	7165										

DIMENSIONS AND LOAD CHARTS

A	ft-in (mm)	3-11,2	(1200)
B	ft-in (mm)	7-6,6	(2300)
C	ft-in (mm)	3-3	(991)
C1	ft-in (mm)	3-0,5	(928)
D	ft-in (mm)	12-9,3	(3894)
D1	ft-in (mm)	12-6,8	(3831)
D2	ft-in (mm)	10-8,9	(3275)
E	ft-in (mm)	16-8,6	(5094)
F	ft-in (mm)	4-10,7	(1492)
F1	ft-in (mm)	4-10,7	(1492)
G	in (mm)	9,45	(240)
G1	in (mm)	13	(330)
G2	in (mm)	9,96	(253)
G3	in (mm)	-	-
H	° °	-	-
H1	° °	-	-
I	in (mm)	23,74	(603)
J	in (mm)	31,38	(797)
K	ft-in (mm)	3-4	(1015)
L	in (mm)	1,77	(45)
N	ft-in (mm)	4-3,7	(1314)
O	in (mm)	4,92	(125)
P2	° °	37	(37)
P3	° °	52	(52)
R	ft-in (mm)	10-4	(3150)
S	ft-in (mm)	21-9,9	(6651,5)
T	ft-in (mm)	12-10,9	(3935)
U1	ft-in (mm)	6-3,6	(1920)
U2	ft-in (mm)	6-8,9	(2054)
V	ft-in (mm)	15-5	(4700)
V1	ft-in (mm)	2-6,1	(765)
V2	ft-in (mm)	10-10,3	(3310,5)
W	ft-in (mm)	5-11,4	(1813)
W1	ft-in (mm)	-	-
W2	ft-in (mm)	-	-
W3	ft-in (mm)	-	-
Y	° °	12	(12)
Z	° °	117	(117)



VISIBILITY









We use European standard EN15830 relating to operator visibility.

- Adhere to the instructions for optimising operator visibility in the immediate vicinity (1 - OPERATING AND SAFETY INSTRUCTIONS: INSTRUCTIONS TO THE OPERATOR: DRIVING INSTRUCTIONS UNLADEN AND LADEN: D - VISIBILITY).

DESCRIPTION AND ADJUSTMENT OF REAR-VIEW MIRRORS

- 1 - LEFT REAR-VIEW MIRROR
- 2 - MAIN RIGHT REAR-VIEW MIRROR
- 3 - CENTRAL RIGHT REAR-VIEW MIRROR
- 4 - UPPER RIGHT REAR-VIEW MIRROR
- 5 - INSIDE REAR-VIEW MIRROR (OPTION)
- 6 - REAR-VIEW MIRROR (OPTION)

- Place the lift truck on level ground with the engine stopped, and the boom retracted and lowered as far as possible.
- Note the position of the reference points ●...○ in the illustrations, to see and correctly adjust the rear-view mirrors.



INSTRUMENTS AND CONTROLS

DESCRIPTION

NOTE: All the terms such as: RIGHT, LEFT, FRONT, REAR are as seen by an observer occupying the driver's seat and looking straight ahead.

1 - DRIVER'S CAB ACCESS	2-20
2 - SEAT BELT	2-20
3 - DRIVER'S SEAT	2-21
4 - IGNITION SWITCH	2-22
5 - EMERGENCY STOP	2-22
6 - BATTERY CUT-OFF	2-22
7 - BATTERY	2-22
8 - MAN-MACHINE INTERFACE (MMI)	2-23
9 - LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE	2-28
10 - SWITCHES	2-30
11 - ARMREST AND STORAGE	2-31
12 - DIAGNOSTIC PLUG	2-31
13 - FUSES AND RELAYS	2-32
14 - CIGARETTE LIGHTER	2-34
15 - LIGHTING, HORN AND INDICATOR SWITCH	2-34
16 - FRONT AND REAR WINDSCREEN WIPER SWITCH	2-34
17 - FUNCTION FILES	2-34
18 - HYDRAULIC CONTROLS	2-35
19 - ACCELERATOR PEDAL	2-37
20 - SERVICE BRAKE PEDAL AND TRANSMISSION CUT-OFF	2-37
21 - FORWARD/NEUTRAL/REVERSE GEAR SELECTION	2-37
22 - STEERING SELECTION	2-38
23 - HEATER CONTROL	2-39
24 - AIR CONDITIONING CONTROLS (AIR CONDITIONING OPTION)	2-39
25 - HEATING VENTS	2-40
26 - DEMIST VENTS	2-40
27 - LEVEL INDICATOR	2-40
28 - DOOR LOCK	2-40
29 - DOOR WINDOW OPENING HANDLE	2-40
30 - DOOR WINDOW RELEASE BUTTON	2-40
31 - HANDLE FOR REAR WINDOW OPENING	2-40
32 - REAR STORAGE SPACE	2-40
33 - DOCUMENT STORAGE NET	2-40
34 - STEERING WHEEL ADJUSTMENT LEVER (OPTION)	2-40
35 - FRONT HEADLIGHTS	2-41
36 - REAR LIGHTS	2-41
37 - ROTATING BEACON LIGHT (DEPENDING ON ASSEMBLY)	2-41
38 - ROOF LIGHT (DEPENDING ON ASSEMBLY)	2-41
39 - ROOF-SIDE WINDSCREEN WIPER SWITCH (DEPENDING ON ASSEMBLY)	2-41
40 - SUN VISOR	2-41
41 - BOOM SAFETY WEDGE	2-42
42 - FUEL TANK	2-42
43 - "A-B-C-D-E" MARKING ON BOOM	2-42
44 - ANGULAR SECTOR ON BOOM	2-42



1 - DRIVER'S CAB ACCESS

Use the contact points 1 to get into or out of the driver's cab.

- Mounting at the front.
- Descending at the rear.



2 - SEAT BELT

⚠ IMPORTANT ⚠

*Under no circumstances must the lift truck be used if the seat belt is defective (fixing, locking, cuts, tears, etc.).
Immediately repair or replace the safety belt.*

- Sit correctly on the seat.
- Check that seat belt is not twisted.
- Place the seat belt at hip level.
- Attach the seat belt and check that it locks.
- Adjust the seat belt to your body shape without compressing your pelvis and without excessive slack.



3 - DRIVER'S SEAT



DESIGNED FOR MAXIMUM COMFORT, THIS SEAT CAN BE ADJUSTED AS FOLLOWS.

WEIGHT ADJUSTMENT

Adjust the weight when the driver is sitting on the seat.

- Pull the weight adjustment lever 1 fully out.
- Move the weight adjustment lever 1 upwards to increase the weight or downwards to reduce it.
- There are ten possible positions between the min and max weights. Before each run, return the lever to the central position. The max. or min. position is indicated by a freely travelling lever.
- The driver's weight is correctly adjusted when the arrow is in the centre of indicator lamp 2.
- After completing the weight adjustment, fully lower the lever 1.

NOTE: To avoid any health problems, it is recommended that the weight setting is checked and adjusted before starting the lift truck.



LONGITUDINAL ADJUSTMENT

- Adjust the locking lever until you reach the position required. This then locks and the seat will not shift into another position.

⚠ IMPORTANT ⚠

Only operate the lever by its recessed section and do not grasp from below, at the risk of crushing the hand.

LUMBAR ADJUSTMENT

This increases the comfort of the seat and the driver's freedom of movement.

- Turn the handle to 1 to adjust the height and depth of the lumbar support of the upper part of the back-rest.
- Turn the handle to 2 to adjust the height and depth of the lumbar support of the lower part of the back-rest.

BACK-REST ANGLE ADJUSTMENT

- Support the back-rest, pull the lever and position the back-rest to find the desired position.

⚠ IMPORTANT ⚠

If you do not support the back rest when making adjustments, it will tilt forwards.

MAINTENANCE



Dirt may adversely affect the correct functioning of the seat. For this reason, make sure your seat is always clean.

- The cushions do not require to be removed from the seat frame for cleaning.

⚠ IMPORTANT ⚠

Accident risks are increased when the back-rest tilts.

First check the resistance of the fabric on a small concealed area before using any fabric and plastic cleaner.



4 - IGNITION SWITCH

This switch has 5 positions:

- P - Not used.
- O - Ignition cut-off and engine stopped.
- I - Ignition + preheat.
- II - Not used.
- III - Starting and return to position I as soon as the key is released.

5 - EMERGENCY STOP

In the event of danger, it enables the engine to be shut down, thereby cutting-off all hydraulic movements.

⚠ IMPORTANT ⚠

Be ready for hydraulic movements suddenly stopping when you press this button.

If possible stop the lift truck before using the emergency stop button.

- Turn the knob to deactivate it before restarting the lift truck.



6 - BATTERY CUT-OFF

For quickly disconnecting the battery when working on the electric circuit or when soldering, for example.

⚠ IMPORTANT ⚠

Operate the battery cut-off for a minimum of 30 seconds after having switched off the ignition with the ignition key.



7 - BATTERY



8 - MAN-MACHINE INTERFACE (MMI)

- A - INSTRUMENT CONTROL PANEL
- B - SCREEN DISPLAYS

A - INSTRUMENT CONTROL PANEL

⚠ IMPORTANT ⚠

A permanently lit or flashing warning lamp, with the engine running, is the sign of an operating fault. The lighting of some lamps may be accompanied by an audible signal. Do not ignore this warning, consult your dealer without delay. If one of the warning lamps comes on while the lift truck is in motion, stop the lift truck under the safest possible conditions.



REV COUNTER

10-level LED display from 0 to 3000 rpm.



ENGINE WATER TEMPERATURE

Temperature zones:

- 1 LED - (< 104 °F) or (< 40 °C) zone. Use the lift truck with moderation, wait for temperature to increase before normal operation.
- 2 LEDs - (104 °F- 140 °F) or (40 °C - 60 °C) zone.
- 3 LEDs - (140 °F- 176 °F) or (60 °C - 80 °C) zone.
- 4 LEDs - (176 °F- 185 °F) or (80 °C - 85 °C) zone.
- 5 LEDs - (185 °F- 194 °F) or (85 °C - 90 °C) zone.
- 6 LEDs - (194 °F- 203 °F) or (90 °C - 95 °C) zone from (104 °F to 203 °F) or (40 °C to 95 °C) use the lift truck normally.
- 7 LEDs - (203 °F- 221 °F) or (95 °C - 105 °C) zone. Use the lift truck with moderation.
- 8 LEDs - (221 °F- 230 °F) or (105 °C - 110 °C) zone. Use the lift truck with moderation, ventilation control operating at full speed.
- 9 LEDs - Red zone (230 °F- 239 °F) or (110 °C - 115 °C).
- 10 LEDs - Red zone (> 239 °F) or (> 115 °C) Stop the lift truck, seek the cause of overheating.



NOTE: If the red indicator lamp and the buzzer come on (> 230 °F) or (> 110 °C) when the lift truck is running, stop the engine immediately and seek the cause of the failure in the cooling system.



FUEL LEVEL

When only one LED is still displayed, the indicator lamp  comes on, indicating that you are using the reserve fuel supply and that your operating time is limited.



FORWARD/NEUTRAL/REVERSE INDICATOR

◀ FORWARD/NEUTRAL/REVERSE GEAR SELECTION



AIR FILTER CLOGGING WARNING INDICATOR LAMP

The indicator lamp and buzzer come on when the air filter cartridge is clogged. When this indicator lamp remains on continuously the cartridge needs changing. Stop the engine and carry out the necessary repairs (◀ 3 - MAINTENANCE: FILTER ELEMENTS AND BELTS).




HYDRAULIC OIL FILTER CLOGGING WARNING INDICATOR LAMP

The indicator lamp and the buzzer come on when the hydraulic oil filter cartridge is clogged. Stop the engine and carry out the necessary repairs (◀ 3 - MAINTENANCE: FILTER ELEMENTS AND BELTS).



GENERAL FAULT WARNING INDICATOR LAMP

If the lamp and the buzzer come on when the lift truck is running, stop the engine immediately and consult your dealer.





TRANSMISSION OIL TEMPERATURE WARNING INDICATOR LAMP

The lamp and the buzzer come on when the transmission oil temperature is abnormally high. Stop the lift truck and seek the cause of this overheating.



ENGINE FAULT INDICATOR LAMP

If the indicator lamp comes on or flashes while the lift truck is in operation, a diagnostic fault has been detected. The lift truck will operate in reduced mode. Consult your dealer without delay.



FUEL LEVEL LAMP WARNING INDICATOR LAMP



FUEL LEVEL



BATTERY CHARGE WARNING INDICATOR LAMP

If the lamp and the buzzer come on when the lift truck is running, stop the engine immediately and seek the cause (electric circuit, alternator belt, alternator, etc.).



AUTOMATIC EXHAUST PURIFICATION DEACTIVATED INDICATOR LAMP

The indicator lamp comes on when the lift truck is running to indicate that the automatic exhaust purification is disabled (SWITCHES).



HIGH EXHAUST GAS TEMPERATURE INDICATOR LAMP

The indicator lamp comes on while the lift truck is operating to indicate a high exhaust gas temperature. You can continue to use the lift truck (SWITCHES).



SOOT LEVEL INDICATOR LAMP

The indicator lamp comes on while the lift truck is operating to indicate the soot level (SWITCHES).



"STATIONARY LIFT TRUCK" EXHAUST PURIFICATION INDICATOR LAMP

The indicator lamp comes on while the lift truck is operating, indicating a "stationary lift truck" exhaust purification is in progress (3 - MAINTENANCE; OCCASIONAL MAINTENANCE).



ENGINE OIL PRESSURE WARNING INDICATOR LAMP


If the indicator lamp and the buzzer come on when the lift truck is operating, stop the engine immediately and look for the cause (engine oil level, etc.).



ENGINE WATER TEMPERATURE WARNING INDICATOR LAMP



ENGINE WATER TEMPERATURE



(P) PARKING BRAKE FAULT INDICATOR LAMP

The indicator lamp comes on when the parking brake is applied (↔ SWITCHES).

(🔴) BRAKING OIL LEVEL WARNING INDICATOR LAMP

If the lamp comes on when the lift truck is running, stop the engine immediately and check the brake fluid level. In the event of an abnormal drop in the level, consult your dealer.

(🔴) ENGINE PREHEAT FAULT INDICATOR LAMP

If preheating is required, the lamp comes on when the lift truck's ignition is switched on and should go out as soon as preheating is ended. If this lamp comes on while the lift truck is in operation, immediately stop the engine and seek the cause.

(🔴) WATER IN FUEL PRE-FILTER WARNING INDICATOR LAMP

This light will come on when there is water in the fuel pre-filter. Stop the lift truck and carry out the necessary repairs.

(🟢) NOT USED

(↔) INDICATOR LIGHTS INDICATOR LAMP

(🔴) FRONT WHEEL ALIGNMENT INDICATOR LAMP

(🔴) REAR WHEEL ALIGNMENT INDICATOR LAMP

(🔴) FAST GEAR INDICATOR LAMP


(🔴) SLOW GEAR INDICATOR LAMP

(🔴) BLUE MAIN BEAM HEADLIGHTS INDICATOR LAMP

B - SCREEN DISPLAYS



UPPER SCREEN DISPLAY




LOWER SCREEN DISPLAY



SCROLL BUTTON




VALIDATION, RESET AND ERROR CODE BUTTON




UPPER SCREEN DISPLAY



Switch on the lift truck ignition, by default, the screen will show the time. Press the scroll button to switch from one screen to the other in turn.




RESETTING THE PARTIAL HOUR METER



- Display the partial hour meter screen.
- Press the button  for 2 seconds, resetting is confirmed by an audible signal.





LOWER SCREEN DISPLAY

Switch on the lift truck ignition, by default, the screen will show the hour meter , i.e. the total number of hours the lift truck has been used. As soon as the engine is running, the flashing  pictogram is displayed and the hour meter records the hours of operation.

MAINTENANCE INTERVAL



NOTE: When the new lift truck is started, the maintenance key  will logically be displayed to provide a reminder to replace the engine oil and the oil filter after the first 50 hours of use of the new lift truck (<3 - MAINTENANCE: DAILY AND WEEKLY SERVICING).







The maintenance key  appears on the hour meter screen  50 hours before the maintenance deadline and generates an audible signal.

- Press the  button to display the time remaining before maintenance . In the event that the deadline is exceeded, the hours are shown with a plus sign.
- Press once more on the  button to return to the hour meter screen. The maintenance key  will be displayed for information.
- Contact your dealer to carry out the necessary maintenance operations and reset the maintenance interval.

NOTE: The maintenance frequency interval displayed by default is 500 hours; this interval can be modified. Please contract your dealer about this.

ERROR CODES

The appearance of the pictogram  on the hour meter screen  together with an audible signal, indicate that a fault has been detected by one of the lift truck's Electronic Control Units (ECU).

- Press the  button to display the information  on the upper screen, as well as the error code .
- If there are several error codes, press the button  to scroll through all the error codes.
- Press the button  again to return to the hour meter screen; the pictogram  will remain displayed as long the as the required repairs have not been carried out.
- Contact your dealer, stating the error code or codes.

NOTE: A faulty fuse can generate several error codes. When "error codes" and "maintenance interval" are displayed together, the maintenance reminder time will appear at the end of the list.

9 - LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE

(For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")


⚠ IMPORTANT ⚠

The operator must respect the lift truck's load chart, and the operating mode according to the attachment.

This device warns the operator of the lift truck's longitudinal stability limits. However, lateral stability can reduce the load chart in the upper part, and this reduction is not detected by the device.

Depending on the type of work required, the longitudinal stability limiter and warning device allows the operator to operate the lift truck in complete safety.


UPDATE: To gain maximum advantage from the longitudinal stability limiter and warning device of your lift truck, contact your dealer to receive the latest version of the software available.




"HANDLING" MODE

USE ON FORKS


- By default, the device is in "HANDLING MODE" each time the lift truck is started.
- Protection against tilting forwards during aggravating movements is guaranteed, except when the telescope is retracted.


STATUS OF THE DEVICE			
HALTED	SLOW SPEED 1 to 5 km/h	SPEED > 5 km/h	BOOM RETRACTED
A4-A5: Very slow intermittent sound alarm. A6: Slow intermittent sound alarm. A7: Fast intermittent sound alarm. A8: Very fast intermittent sound alarm.	A7: Fast intermittent sound alarm. A8: Very fast intermittent sound alarm.	-No sound alarm.	-No sound alarm. -Indicator lamp A9  on.




"BUCKET" MODE

USE WITH BUCKET


- Place the lift truck in the transport position.
- Hold down the  button, "BUCKET" MODE is confirmed by a sound signal and the indicator lamp coming on.
- Press this button again or switch off the ignition with the ignition key to return to "HANDLING" MODE.
- Protection against tilting forwards during aggravating movements is guaranteed, except when the telescope is retracted.


STATUS OF THE DEVICE			
HALTED	SLOW SPEED 1 to 5 km/h	SPEED > 5 km/h	BOOM RETRACTED
-The "BUCKET" mode deactivates automatically if the lift truck remains stationary.	A6: An audible signal upon passing into the red zone. -The hydraulic movements are adapted.	-No sound alarm. -The hydraulic movements are adapted.	-No sound alarm. -Indicator lamp A9  on.



"SUSPENDED LOAD" MODE


USE WITH LIFTING DEVICE (offering a higher margin of safety)

- Place the lift truck in the transport position.
- Press the  button, the "SUSPENDED LOAD" MODE is confirmed by a sound signal and the indicator lamp coming on. Hydraulic tilting movements are neutralised, as well as the lifting movement when the longitudinal stability limit is reached (indicator lamp A8 lit).
- Press this button again or switch off the ignition with the ignition key to return to "HANDLING" MODE.
- Protection against tilting forwards during aggravating movements is guaranteed, except when the telescope is retracted.

STATUS OF THE DEVICE			
HALTED	SLOW SPEED 1 to 5 km/h	SPEED > 5 km/h	BOOM RETRACTED
	A4-A5: Very slow intermittent sound alarm. A6: Slow intermittent sound alarm. A7: Fast intermittent sound alarm. A8: Very fast intermittent sound alarm.		-No sound alarm. -Indicator light A9 on. 

A - VISUAL ALARMS

- A1 - A2 - A3: There is a significant reserve of longitudinal stability.
- A4 - A5: The lift truck is approaching the limit of longitudinal stability, move with care.
- A6: The lift truck is close to the longitudinal stability limit. Manoeuvre with care.
- A7: The lift truck is very close to the longitudinal stability limit. Manoeuvre with extreme caution.
- A8: The lift truck is at the authorised longitudinal stability limit.
- A9: The "AGGRAVATING" hydraulic movement cut-off is disabled.

- The warning indicator lamp  accompanied by a sound alarm indicates a fault. To view this error code (SCREEN DISPLAYS).

B - HYDRAULIC MOVEMENT CUT-OFF

"HANDLING" MODE

- A8: All "AGGRAVATING" hydraulic movements are cut off. Only perform de-aggravating hydraulic movements in the following order: retract and raise the boom.

"BUCKET" MODE

- A8: The boom lowering and extension movements are cut off, the other movements remain available.

"SUSPENDED LOAD" MODE

- A8: All "AGGRAVATING" and boom raising hydraulic movements are cut-off. Only the boom retraction hydraulic movement is available.


C - DISABLING "AGGRAVATING" HYDRAULIC MOVEMENT CUT-OFF

IMPORTANT


Remain very vigilant during this operation. The only information available to the operator is the lift truck's dynamic stability.

In certain cases, in order to get out of a difficult situation, the operator can bypass this safety device. Button C temporarily disables the cut-off of "AGGRAVATING" hydraulic movements.

- Hold down button C, indicator lamps A9 and C1 will light (60 second time delay), and at the same time perform the necessary "AGGRAVATING" hydraulic movement with extreme care.



D - TESTING THE LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE

- Press briefly on the  button at any time to verify that the longitudinal stability alarm is working.
 - Correct operation: All the LEDs A1 to A8 light for two seconds and an audible alarm is sounded.

NOTE: This test does not make it possible to check the correct adjustment of the longitudinal stability limiter device which must be inspected daily or after every 10 hours of service (3 - MAINTENANCE: 10H - DAILY SERVICE OR EVERY 10 HOURS SERVICE).

E - STRAIN GAUGE







IMPORTANT

Disassembly or calibration of the strain gauge is prohibited, this must only be done by specially trained personnel, consult your dealer.



10 - SWITCHES

NOTE: The location of the switches may vary depending on the options.

-  **HAZARD WARNING LIGHTS**
-  **REAR FOG LIGHT (OPTION)**
-  **ROTATING BEACON LIGHT**
-  **FRONT AND REAR WORKING LIGHTS (OPTION)**
-  **REAR WINDOW DEFROSTER (OPTION) MT 625 H COMFORT 75K ST5**
-  **HYDRAULIC MOVEMENT NEUTRALISATION**



When driving on the road, it is highly recommended (mandatory in Germany) that you cut-off all the hydraulic movements. The indicator lamp shows when it is in use.

"LIFT TRUCK STATIONARY" EXHAUST PURIFICATION



 3 - MAINTENANCE: OCCASIONAL MAINTENANCE
















AUTOMATIC EXHAUST PURIFICATION DEACTIVATION

⚠ IMPORTANT ⚠

Disabling the automatic exhaust purification remains a function that is only to be used in case of necessity (confined or unventilated space, etc.).

By default, the automatic exhaust purification is activated each time the lift truck is started.

- To deactivate the automatic exhaust purification, hold down the bottom of the switch. The indicator lamp  lights up and an audible signal confirms deactivation.
- To reactivate the automatic exhaust purification hold down the bottom of the switch again. The  indicator lamp goes out to confirm reactivation.

EXHAUST PURIFICATION MANAGEMENT			
INDICATIONS	ACTIONS		
 + 1 short sound alarm. Moderate soot level.	Indicator lamp  comes on. Preferably wait until automatic purification is completed before switching off the ignition.	Or	Activate "lift truck stationary" exhaust purification ( 3 - MAINTENANCE: OCCASIONAL MAINTENANCE).
 +  + 1 short sound alarm. Moderate soot level, automatic purification disabled.	Enable automatic purification as soon as possible.	Or	Activate "lift truck stationary" exhaust purification ( 3 - MAINTENANCE: OCCASIONAL MAINTENANCE).
 +  + permanent sound alarm. High soot level.	Engine speed limited to 1200 rpm, only a "stationary lift truck" purification must be performed ( 3 - MAINTENANCE: OCCASIONAL MAINTENANCE).		
 +  +  + permanent sound alarm. Moderate soot level, automatic purification disabled.			
 +  +  + 1 short sound alarm. Very high soot level, particle filter clogged.	Reduced lift truck efficiency, shut down the lift truck and contact your dealer.		

PARKING BRAKE

To connect the parking brake, press the bottom of the switch. The indicator lamp indicates when it is in use. To disconnect the parking brake, press the top of the switch.

DISABLING "AGGRAVATING" HYDRAULIC MOVEMENT CUT-OFF (For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")

 LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE

ATTACHMENT HYDRAULIC LOCKING (OPTION) OR **BOOM HEAD ELECTROVALVE (OPTION) MT 625 H COMFORT 75K ST5** OR **BOOM HEAD ELECTROVALVE + ATTACHMENT HYDRAULIC LOCKING (OPTION) MT 625 H COMFORT 75K ST5**

 DESCRIPTION AND USE OF THE OPTIONS

ATTACHMENT HYDRAULIC CONTROL FORCED OPERATION (OPTION) MT 625 H COMFORT 75K ST5

 DESCRIPTION AND USE OF THE OPTIONS

BOOM ELECTRICAL PREDISPOSITION (OPTION) MT 625 H COMFORT 75K ST5

 DESCRIPTION AND USE OF THE OPTIONS

TILTING MOVEMENT NEUTRALISATION (OPTION)

Makes it possible to cut off the carriage excavating and dumping movements. The indicator lamp shows when it is in use.



11 - ARMREST AND STORAGE

- Lift the armrest 1 to access the storage.



12 - DIAGNOSTIC PLUG

- Remove the access panel to access the plugs.



13 - FUSES AND RELAYS

A sticker on the inside of the access panel provides a quick indication of the use of the fuse plate's components described below.


- Remove the access panel 1 to access the fuses and relays. Replace a used fuse with a new fuse of the same quality and capacity. Never reuse a repaired fuse.

IN THE CAB


F1	5A	Control instrument module.
F2	5A	Water in fuel sensor. Alternator excitation. Longitudinal stability limiter and warning device. (For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE") ECM wake-up.
F3	5A	Anti-theft device predisposition. Diagnostic plug.
F4	10A	"Transmission" electronic control unit. Seat switch. Telescoping and attachment movement control. Exhaust purification switch. Negative parking brake electrovalve. Hydraulic movement cut-off.
F5	15A	12 V plug. Car radio (OPTION).
F6	10A	Presence of driver on seat. Retraction and boom angle sensors.
F7	10A	"Hydraulics" electronic control unit.
F8	5A	Deactivation of aggravating hydraulic movement cut-off.
	7,5A	Deactivation of aggravating hydraulic movement cut-off. Boom head electrovalve (OPTION). **
F9	10A	Brake light relay power supply. Reversing light relay power supply. Audible reversing alarm relay power supply.
F10	2A	Wheel alignment.
F11	15A	Flashing unit.
F12	5A	Rear fog lights.
F13	15A	Working lights on boom switch (OPTION). **
F14	7,5A	Rotating beacon light.
F15	10A	Rear windscreen defrost (OPTION). **
F16	7,5A	Not used. **
F17	15A	Rear windscreen wiper and windscreen washer. Roof windscreen wiper.
F18	15A	Front windscreen wiper and windscreen washer.
F19	30A	Power supply F27-F28-F29-F30.
F20	20A	Heating.
F21	3A	Left sidelights.
F22	3A	Right sidelights.
F23	15A	Dipped beam headlights.
F24	15A	Main beam headlights.
F25	7,5A	Right indicator lights.
F26	7,5A	Left indicator lights.
F27	7,5A	Electric power socket on boom head (OPTION). ** Boom head electrovalve (OPTION). **
F28	10A	Not used. **
F29	10A	Pneumatic seat (OPTION). **
F30	20A	Front and rear working lights (OPTION).
	25A	Front and rear working lights (OPTION). Working lights on boom (OPTION). **
F31	20A	Lighting, horn and indicator switch.
F32	15A	Hazard warning lights (K4).
F33	5A	Diagnostic plug. Anti-theft device predisposition.
F34	7,5A	Warning device. Roof light. **
F35	10A	Car radio. **
F36	5A	"Hydraulics" electronic control unit power supply.
F37	10A	Rear windscreen wiper (+) permanent.
F38	15A	Front windscreen wiper (+) permanent.
F39	7,5A	Air conditioning compressor (OPTION). **
F40	20A	Air conditioning electric fan (OPTION). **



* MT 625 H 75K ST5





** MT 625 H COMFORT 75K ST5



F61	2A	Control instrument module power supply. *
		Not used. **
F62	2A	Battery power supply (+). *
		Not used. **
F63		Free. *
		Not used. **
F64		Free. *
		Not used. **
F71	2A	Control instrument module power supply. **
F72	2A	Battery power supply (+). **
F73		Free. **
F74		Free. **

K1		Free. *
		Not used. **
K2		Reversing lights.
		Reversing sound alarm.
K3		Brake lights.
K4		Free. *
		Working lights on boom (OPTION). **
K5		Air conditioning electric fan (OPTION). **
K6		Air conditioning compressor (OPTION). **
K7		Heating.
K8		Flashing unit.
K9		Not used. *
		Free. **
K10		Air conditioning (OPTION). **




IN THE ENGINE COMPARTMENT

- Open the engine bonnet, remove cover 1 to gain access to the fuses and relays. Replace a used fuse with a new fuse of the same quality and capacity. Never reuse a repaired fuse.



F41	20A	Engine ECU power supply.
F42	60A	Ignition switch.
F43	80A	Alternator.
F44	50A	Power supply for fuses in the cab.
F45	30A	Starter relay power supply.
F46	40A	Engine preheat.
		Fuel decongealant (OPTION).
F51	5A	Air flow sensor.
		Engine EGR valve.
F52	3A	Dashboard power supply.
F53	5A	Start relay control K22.
		Engine ECU information.
F54	5A	Water in fuel sensor power supply.
F55	5A	Engine ECU control power supply.

K20		Engine preheat.
K21		Engine ECU power supply.
K22		Starter control.



14 - CIGARETTE LIGHTER

For 12 V appliance and max. amperage 15A.


15 - LIGHTING, HORN AND INDICATOR SWITCH

The switch controls the visual and sound alarms.

- A - All lights are off, the indicator lights do not flash.
- B - The right hand indicator lights flash.
- C - The left hand indicator lights flash.
- D - Sidelights and rear lights on.
- E - The dipped headlights and the rear lights are on.
- F - The main beam headlights and the rear lights are on.
- G - Headlight signalling.

Pressing the end of the switch sounds the horn.

NOTE: Positions D - E - F - G can be used without switching on the ignition.




16 - FRONT AND REAR WINDSCREEN WIPER SWITCH

FRONT WINDSCREEN WIPER

- A - Front windscreen wiper stop.
- B - Front windscreen wiper low speed.
- C - Front windscreen wiper high speed.
- D - Front windscreen wiper intermittent.
- E - Front windscreen washer by pressing.

REAR WINDSCREEN WIPER

- F - Rear windscreen wiper stop.
- G - Rear windscreen wiper.
- H - Rear windscreen washer by pressing.



17 - FUNCTION FILES

These files contain, among other things, the description of the hydraulic controls and the load charts for the attachments used on the lift truck.

18 - HYDRAULIC CONTROLS

⚠ IMPORTANT ⚠



Do not attempt to alter the hydraulic system pressure by interfering with the pressure regulating valve. In the event of suspected malfunction, contact your dealer. ANY ALTERATION MAY RENDER THE WARRANTY NULL AND VOID.

Use the hydraulic controls gently without jerking, to avoid incidents caused by shaking the lift truck.

NOTE: When driving on the road, it is highly recommended (mandatory in Germany) that all the hydraulic movements are cut off (☞ SWITCHES).

HYDRAULIC CONTROLS ACTIVATION

To avoid inadvertent operation of the hydraulic lifting, tilting, telescoping and attachment controls, a safety device is added to the lift truck (SECOND FIT).

FIRST FIT: NO HYDRAULIC CONTROLS ACTIVATION	
	<p>-Place your hand on the lever and perform the hydraulic movement.</p>
SECOND FIT: HYDRAULIC CONTROLS ACTIVATION	
	<p>-Place your hand on the lever, activate the hydraulic controls by contact on the capacitive sensor and perform the hydraulic movement.</p>
<p>-Hydraulic controls activation is maintained on a timer while the lift truck is being used. -If necessary, reactivate the hydraulic controls.</p>	

A1 - LIFTING

A2 - LOWERING

B1 - EXCAVATION

B2 - DUMP

C1 - TELESCOPE EXTENSION


C2 - TELESCOPE RETRACTION

D1 - ATTACHMENT

D2 - ATTACHMENT



E - BOOM HEAD ELECTROVALVE (OPTION) MT 625 H COMFORT 75K ST5



☞ DESCRIPTION AND USE OF THE OPTIONS




ADJUSTMENT OF ATTACHMENT HYDRAULIC FLOW RATE

- Switch on lift truck ignition.

- Select the attachment circuit hydraulic flow screen  with the scroll button . In turn the screen displays the hydraulic flow stored in the memory of circuit B (without "-" sign) and of circuit A (with "-" sign).


- Press the  button for two seconds, the screen  will appear on the lower screen display.


- Turn button C forwards to select a hydraulic flow for circuit B of between 10% and 100%.




- Hold button C at the desired flow and confirm with the  button.

- The screen  appears on the lower screen display.

- Turn button C backwards to select a hydraulic flow for circuit A between -10% and -100%.

- Hold button C at the desired flow and confirm with the  button.



- The hour meter screen  appears on the lower display screen, confirming that adjustment is completed.



SPEED SELECTION

Speeds can be selected while driving.

Buttons 1 and 2 are used to select a speed.

- HIGH SPEED: For driving on the road. Press button 1, the high speed indicator lamp comes on .
- SLOW SPPED: For handling operations. Press button 2, the slow speed indicator lamp comes on .

20 - SERVICE BRAKE PEDAL AND TRANSMISSION CUT-OFF

The pedal acts on the front wheels by means of a hydraulic brake system to slow down and stop the lift truck. During free travel it enables the transmission to be cut off progressively thus allowing a gradual approach (delicate handling) with all the engine power.


21 - FORWARD/NEUTRAL/REVERSE GEAR SELECTION

When changing the direction of travel, the lift truck should be travelling at slow speed and not accelerating.

FORWARD: Push the switch forward (position A).

REVERSE: Tilt the switch backwards (position B). A reversing light and audible reversing alarm indicate that the lift truck is travelling in reverse.

NEUTRAL: If indicator lamps   or  are flashing, move the forward/reverse selector back through neutral (position C).







SAFETY FOR MOVING THE LIFT TRUCK

Authorisation to move the lift truck is controlled by an electronic module. The operator must observe the following sequence of operations to move the truck forwards or backwards:

- 1 - sit down correctly in the driver's seat,
- 2 - release the parking brake,
- 3 - engage forward or reverse.

To stop the forklift truck, the following sequence must be observed:

- 1 - set the forward/reverse selector to neutral,
- 2 - engage the parking brake,
- 3 - get out of the lift truck.

- If the operator leaves the driver's cab with forward or reverse engaged, the screen  will appear and generate a sound alarm for two seconds. During this time, the operator can sit back down in the seat and continue advancing or reversing. When this time is exceeded, the transmission will switch to neutral and the indicator lamps   or  will flash. The operator must sit back down and pass the forward/reverse selector back through neutral.

SAFETY FOR MOVING THE LIFT TRUCK

The operator must observe the following sequence to move the truck forwards or backwards:

- 1 - sit down correctly in the driver's seat,
- 2 - release the parking brake,
- 3 - engage forward or reverse.

22 - STEERING SELECTION

A - GREEN WHEEL ALIGNMENT INDICATOR LAMPS

⚠ IMPORTANT ⚠

*Before selecting one of the three steering possibilities, align the 4 wheels in relation to the lift truck axis.
Never change the steering mode whilst driving.*

These green indicator lamps come on to indicate the alignment of the wheels in relation to the lift truck. The A1 indicator lamp for the front wheels and the A2 indicator lamp for the rear wheels.

B - STEERING SELECTION LEVER

- B1 - Front drive wheels (road traffic).

NB: The reversing sound alarm is deactivated when this mode is selected.

- B2 - Front and rear drive wheels in the opposite direction (small turning circle).
- B3 - Front and rear drive wheels in the same direction (crabwise movement).



CHECKING WHEEL ALIGNMENT

⚠ IMPORTANT ⚠

*Before travelling on a public road, it is necessary to check the rear wheel alignment and to travel on front drive wheels.
Checking the rear wheel alignment must be performed regularly using the green indicator lamps when the forklift truck is in motion.*

In case of technical faults, consult your dealer.

- Place the steering selection lever B in position B2 (short turning circle).
- Turn the steering wheel and bring the rear wheels into alignment until the A2 indicator lamp comes on.
- Place the steering selection lever B in position B1 (road traffic).
- Turn the steering wheel and align the front wheels until indicator lamp A1 lights up.



23 - HEATER CONTROL

A - FAN CONTROL

This 3-speed control allows the air to be ventilated through the air vents.

B - TEMPERATURE CONTROL

Adjusts the temperature inside the cab.

- B1 - The fan pumps in the air at ambient temperature.
- B2 - The fan pumps in warm air.

The intermediate positions allow the temperature to be adjusted.



24 - AIR CONDITIONING CONTROLS (AIR CONDITIONING OPTION)

MT 625 H COMFORT 75K ST5

⚠ IMPORTANT ⚠

The air conditioning only works if the lift truck has been started.

When using your air conditioning, it is essential to work with the cab closed.

In winter: So as to ensure that the air conditioning unit is correctly operated and completely efficient, start up the compressor once a week, even for a short period of time, in order to lubricate the internal seals.

In cold weather: Warm the engine before switching on the compressor, in order to allow the coolant that has collected in the liquid state at the lowest point of the compressor's circuit to turn into gas under the effect of the heat given off by the engine, as the compressor is liable to be damaged by coolant in the liquid state.

If your air conditioning does not seem to be working correctly, have it examined by your dealer.

Never try to repair any faults yourself.



A - FAN CONTROL

This 3-speed control allows the air to be ventilated through the air vents.

B - TEMPERATURE CONTROL

Adjusts the temperature inside the cab.

- B1 - The fan pumps in cold air.
- B2 - The fan pumps in warm air.

The intermediate positions allow the temperature to be adjusted.

C - AIR CONDITIONING CONTROL

This control with a pilot light allows the air conditioning unit to be switched on.

HEATING MODE

The controls must be adjusted in the following way:

- C - Control with pilot light off.
- B - At the desired temperature.
- A - At the desired speed: 1, 2 or 3.

AIR CONDITIONING MODE

The controls must be adjusted in the following way:

- C - Control with pilot light on.
- B - At the desired temperature.
- A - At the desired speed: 1, 2 or 3.

DEMISTING MODE

The controls must be adjusted in the following way:

- C - Control with pilot light on.
- B - At the desired temperature.
- A - At speed 3.

For optimum effectiveness, close the heating ventilators.

25 - HEATING VENTS

These swivelling heating vents, which can be shut off, allow you to direct and adjust the flow inside the cab.

26 - DEMIST VENTS

These vents allow the windscreen and side windows to be demisted. For optimum efficiency, close the heating vents.

27 - LEVEL INDICATOR

Enables the operator to check that the lift truck is in the horizontal position.

28 - DOOR LOCK

Two keys are provided with the lift truck to enable the cabin to be locked.

29 - DOOR WINDOW OPENING HANDLE

30 - DOOR WINDOW RELEASE BUTTON

31 - HANDLE FOR REAR WINDOW OPENING

EMERGENCY EXIT

Use the rear window as an emergency exit, if it is impossible to leave the cab by the door.

32 - REAR STORAGE SPACE

MT 625 H COMFORT 75K ST5

33 - DOCUMENT STORAGE NET

Make sure that the operator's manual is in the right place, i.e. in the document holder net.

NOTE: An OPTIONAL waterproof document-holder is available.

34 - STEERING WHEEL ADJUSTMENT LEVER (OPTION)

MT 625 H COMFORT 75K ST5

This handle enables the angle and height of the steering wheel to be adjusted.

- Pull the handle 1 backwards.
- Adjust the steering wheel to the desired position.
- Push the knob back to lock the steering wheel in position.





35 - FRONT HEADLIGHTS

- A - Left front indicator light.
- B - Left front dipped beam headlight.
- C - Left front main beam.
- D - Left front side light.
- E - Right front indicator light.
- F - Right front dipped beam headlight.
- G - Right front main beam headlight.
- H - Right front side light.



36 - REAR LIGHTS

- A - Left rear indicator light.
- B - Left rear brake light.
- C - Left rear light.
- D - Rear fog light.
- E - Reversing light.
- F - Right rear light.
- G - Right rear brake light.
- H - Right rear indicator light.




37 - ROTATING BEACON LIGHT (DEPENDING ON ASSEMBLY)

The magnetic rotating beacon light must be clearly visible on the roof of the cab and plugged into socket 1.



38 - ROOF LIGHT (DEPENDING ON ASSEMBLY)

39 - ROOF-SIDE WINDSCREEN WIPER SWITCH (DEPENDING ON ASSEMBLY)



40 - SUN VISOR

STANDARD MT 625 H COMFORT 75K ST5
 OPTION MT 625 H 75K ST5



41 - BOOM SAFETY WEDGE

⚠ IMPORTANT ⚠

Only use the wedge supplied with the lift truck.

The lift truck is equipped with a boom safety wedge which must be installed on the rod of the lifting cylinder when working beneath the boom (↩ 1 - OPERATING AND SAFETY INSTRUCTIONS).



42 - FUEL TANK

As far as possible, keep the fuel tank well filled in order to minimise condensation due to the atmospheric conditions.

⚠ IMPORTANT ⚠

Never smoke or approach with a flame during filling operations or when the tank is open.


Never refill while engine is running.

- If necessary, add diesel (↩ 3 - MAINTENANCE: LUBRICANTS AND FUEL).
- Remove cap 1.
- Fill the fuel tank with clean diesel filtered through the filler port.
- Refit the cap.
- Visually check that there is no leakage in the tank and pipes.



43 - "A-B-C-D-E" MARKING ON BOOM

The marking indicates the outreach of the boom and therefore improves reading of the load charts.



44 - ANGULAR SECTOR ON BOOM

The angular sector displays the boom angle, and thus improves the reading of the load charts.



TOWING DEVICE

1 - TOWING PIN	2-45
2 - REAR ELECTRIC SOCKET (DEPENDING ON ASSEMBLY)	2-45
3 - COUPLING FITTING (OPTION)	2-45
4 - REAR-VIEW MIRROR (OPTION).....	2-45

⚠ IMPORTANT ⚠

Do not tow a trailer or an attachment that is not in perfect working condition.

Using a trailer in poor condition may affect the lift truck's steering and braking, and hence the safety of the assembly.

If a third party helps in coupling or uncoupling the trailer, this person must be permanently visible to the driver and wait until the lift truck has stopped, the handbrake is on and the I.C. engine is switched off before performing the operation.

Located at the rear of the lift truck, this device is used to couple a trailer. Capacity is limited for each lift truck by the authorised gross vehicle weight (AGVW), tractive effort and maximum vertical force on the coupling point. This information is given on the manufacturer's plate fixed to each lift truck (↖ IDENTIFICATION OF THE LIFT TRUCK).

- To use a trailer, see current regulations in your country (maximum running speed, braking, maximum weight of trailer, etc.).
- Verify the trailer's condition before using it (tyre condition and pressures, electrical connection, hydraulic hose, brake system...).

NOTE: Our tractor type-approved lift trucks are not compatible for use with trailers fitted with the ISO7638 socket.

1 - TOWING PIN

⚠ IMPORTANT ⚠


Be careful not to get your fingers caught or crushed during this operation.

Do not forget to put the cotter pin back in place.

When uncoupling, make sure that the trailer is supported independently.

COUPLING AND UNCOUPLING THE TRAILER

- To couple the trailer, position the lift truck as close as possible to the trailer ring.
- Apply the handbrake on and switch off the engine.
- Remove the pin 1, lift the towing pin 2 and place or remove the trailer ring.



2 - REAR ELECTRIC SOCKET (DEPENDING ON ASSEMBLY)

Connect the male plug to the female socket 1 on the lift truck and make sure the lights of the trailer or the light bar are working properly.



3 - COUPLING FITTING (OPTION)

⚠ IMPORTANT ⚠


Be careful not to get your fingers caught or crushed during this operation.

Do not forget to put the cotter pin back in place.

When uncoupling, make sure that the trailer is supported independently.


COUPLING AND UNCOUPLING THE TRAILER

- To couple the trailer, position the lift truck as close as possible to the trailer ring.
- Switch off the engine.
- Remove the pin 1, lift the towing pin 2 and place or remove the trailer ring.



4 - REAR-VIEW MIRROR (OPTION)

The rear-view mirror allows the lift truck to approach the trailer ring more precisely.



DESCRIPTION AND USE OF THE OPTIONS

1 - PREHEAT ROD	2-46
2 - MODCOD ANTI-THEFT SYSTEM	2-46
3 - MODCLE ANTI-START SYSTEM	2-47
4 - LICENSE PLATE LIGHT	2-47
5 - BOOM ELECTRICAL PREDISPOSITION	2-47
6 - EXTERIOR DRAIN-BACK	2-47
7 - WATERPROOF DOCUMENT HOLDER	2-48
8 - WINDSCREEN GRILL	2-48
9 - ATTACHMENT HYDRAULIC LOCKING	2-48
10 - BOOM HEAD ELECTROVALVE	2-49
11 - BOOM HEAD ELECTROVALVE + HYDRAULIC ATTACHMENT LOCKING	2-49
12 - ATTACHMENT HYDRAULIC CONTROL FORCED OPERATION	2-50
13 - ENGINE SPEED REGULATOR	2-50
14 - SPEED LIMITER	2-50
15 - LIFTING RING ON SINGLE CARRIAGE	2-51
16 - CAR STEREO	2-51
17 - INSIDE REAR-VIEW MIRROR	2-51
18 - TELEPHONE HOLDER	2-51
19 - REFLECTIVE BANDS	2-51
20 - FUEL DECONGEALANT	2-51

1 - PREHEAT ROD

Enables the engine block to be kept warm during prolonged periods of stoppage and thus improves engine starting.

SUPPLY CHARACTERISTICS OF PREHEATING SYSTEM:

- Rated power supply voltage range: 110-120 V; 60 Hz.
- Power: 600 W.
- Class 1 equipment.
- Equipment can only be connected to TT or TN supply diagrams.
- Installation category 2.

ENVIRONMENTAL CONDITIONS FOR USE:

- Maximum ambient temperature for using preheat: +77°F (+25°C).
- Pollution level 2.

CONDITIONS FOR CONNECTION AND USE OF PREHEATING:

- The preheat system should not be used for an external ambient temperature higher than +77°F (+25°C).
- It is essential that the power supply to the preheating system:
 - Is effected with a cable that conforms to the installation standards in force and contains a protective earth conductor.
 - Contains an appropriate sectioning system.
 - Incorporates an appropriate safety system against short circuits (fuses or circuit breaker) and a differential circuit breaker with 30 mA sensitivity.
- Only connect to and disconnect from the power supply while the unit is switched off and the engine is stopped.



2 - MODCOD ANTI-THEFT SYSTEM

OPERATION

- Switch on lift truck ignition, red LED 1 will flash.
- Enter your user code followed by "V" to validate, green LED 2 will light.
- Start the lift truck within the next 60 seconds; otherwise the anti-theft system will be reactivated and red LED 1 will flash.

NOTE: If you make a mistake when entering the code, press key "A" to cancel and re-enter the code in full. If you wait more than 5 seconds between key presses, code entry is abandoned, the anti-theft system is reactivated and the red LED will flash.



3 - MODCLE ANTI-START SYSTEM

OPERATION

- Switch on lift truck ignition, red LED 1 will flash.
- Apply key 2 to its base 3, and withdraw it as soon as the system emits a continuous sound signal, and LED 1 turns green.
- Start the lift truck within the next 20 seconds; otherwise the anti-theft system will be reactivated and red LED 1 will flash.

NOTE: You can restart the lift truck within 20 seconds of stopping it; after this time, the anti-start system reacts and red LED 1 flashes.



4 - LICENSE PLATE LIGHT



5 - BOOM ELECTRICAL PREDISPOSITION

MT 625 H COMFORT 75K ST5

Enables an electrical function to be used at the head of the boom.

OPERATION

- Set switch 1 to position A to activate the predisposition, the indicator lamp comes on to show that it is activated.



6 - EXTERIOR DRAIN-BACK

Enables connection of an attachment for which drain-back is required.



7 - WATERPROOF DOCUMENT HOLDER



8 - WINDSCREEN GRILL

DESCRIPTION

The windscreen grill provides additional protection for the operator from any external elements spattered on the windscreen. This grill must be removable from inside the cab to enable an emergency exit.

EMERGENCY EXIT

- After breaking the windscreen with the emergency hammer, push (with force) on the windscreen grill at A to remove it.



9 - ATTACHMENT HYDRAULIC LOCKING

Enables the attachment to be locked onto the carriage and a hydraulic attachment to be used by the same hydraulic circuit.

ATTACHMENT LOCKING CONTROL




- Put tap 1 in position A and press switch 2 at position B (indicator lamp on).
- Push switch 3 forward to lock the attachment and backward to release it.



After locking the attachment, return switch 2 to position A (indicator lamp off) to prevent accidental unlocking of the attachment.

HYDRAULIC ATTACHMENT CONTROL

- Put the tap in position B and press switch 2 at position B (indicator lamp on).
- Push switch 3 forward or backward.



10 - BOOM HEAD ELECTROVALVE

MT 625 H COMFORT 75K ST5

Enables use of two hydraulic functions on the attachment circuit.

⚠ IMPORTANT ⚠



To facilitate connection of the quick couplers, decompress the hydraulic circuit by pressing button 1 on the electrovalve.

ATTACHMENT LINE A1/B1 CONTROL

- Put switch 1 to position A (indicator lamp off).
- Push switch 2 forward or backward.

ATTACHMENT LINE A2/B2 CONTROL

- Put switch 1 to position B (indicator light on) and hold down button 3.
- Push switch 2 forward or backward.



11 - BOOM HEAD ELECTROVALVE + HYDRAULIC ATTACHMENT LOCKING

MT 625 H COMFORT 75K ST5

Enables the use of a hydraulic function and hydraulic locking of the attachment on the attachment circuit.

⚠ IMPORTANT ⚠



To facilitate connection of the quick couplers, decompress the hydraulic circuit by pressing button 1 on the electrovalve.

ATTACHMENT LINE A1/B1 CONTROL

- Put switch 1 to position A (indicator lamp off).
- Push switch 2 forward or backward.

ATTACHMENT A2/B2 LOCKING CONTROL

- Put switch 1 to position B (indicator light on) and hold down button 3.
- Push switch 2 forward to lock the attachment and backward to release it.



12 - ATTACHMENT HYDRAULIC CONTROL FORCED OPERATION

MT 625 H COMFORT 75K ST5



⚠ IMPORTANT ⚠

This OPTION must only be used with an attachment requiring continuous hydraulic movement, such as a brush, feeder bucket, mixer, spray etc. It is strictly forbidden for use in handling operations and all other applications (winch, crane jib, crane jib with winch, hook, etc.).

CONTINUOUS HYDRAULIC MOVEMENT OF THE ATTACHMENT

- Simultaneously hold button 1 in the forward or backward position (according to the type of attachment) and switch 2 in position B (indicator light on). An audible alarm will sound when activated. Release button 1 and switch 2.
- To stop the movement, press again on the bottom of switch 1, or operate button 2.

NOTE: If the operator leaves the driver's cab, the continuous hydraulic movement will automatically stop and must be restarted.



13 - ENGINE SPEED REGULATOR

MT 625 H COMFORT 75K ST5

⚠ IMPORTANT ⚠

This option cannot under any circumstances be used while driving on the road. Caution when driving, sudden acceleration or braking when you use button 2.

The regulator controls the engine speed, increases the hydraulic flow and therefore increases the speed of all the movements.

- Adjust the engine speed with lever 1.

Used for an attachment requiring continuous hydraulic movement (brush, feeder bucket, mixer, spray).



14 - SPEED LIMITER

MT 625 H COMFORT 75K ST5

⚠ IMPORTANT ⚠

This option cannot under any circumstances be used while driving on the road.

Only accessible in TORTOISE MODE, the speed limiter limits the speed from 0,25 to 7,5 mph (0,4 to 12 km/h) by turning the button 1.

Use for an attachment requiring a constant speed of travel (brush, feeder bucket, spray).

- After having switched off the ignition with the ignition key turn button 1 to zero to reinitialise this option then reset to the desired value.




15 - LIFTING RING ON SINGLE CARRIAGE

CONDITIONS OF USE

⚠ IMPORTANT ⚠

Follow the instructions given in your lift truck's instruction manual (1 - OPERATING AND SAFETY INSTRUCTIONS FOR HANDLING LOADS), and in addition those given below.

- The lifting ring must be used WITHOUT FORKS AND ATTACHMENTS, but the angle of inclination of the carriage must be same as when the forks are used in the horizontal position.
- Check the maximum permitted angle, which is 45°.
- Do not change the angle of the carriage while using the lifting ring.
- The lifting hook, the chains and slings shall have a minimum capacity of 6614 lbs (3000 kg) with a safety coefficient of 4 in relation to breakage.



LOAD CHARTS AND FUNCTION SHEETS

⚠ IMPORTANT ⚠

The load charts are defined for use without forks and without attachments.


16 - CAR STEREO

17 - INSIDE REAR-VIEW MIRROR

18 - TELEPHONE HOLDER



19 - REFLECTIVE BANDS



20 - FUEL DECONGELANT

The paraffin particles found naturally in diesel crystallise at low temperatures. The fuel decongelant helps to limit accumulation in the filter.

3 - MAINTENANCE

3 - MAINTENANCE

ORIGINAL MANITOU SPARE PARTS AND EQUIPMENT	3-3
FORKLIFT TRUCK MAINTENANCE	3-4
DAILY AND WEEKLY MAINTENANCE	3-4
MANDATORY FIRST 500 HOURS OR 6 MONTHS SERVICE	3-5
PERIODIC SERVICE	3-6
OCCASIONAL MAINTENANCE AND OPERATION	3-8
FILTER ELEMENTS AND BELTS	3-9
LUBRICANTS AND FUEL	3-10
➞ 10H - DAILY SERVICE OR EVERY 10 HOURS OF SERVICE	3-12
➞ 50H - WEEKLY SERVICE OR EVERY 50 HOURS OF SERVICE	3-14
➞ ① 500H - PERIODIC SERVICE - EVERY 500 HOURS OF SERVICE OR 1 YEAR	3-20
➞ ② 1000H - PERIODIC SERVICE - EVERY 1000 HOURS OF SERVICE OR 2 YEARS	3-24
➞ ③ 2000H - PERIODIC SERVICE - EVERY 2000 HOURS OF SERVICE OR 4 YEARS	3-30
➞ ④ 3000H - PERIODIC SERVICE - EVERY 3000 HOURS OF SERVICE OR 6 YEARS	3-33
➞ OCCASIONAL MAINTENANCE	3-34
➞ OCCASIONAL OPERATION	3-38

ORIGINAL MANITOU SPARE PARTS AND EQUIPMENT

OUR LIFT TRUCKS MUST BE SERVICED USING ORIGINAL MANITOU PARTS.

BY ALLOWING THE USE OF NON ORIGINAL MANITOU PARTS, YOU RISK:

⚠ IMPORTANT ⚠

THE USE OF COUNTERFEIT PARTS OR COMPONENTS NOT APPROVED BY THE MANUFACTURER, MEANS YOU LOSE THE BENEFIT OF THE CONTRACTUAL GUARANTEE.

- Legally - to be held responsible in the event of an accident.
- Technically - to cause operating malfunctions or shorten the life of the lift truck.

BY USING ORIGINAL MANITOU PARTS FOR MAINTENANCE OPERATIONS, YOU BENEFIT FROM OUR KNOW-HOW

Through its network, MANITOU provides the user with,

- Know-how and competence.
- The guarantee of high-quality work.
- Original replacement parts.
- Help with preventive maintenance.
- Efficient help with diagnosis.
- Improvements due to experience feedback.
- Operator training.
- Only the MANITOU network has detailed knowledge of the design of the lift truck and therefore the best technical ability to provide maintenance.

⚠ IMPORTANT ⚠

ORIGINAL REPLACEMENT PARTS ARE DISTRIBUTED EXCLUSIVELY BY MANITOU AND ITS DEALER NETWORK.

The dealer network list is available on the MANITOU web site: www.manitou.com

FORKLIFT TRUCK MAINTENANCE

DAILY AND WEEKLY MAINTENANCE



THE OPERATOR IS AUTHORISED TO CARRY OUT THIS MAINTENANCE.

These maintenance operations enable the operator to maintain the lift truck in a clean and safe condition.

MANDATORY FIRST 500 HOURS OR 6 MONTHS SERVICE



THIS SERVICE MUST BE CARRIED OUT AFTER THE FIRST 500 HOURS OF SERVICE OR WITHIN THE 6 MONTHS FOLLOWING PUTTING THE MACHINE INTO SERVICE (WHICHEVER OCCURS FIRST).

PERIODIC SERVICE



THE PERIODIC MAINTENANCE MUST BE CARRIED OUT BY AN APPROVED PROFESSIONAL FROM THE MANITOU NETWORK.

MAINTENANCE SCHEDULE

This schedule enables the operator to keep up with the periodic service of the lift truck by notifying the total number of hours of operation and the date of the service performed by the professional approved by the MANITOU network.

OCCASIONAL MAINTENANCE AND OPERATION

These maintenance tasks and operations are to be performed as required for the safety and upkeep of the lift truck.

DAILY AND WEEKLY MAINTENANCE

↻ 10H - DAILY SERVICE OR EVERY 10 HOURS OF SERVICE

- CHECK	Lift truck environment	3-12
- CHECK	Engine oil level	3-12
- CHECK	Cooling liquid level	3-12
- CHECK	Longitudinal stability limiter and warning device	3-13
- CLEAN	Cyclonic pre-filter (option)	3-13

↻ 50H - WEEKLY SERVICE OR EVERY 50 HOURS OF SERVICE

- CHECK	Alternator/crankshaft belt tension	3-14
- CHECK	Compressor belt tension (Air conditioning option)	3-14
- CHECK	Transfer box oil level	3-14
- CHECK	Tyre pressures	3-14
- CHECK	Wheel nut tightening	3-14
- CHECK	Front axle differential seal	3-15
- CHECK	Rear axle differential seal	3-15
- CHECK	Front wheel reducer seals	3-15
- CHECK	Rear wheel reducer seals	3-15
- CHECK	Brake fluid level	3-15
- CHECK	Boom pad slide pathways	3-15
- CHECK	Hydraulic oil level	3-16
- CHECK	Windscreen washer liquid level	3-16
- CLEAN	Fuel pre-filter	3-16
- CLEAN	Radiator cores	3-17
- CLEAN	Dry air filter cartridge	3-17
- CLEAN	Condenser wiring harness (Air conditioning OPTION)	3-17
- LUBRICATE	General lubrication	3-18
- REPLACE	Engine oil *	3-19
- REPLACE	Engine oil filter *	3-19

*** Only for the first 50 hours of service and then every 500 hours of service or 1 year.**

MANDATORY FIRST 500 HOURS OR 6 MONTHS SERVICE

FIRST 500 HOURS BEFORE THE FIRST 6 MONTHS

- If the lift truck has reached the first 500 hours of service before the first 6 months have expired, perform both the mandatory service and periodic 500 H service (◀ ➡ ① 500H - PERIODIC SERVICE - EVERY 500 HOURS OF SERVICE OR 1 YEAR).

FIRST 6 MONTHS BEFORE THE FIRST 500 HOURS

- If the lift truck has not completed 500 hours of service in the first 6 months, just carry out the mandatory service.

MANDATORY SERVICE

- CHECK	Alternator/crankshaft belt tension	3-14
- CHECK	Compressor belt tension (Air conditioning option)	3-14
- CHECK	Transfer box oil level	3-14
- CHECK	Tyre pressures	3-14
- CHECK	Wheel nut tightening	3-14
- CHECK	Front axle differential seal	3-15
- CHECK	Rear axle differential seal	3-15
- CHECK	Front wheel reducer seals	3-15
- CHECK	Rear wheel reducer seals	3-15
- CHECK	Brake fluid level	3-15
- CHECK	Boom pad slide pathways	3-15
- CHECK	Hydraulic oil level	3-16
- CHECK	Windscreen washer liquid level	3-16
- CLEAN	Fuel pre-filter	3-16
- CLEAN	Radiator cores	3-17
- CLEAN	Dry air filter cartridge	3-17
- CLEAN	Condenser wiring harness (Air conditioning OPTION)	3-17
- LUBRICATE	General lubrication	3-18
- CHECK	Hoses and differential pressure hoses for the exhaust particle filter "DPF" **	3-23
- CHECK	Exhaust gas recirculation piping "EGR" **	3-23
- CHECK	Intake hose **	3-23
- CHECK	**Exhaust manifold	3-23
- CHECK	Fork wear *	3-23
- CHECK	Safety belt	3-24
- CHECK	Silentblocks **	3-28
- CHECK	Valve lash **	3-28
- CHECK	Injectors **	3-28
- CHECK	Exhaust gas recirculation cooler "EGR" **	3-28
- CHECK	Casing gas recycling valve **	3-28
- CHECK	Brake system pressure *	3-28
- CHECK	Boom pad wear *	3-28
- CHECK	Condition of wiring harnesses and cables *	3-28
- CHECK	Lights and signals *	3-28
- CHECK	Warning indicators *	3-28
- CHECK	Condition of the rear-view mirrors *	3-28
- CHECK	Cabin structure *	3-28
- CHECK	Frame structure *	3-28
- CHECK	Attachment carriage *	3-28
- CHECK	Condition of attachments *	3-28
- EPLACE	Brake fluid *	3-28

**** Engine service, consult your dealer.**

*** Consult your dealer.**

PERIODIC SERVICE

MAINTENANCE SCHEDULE

WHEN DUE ➡	↻ OR ↻		500 H or 1 YEAR	1000 H or 2 YEARS	1500 H or 3 YEARS	2000 H or 4 YEARS
	FIRST 6 MONTHS	FIRST 500 HOURS				
PERIODIC SERVICE ➡	MANDATORY SERVICE	MANDATORY SERVICE + ①	①	①+②	①	①+②+③
MACHINE COUNTER ➡						
DATE OF SERVICING ➡						

WHEN DUE ➡	2500 H or 5 YEARS	3000 H or 6 YEARS	3500 H or 7 YEARS	4000 H or 8 YEARS	4500 H or 9 YEARS	5000 H or 10 YEARS	5500 H or 11 YEARS
PERIODIC SERVICE ➡	①	①+②+④	①	①+②+③	①	①+②	①
MACHINE COUNTER ➡							
DATE OF SERVICING ➡							

WHEN DUE ➡	6000 H or 12 YEARS	6500 H or 13 YEARS	7000 H or 14 YEARS	7500 H or 15 YEARS	8000 H or 16 YEARS	8500 H or 17 YEARS	9000 H or 18 YEARS
PERIODIC SERVICE ➡	①+②+③+④	①	①+②	①	①+②+③	①	①+②+④
MACHINE COUNTER ➡							
DATE OF SERVICING ➡							

➡ ① 500H - PERIODIC SERVICE - EVERY 500 HOURS OF SERVICE OR 1 YEAR

- CHECK	Hydraulic oil	3-20
- REPLACE	Engine oil	3-20
- REPLACE	Engine oil filter	3-20
- REPLACE	Fuel filter	3-21
- REPLACE	Fuel pre-filter	3-21
- REPLACE	Transfer box oil	3-21
- REPLACE	Front axle differential oil	3-22
- REPLACE	Hydraulic return oil filter cartridge	3-22
- REPLACE	Hydraulic fluid tank filter cap	3-23
- REPLACE	Cab fan filter	3-23
- CHECK	Hoses and differential pressure hoses for the exhaust particle filter "DPF" **	3-23
- CHECK	Exhaust gas recirculation piping "EGR" **	3-23
- CHECK	Intake hose **	3-23
- CHECK	**Exhaust manifold	3-23
- CHECK	Fork wear *	3-23
- CHARGE	12 V battery	3-23

**** Engine service, consult your dealer.**

*** Consult your dealer.**

➔ 2 1000H - PERIODIC SERVICE - EVERY 1000 HOURS OF SERVICE OR 2 YEARS

ALSO PERFORM THE 500 HOUR PERIODIC MAINTENANCE OPERATIONS.

- CHECK	Safety belt	3-24
- CLEAN	Fuel tank	3-24
- REPLACE	Alternator belt	3-25
- REPLACE	Engine crankcase ventilation filter	3-25
- REPLACE	Dry air filter cartridge	3-26
- REPLACE	Coolant	3-26
- REPLACE	Rear axle differential oil	3-27
- REPLACE	Front wheel reducer oil	3-27
- REPLACE	Rear wheel reducer oil	3-27
- CHECK	Silentblocks **	3-28
- CHECK	Valve lash **	3-28
- CHECK	Injectors **	3-28
- CHECK	Exhaust gas recirculation cooler "EGR" **	3-28
- CHECK	Casing gas recycling valve **	3-28
- CHECK	Brake system pressure *	3-28
- CHECK	Boom pad wear *	3-28
- CHECK	Condition of wiring harnesses and cables *	3-28
- CHECK	Lights and signals *	3-28
- CHECK	Warning indicators *	3-28
- CHECK	Condition of the rear-view mirrors *	3-28
- CHECK	Cabin structure *	3-28
- CHECK	Frame structure *	3-28
- CHECK	Attachment carriage *	3-28
- CHECK	Condition of attachments *	3-28
- EPLACE	Brake fluid *	3-28
- BLEED	Brake circuit *	3-28
- ADJUST	Brake *	3-28

**** Engine service, consult your dealer.**

*** Consult your dealer.**

➔ 3 2000H - PERIODIC SERVICE - EVERY 2000 HOURS OF SERVICE OR 4 YEARS

ALSO PERFORM THE 500 HOUR AND 1000 HOUR PERIODIC MAINTENANCE OPERATIONS.

- CHECK	Wheel nut tightening torques	3-30
- REPLACE	Dry air filter safety cartridge	3-30
- REPLACE	Hydraulic oil	3-31
- REPLACE	Brake accumulator unit filter	3-31
- CHECK	Radiator *	3-32
- CHECK	Transmission pressures *	3-32
- CHECK	Steering *	3-32
- CHECK	Steering swivel joints *	3-32
- CHECK	Brake pad and brake disk wear *	3-32
- CHECK	Condition of boom assembly *	3-32
- CHECK	Bearings and bushings *	3-32
- CHECK	Condition of hoses and flexible pipes *	3-32
- CHECK	Condition of cylinders (leakage, rods) *	3-32
- CHECK	Hydraulic circuit pressures *	3-32
- CLEAN	Air conditioning (OPTION) *	3-32
- REPLACE	Compressor belt (Air Conditioning OPTION) *	3-32

*** Consult your dealer.**

➔ 4 3000H - PERIODIC SERVICE - EVERY 3000 HOURS OF SERVICE OR 6 YEARS

ALSO PERFORM THE 500 HOUR AND 1000 HOUR PERIODIC MAINTENANCE OPERATIONS.

- CHECK	Turbocharger **	3-33
- CHECK	Exhaust gas recirculation system "EGR" **	3-33
- CLEAN	Exhaust particle filter "DPF" **	3-33

**** Engine service, consult your dealer.**

OCCASIONAL MAINTENANCE AND OPERATION

↻ OCCASIONAL MAINTENANCE


- CLEAN	"Stationary lift truck" exhaust purification.....	3-34
- REPLACE	Wheels	3-35
- REPLACE	Battery failure.....	3-36
- ADJUST	Front headlights	3-36
- RESET	Longitudinal stability limiter and warning device.....	3-37

↻ OCCASIONAL OPERATION


- TOW OR WINCH	Lift truck.....	3-38
- SLING	Lift truck.....	3-38
- TRANSPORT	Lift truck.....	3-39

FILTER ELEMENTS AND BELTS

➔ ① 500H - PERIODIC SERVICE - EVERY 500 HOURS OF SERVICE OR 1 YEAR




ENGINE OIL FILTER




HYDRAULIC RETURN OIL FILTER CARTRIDGE



FUEL PRE-FILTER



INTERIOR CAB VENTILATION FILTER




FUEL FILTER




HYDRAULIC FLUID TANK FILTER CAP

➔ ② 1000H - PERIODIC SERVICE - EVERY 1000 HOURS OF SERVICE OR 2 YEARS


ALSO ADD FILTER ELEMENTS FOR PERIODIC MAINTENANCE AFTER 500 HOURS OF SERVICE.



ALTERNATOR BELT




DRY AIR FILTER CARTRIDGE




ENGINE CRANKCASE VENTILATION FILTER

➔ ③ 2000H - PERIODIC SERVICE - EVERY 2000 HOURS OF SERVICE OR 4 YEARS

ALSO ADD FILTER ELEMENTS FOR PERIODIC MAINTENANCE AT 500 HOURS AND 1000 HOURS OF SERVICE.




SAFETY DRY AIR FILTER CARTRIDGE




BRAKE ACCUMULATOR UNIT FILTER

➔ OCCASIONAL MAINTENANCE



SUCTION STRAINER FOR HYDRAULIC OIL TANK



CYCLONIC PRE-FILTER (OPTION)

LUBRICANTS AND FUEL

⚠ IMPORTANT ⚠

- USE THE RECOMMENDED LUBRICANTS AND FUEL:**
- For topping up, oils may not be miscible.
 - For oil changes, MANITOU oils are perfectly appropriate.

DIAGNOSTIC ANALYSIS OF OILS

If a service or maintenance contract has been set up with the dealer, a diagnostic analysis of engine, transmission and axle oils may be requested depending on the rate of use.

(*) REQUIRED FUEL SPECIFICATION

⚠ IMPORTANT ⚠

- Replace the water separator O-ring when switching from diesel fuel to biodiesel fuel such as HVO.**
- Pay special attention to the seals and fuel hoses when using HVO.**

Use fuel that meets the following standards:

- Diesel EN590
- Diesel ASTM D975
- Biodiesel HVO100 EN15940

RECOMMENDATION

ENGINE		RECOMMENDATION									
DESCRIPTION	CAPACITY	-40°F	-22°F	-4°F	14°F	32°F	50°F	68°F	86°F	104°F	122°F
		-40°C	-30°C	-20°C	-10°C	0°C	10°C	20°C	30°C	40°C	50°C
ENGINE	3 US gal (11,2 ℓ)										
COOLING CIRCUIT	12.7 US qt (12 ℓ)	COOLANT -35°C									
FUEL TANK	16.6 US gal (63 ℓ)	GNR HP DIESEL FUEL *									
BOOM		RECOMMENDATION									
DESCRIPTION		-40°F	-22°F	-4°F	14°F	32°F	50°F	68°F	86°F	104°F	122°F
		-40°C	-30°C	-20°C	-10°C	0°C	10°C	20°C	30°C	40°C	50°C
BOOM PAD SLIDE PATHWAYS		MANITOU BLACK MULTI-PURPOSE LUBRICANT									
GREASING OF THE BOOM		MANITOU BLUE MULTI-PURPOSE LUBRICANT									
HYDRAULICS		RECOMMENDATION									
DESCRIPTION	CAPACITY	-40°F	-22°F	-4°F	14°F	32°F	50°F	68°F	86°F	104°F	122°F
		-40°C	-30°C	-20°C	-10°C	0°C	10°C	20°C	30°C	40°C	50°C
HYDRAULIC OIL TANK	22.5 US gal (85 ℓ)										

BRAKES		
DESCRIPTION	CAPACITY	RECOMMENDATION
BRAKE SYSTEM	1.06 US qt (1 ℓ)	MANITOU MINERAL BRAKE FLUID

CAB		
DESCRIPTION	CAPACITY	RECOMMENDATION
WINDSCREEN WASHER TANK	2.11 US qt (2 ℓ)	WINDSCREEN WASHER LIQUID

FRONT AXLE		
DESCRIPTION	CAPACITY	RECOMMENDATION
FRONT AXLE DIFFERENTIAL	4.23 US qt (4 ℓ)	SPECIAL MANITOU OIL FOR IMMersed BRAKES
		-40°F -22°F -4°F 14°F 32°F 50°F 68°F 86°F 104°F 122°F
		-40°C -30°C -20°C -10°C 0°C 10°C 20°C 30°C 40°C 50°C
TRANSFER GEAR BOX FRONT WHEEL REDUCING GEAR	0.79 US qt (0,75 ℓ) 2 x 0.85 US qt (0,8 ℓ)	MANITOU SAE80W90 MECHANICAL TRANSMISSION OIL
		-40°F -22°F -4°F 14°F 32°F 50°F 68°F 86°F 104°F 122°F
		-40°C -30°C -20°C -10°C 0°C 10°C 20°C 30°C 40°C 50°C
FRONT WHEEL REDUCING GEAR PIVOTS		MANITOU BLACK MULTI-PURPOSE LUBRICANT

REAR AXLE		
DESCRIPTION	CAPACITY	RECOMMENDATION
REAR AXLE DIFFERENTIAL	4.02 US qt (3,8 ℓ)	SPECIAL MANITOU OIL FOR IMMersed BRAKES
		-40°F -22°F -4°F 14°F 32°F 50°F 68°F 86°F 104°F 122°F
		-40°C -30°C -20°C -10°C 0°C 10°C 20°C 30°C 40°C 50°C
REAR WHEEL REDUCING GEAR	2 x 0.95 US qt (0,9 ℓ)	MANITOU SAE80W90 MECHANICAL TRANSMISSION OIL
		-40°F -22°F -4°F 14°F 32°F 50°F 68°F 86°F 104°F 122°F
		-40°C -30°C -20°C -10°C 0°C 10°C 20°C 30°C 40°C 50°C
REAR AXLE OSCILLATION		MANITOU BLUE MULTI-PURPOSE LUBRICANT
		-40°F -22°F -4°F 14°F 32°F 50°F 68°F 86°F 104°F 122°F
		-40°C -30°C -20°C -10°C 0°C 10°C 20°C 30°C 40°C 50°C
REAR WHEEL REDUCING GEAR PIVOTS		MANITOU BLACK MULTI-PURPOSE LUBRICANT

CHECK

Lift truck environment

Carry out a general inspection around the lift truck:

- Fluid leaks or stains on the ground.
- Additional objects on the lift truck and in the cabin.
- Mounting and locking of the attachment.
- Mounting and adjustment of rear-view mirrors.
- Condition of the tyres, to detect cuts, blisters, wear, etc.

⚠ IMPORTANT ⚠

Follow the operator instructions (↩ 1 - OPERATING AND SAFETY INSTRUCTIONS: OPERATOR INSTRUCTIONS).

CLEANLINESS OF THE FORKLIFT

- Cleanliness of lights and rear-view mirror.
- Excess dirt or build-up of material (e.g. straw, flour, sawdust, organic waste, etc.).
- On a daily basis, according to the conditions of use and the environment, the operator should ensure that the forklift truck is kept in a clean condition.
- Particular attention should be paid to accumulations of flammable materials (e.g. straw, flour, sawdust, organic waste, etc.) and fuel or lubricant leaks, as these significantly increase the risk of fire outbreaks.
- A regular inspection of the whole lift truck, especially the engine housing and the central part of the frame, is necessary to see how frequently it needs to be cleaned to prevent these potential accumulations of material or leakages.

CHECK

Engine oil level

Place the lift truck on level ground with the engine stopped, and let the oil settle in the sump.

- Open the engine cover.
- Pull out dipstick 1.
- Clean the dipstick and check the correct level between the two notches.
- If necessary, add oil (↩ LUBRICANTS AND FUEL) through the filler hole 2.
- Visually check that there is no leakage or seepage.



CHECK

Cooling liquid level

Place the lift truck on level ground with the engine stopped, and allow the engine to cool.

⚠ IMPORTANT ⚠

To avoid any risk of spraying or scalding, wait until the engine has cooled down before removing the cooling system filler plug.

In the event of an emergency, it is possible to use water as the coolant, but then proceed to drain the coolant circuit as quickly as possible.

- Open the engine cover.
- The liquid must be at mid-height in the expansion tank 1.
- If necessary, add coolant (↩ LUBRICANTS AND FUEL) through the filler hole 2.
- Visually check that there is no leakage or seepage.



(For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")















⚠ IMPORTANT ⚠

Use the test button  only when instructed, following the guidance for a short press (less than 1 second) or a long press (5 seconds).

In case of doubt during the test procedure, exit cleanly by a short press on the "BUCKET" MODE  or "SUSPENDED LOAD" buttons .

These tests are essential for checking the correct operation and adjustment of the different components of the device.

- Place the lift truck on flat, level ground with the wheels straight.
- Hold down the test button .

<p>STEP 1</p> <p>↓</p>	 <ul style="list-style-type: none"> - A beep. - First green LED flashing. - Test button lit. 	<p>→</p>  <ul style="list-style-type: none"> - Place the lift truck without any attachment, with the boom fully retracted and raised. 	<p>→</p> <p>Short press the test button. </p> <p>→</p> <p>TEST OK</p> <ul style="list-style-type: none"> - Beeps once and progresses to stage 2. <p>TEST NOT OK</p> <ul style="list-style-type: none"> - Beeps twice and warning indicator lamp comes on . - Exit test mode. - Go to stage 4.
<p>STEP 2</p> <p>↓</p>	 <ul style="list-style-type: none"> - First green LED continuously lit. - Second green LED flashing. - Test button lit. 	<p>→</p>  <ul style="list-style-type: none"> - Lower the boom with the engine running at full revs and the hydraulic control at the maximum setting. Slow lowering until movement is cut-off. 	<p>→</p> <p>Short press the test button. </p> <p>→</p> <p>TEST OK</p> <ul style="list-style-type: none"> - Beeps once and progresses to stage 3. <p>TEST NOT OK</p> <ul style="list-style-type: none"> - Beeps twice and warning indicator lamp comes on . - Exit test mode. - Go to stage 4.
<p>STEP 3</p> <p>↓</p>	 <ul style="list-style-type: none"> - First and second green LEDs continuously lit. - Third green LED flashing. - Test button lit. 	<p>→</p> <ul style="list-style-type: none"> - Lower the boom until the movement is cut off. - Request, in the following order: an excavation, dumping and a telescope boom extension. None of these 3 movements should be possible. 	<p>→</p> <p>Short press the test button. </p> <p>→</p> <p>TEST OK</p> <ul style="list-style-type: none"> - Conformity of aggravating movement cut-off. - Exit test mode. All the LEDs will light for 2 seconds and a beep will sound. <p>TEST NOT OK</p> <ul style="list-style-type: none"> - Fault indicator lamp  comes on. - Exit test mode. - Go to stage 4.
<p>STEP 4</p>	 <ul style="list-style-type: none"> - The fault indicator goes out. 	<p>→</p> <ul style="list-style-type: none"> - Pictogram  appears on the hour meter screen  and an audible beep is sounded. - Scroll through the error codes (← 2 - DESCRIPTION: 6B - SCREEN DISPLAYS: ERROR CODES). - If the error code "520393" is displayed, the problem may be resolved by resetting the longitudinal stability limiter and warning device (← OCCASIONAL SERVICE). Otherwise consult your dealer and provide the error code numbers. <p>NOTE: For the stage 3 test, specify the non-conforming aggravating hydraulic movements, if necessary.</p>	

CLEAN

Cyclonic pre-filter (option)

The cleaning interval is given as a guide, however the pre-filter must be emptied and cleaned as soon as impurities reach the MAX level on the tank.

⚠ IMPORTANT ⚠

When cleaning, take care not to let impurities into the dry air filter.

- Loosen nut 1 remove cover 2 and empty the tank.
- Clean the pre-filter unit with a clean dry cloth and reassemble the unit.



➔ 50H - WEEKLY SERVICE OR EVERY 50 HOURS OF SERVICE


CHECK

Alternator/crankshaft belt tension

⚠ IMPORTANT ⚠

If the belt is changed, check the tension again after the first 20 hours of service.

- Open the engine cover.
- Check the belt for signs of wear and cracks, and change if necessary (☞ FILTER ELEMENTS AND BELTS).
- Check the belt tension between the fan pulley and the alternator pulley (22,03 lbs / 98 N). The clearance should be about 0,3 to 0,4 in (7 to 9 mm).
- Adjust if necessary.
- Loosen screws 1 by two to three thread turns.
- Swivel the alternator assembly so as to obtain the required belt tension.
- Retighten screws 1 (tightening torque 16 ft-lbs ±1,6 ft-lbs 22 N.m ±2,2 N.m).




CHECK

Compressor belt tension (Air conditioning option)

⚠ IMPORTANT ⚠

If the belt is changed, check the tension again after the first 20 hours of service.

- Open the engine cover.
- Check the belt for signs of wear and cracks, and change if necessary (☞ FILTER ELEMENTS AND BELTS).
- Check the belt tension between the pulleys of the crankshaft and the compressor
- Under a normal pressure exerted with the thumb (10 lbs / 45 N), the clearance should be approximately 0,39 in (10 mm).
- Adjust if necessary.
- Loosen the screws 1 and nuts 2 by two to three thread turns.
- Swivel the compressor assembly so as to obtain the belt tension required.
- Re-tighten screws 1 and nuts 2 (tightening torque 16 ft-lbs ±1,6 ft-lbs 22 N.m ±2,2 N.m).



CHECK

Transfer box oil level

Place the lift truck on level ground with the engine stopped.

- Visually check for any traces of seepage or leakage from the various filler, level and drain plugs.
- If there is any leakage or seepage, check the level.
- Remove the level plug 1, the oil should be flush with the edge of the hole.
- If necessary, add oil (☞ LUBRICANTS AND FUEL) by the same hole.
- Refit and tighten the level plug 1 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).



CHECK

Tyre pressures

CHECK

Wheel nut tightening

⚠ IMPORTANT ⚠

Check that the air hose is correctly connected to the tyre valve before inflating and keep all persons at a distance during inflation. Follow the recommended tyre pressures.

- Check the condition of the tyres, to detect cuts, blisters, wear, etc.
- Check the wheel nut tightening. Non-compliance with this instruction can lead to deterioration and breakage of the wheel bolts and distortion of the wheels.
- Check and restore tyre pressures if necessary (☞ 2 - DESCRIPTION: TYRES).

NOTE: There is an OPTIONAL wheel tool kit.

CHECK

Front axle differential seal

CHECK

Rear axle differential seal

Place the lift truck on level ground with the engine stopped.

- Visually check for any traces of seepage or leakage from the various filler, level and drain plugs.
- If there is any leakage or seepage, check the level.
- Remove the level plug 1, the oil should be flush with the edge of the hole.
- If necessary, add oil (\leq LUBRICANTS AND FUEL) through the filler hole 2.
- Refit and tighten the level plug 1 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).



CHECK

Front wheel reducer seals

CHECK

Rear wheel reducer seals

Place the lift truck on level ground with the engine stopped.

- Visually check for any traces of seepage or leakage from the level plug.
- If there is any leakage or seepage, check the level.
- Place level plug 1 in a horizontal position.
- Remove the level plug; the oil should be flush with the edge of the opening.
- If necessary, add oil (\leq LUBRICANTS AND FUEL) by the same hole.
- Refit and tighten the level plug (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).



CHECK

Brake fluid level

Place the lift truck on level ground.

⚠ IMPORTANT ⚠

If the brake oil level is abnormal consult your dealer.

- Open the protective casing 1 with the ignition key.
- Check tank 2. The correct level should be at the MAX. level on the tank.
- If necessary, add oil (\leq LUBRICANTS AND FUEL).
- Remove cap 3.
- Add oil through filler port.
- Refit the cap.
- Visually check that there is no leakage in the tank and pipes.



CHECK

Boom pad slide pathways

To preserve optimum operation, the pad slide pathways should be correctly lubricated:

⚠ IMPORTANT ⚠

MANDATORY GREASING OF THE BOOM AFTER:
Cleaning the boom, especially after using high pressure cleaner.
The forklift has been unused for a long period of time.

- Fully extend the boom.
- Check the condition of the surface of the pad slide pathways, surface run in (steel whitened) without traces of corrosion.
- If necessary lubricate the pad slide pathways (\leq LUBRICANTS AND FUEL).
- Telescope the boom several times in order to spread the lubricant evenly.
- Remove the surplus lubricant.

⚠ IMPORTANT ⚠

If the lift truck is used in an abrasive environment (dust, sand, coal.) use lubricating varnish (MANITOU reference: 483536). Please consult your dealer.



CHECK

Hydraulic oil level

Place the lift truck on level ground with the engine stopped, and the boom retracted and lowered as far as possible.

⚠ IMPORTANT ⚠

Use a clean funnel and clean the underside of the oil drum before filling.

- Check dipstick 1, the correct level must be at the level of the red dot.
- If necessary, add oil (☞ LUBRICANTS AND FUEL).
- Remove cap 2.
- Add oil through filler port 3.
- Refit the cap.
- Visually check that there is no leakage in the tank and pipes.



CHECK

Windscreen washer liquid level

- Open the protective casing 1 with the ignition key.
- Visually check the level in tank 2.
- If necessary add windscreen washer fluid (☞ LUBRICANTS AND FUEL).
- Remove cap 3.
- Add windscreen washer liquid through filler port.
- Refit the cap.



CLEAN

Fuel pre-filter

⚠ IMPORTANT ⚠

Carefully clean the outside of the pre-filter and its holder, to prevent dust from getting into the system.

- Open the engine cover.
- Disconnect electrical wiring harness 1 from the fuel pre-filter.
- Place a receptacle under the drain plug 2 and unscrew it by two thread turns.
- Allow the diesel fuel to flow out until it is free from impurities and water.
- Re-tighten drain plug 2 and reconnect the wiring harness 1.



CLEAN

Radiator cores

⚠ IMPORTANT ⚠

In a polluting atmosphere, clean the radiator cores every day. Do not use a water jet or high-pressure steam as this could damage the radiator fins.

- Open the engine cover.
- If necessary, clean the intake grille on the engine bonnet.
- Using a soft cloth, clean the radiator cores in order to remove as much dirt as possible.
- Clean the radiator using a compressed air jet aimed from the engine towards the radiator, in the opposite direction to the cooling air flow.



CLEAN

Dry air filter cartridge

When used in very dusty atmospheres there are pre-filtration elements (◀ FILTER ELEMENTS AND BELTS). The cartridge checking and cleaning interval must also be reduced.

⚠ IMPORTANT ⚠


If the clogging indicator lamp comes on, this operation must be carried out as soon as possible (within a maximum of 1 hour). Never use the lift truck without an air filter or with an air filter that is damaged.

Respect the safety distance of 30 mm between the air jet and the cartridge to avoid tearing or piercing the cartridge. The cartridge must not be blown near the air filter box. Never clean the cartridge by tapping it against a hard surface.

Your eyes must be protected during this intervention.

Never clean the dry air filter cartridge by washing it in liquid. Do not clean by any means the safety cartridge located inside the filter cartridge, change it for a new one if it is clogged or damaged.

- For the dismantling and refitting of the cartridge (◀ 1000H: REPLACE Air filter cartridge).
- Clean the filter cartridge using a compressed air jet (max. pressure 3 bars) directed from the top to the bottom and from the inside towards the outside at a minimum distance of 30 mm from the cartridge wall.
- Cleaning is completed when there is no more dust on the cartridge.
- Clean the cartridge seal surface with a damp, clean lint-free cloth and grease with a silicone lubricant (MANITOU part No.: 479292).
- Check visually the outer condition of the air filter and its mounts. Verify the condition of the hoses and their mounts also.



CLEAN

Condenser wiring harness (Air conditioning OPTION)

⚠ IMPORTANT ⚠

In a polluting atmosphere, clean the radiator core every day. Do not use a water jet or high-pressure steam as this could damage the condenser fins.

- Remove the protective grid 1 and clean it if necessary.
- Visually check whether the condenser is clean and clean it if necessary.
- Clean the condenser using a compressed air jet aimed in the same direction as the air flow.
- Clean with the fans running for best results.



To be carried out weekly, if the lift truck has been operated for less than 50 hours during the week.

⚠ IMPORTANT ⚠

In the event of prolonged use in an extremely dusty or oxidising atmosphere, reduce this interval to 10 hours of service or every day.

Clean, then lubricate the following points with grease (← LUBRICANTS AND FUEL) and remove the surplus.

BOOM

- 1 - Lubricators of the boom pin (2 lubricators).
- 2 - Lubricator of the carriage pin (1 lubricator).
- 3 - Lubricator of the tilting cylinder foot pin (1 lubricator).
- 4 - Lubricator of the tilting cylinder head pin (1 lubricator).
- 5 - Lubricator of the lifting cylinder foot pin (1 lubricator).
- 6 - Lubricator of the lifting cylinder head pin (1 lubricator).
- 7 - Lubricator of the compensating cylinder foot pin (1 lubricator).
- 8 - Lubricator of the compensating cylinder head pin (1 lubricator).

FRONT AND REAR WHEEL REDUCTION GEAR PIVOTS

- 9 - Lubricators of the wheel reduction gear pivot pins (8 lubricators).

REAR AXLE OSCILLATION

- 10 - Rear axle oscillation lubricators (2 lubricators).



REPLACE

Engine oil *

REPLACE

Engine oil filter *

Place the lift truck on level ground, let the engine run at idling speed for a few minutes, then stop the engine.

⚠ IMPORTANT ⚠

Dispose of the drain oil in an ecological manner.

Tighten the oil filter by hand pressure only and lock the filter in place by a quarter turn.

DRAINING THE OIL

- Open the engine cover.
- Remove access panel 1.

NOTE: When removing cover plates and hatches, clean the surrounding area and remove any accumulations of flammable materials.

- Place a container under the drain hole and unscrew the drain plug 2.
- Remove the filler plug 3 to ensure correct drainage.

REPLACEMENT OF THE FILTER

- Unscrew and discard the engine oil filter 4, together with its seal.
- Clean the filter bracket with a clean, lint-free cloth.
- Lightly oil the seal before refitting the new oil filter (⚡ FILTER ELEMENTS AND BELTS) on its bracket (tightening torque 11 - 12,5 ft-lbs 15 - 17 N.m).

FILLING WITH OIL

- Refit and tighten the drain plug 1.
- Fill up with oil (⚡ LUBRICANTS AND FUEL) through filler hole 5.
- Wait a few minutes to allow the oil to flow into the sump.
- Start the engine and let it run for a few minutes.
- Check for possible leaks from the drain plug and the oil filter.
- Stop the engine, wait a few minutes and check the correct level between the two marks on the dipstick 6.
- Top up the level if necessary.
- Refit the access cover 1.

** Only for the first 50 hours of service and then every 500 hours of service or 1 year.*



CHECK

Hydraulic oil

MANITOU offers a hydraulic oil analysis kit which might make it possible to delay the recommended deadline in the periodic maintenance schedule (2000 hours). In this case we recommend an analysis of the hydraulic oil every 500 hours or 1 year of service.

The oil analysis kit also makes it possible to confirm the oil quality so as to obtain a deadline of 2000 hours for specific uses causing constraints on the hydraulic circuit: extreme environmental conditions, use of the attachments with a very high hydraulic flow rate (such as a sweeper, or a concrete mixer).

- Order an oil analysis kit from your dealer.
- Upon receiving the kit, take a sample of oil and follow the instructions shown on the kit.
- According to the results, keep the analysis report or replace the hydraulic oil.

MANITOU oil analysis kit Part No. 958162.



REPLACE

Engine oil

REPLACE

Engine oil filter

Place the lift truck on level ground, let the engine run at idling speed for a few minutes, then stop the engine.

⚠ IMPORTANT ⚠

Dispose of the drain oil in an ecological manner.

Tighten the oil filter by hand pressure only and lock the filter in place by a quarter turn.

DRAINING THE OIL

- Open the engine cover.
- Remove access panel 1.

NOTE: When removing cover plates and hatches, clean the surrounding area and remove any accumulations of flammable materials.


- Place a container under the drain hole and unscrew the drain plug 2.
- Remove the filler plug 3 to ensure correct drainage.

REPLACEMENT OF THE FILTER

- Unscrew and discard the engine oil filter 4, together with its seal.
- Clean the filter bracket with a clean, lint-free cloth.
- Lightly oil the seal before refitting the new oil filter (⚡ FILTER ELEMENTS AND BELTS) on its bracket (tightening torque 11 - 12,5 ft-lbs 15 - 17 N.m).

FILLING WITH OIL

- Refit and tighten the drain plug 2.
- Fill up with oil (⚡ LUBRICANTS AND FUEL) through filler hole 5.
- Wait a few minutes to allow the oil to flow into the sump.
- Start the engine and let it run for a few minutes.
- Check for possible leaks from the drain plug and the oil filter.
- Stop the engine, wait a few minutes and check the correct level between the two marks on the dipstick 6.
- Top up the level if necessary.
- Refit the access cover 1.



REPLACE

Fuel filter

⚠ IMPORTANT ⚠

*Carefully clean the outside of the filter and around it, to prevent dust from getting into the system.
Tighten the filter by hand only and lock it by a quarter turn.*

- Switch off the lift truck's ignition with the ignition key.
- Unscrew the filter 1.
- Clean the inside of the filter head using a brush immersed in clean diesel oil.
- Refit a new filter lubricated with clean diesel beforehand (◀ FILTER ELEMENTS AND BELTS).




REPLACE

Fuel pre-filter

⚠ IMPORTANT ⚠

*Carefully clean the outside of the filter and around it, to prevent dust from getting into the system.
Tighten the filter by hand only and lock it by a quarter turn.*

- Disconnect the wiring harness 1.
- Place a receptacle under the filter 2.
- Unscrew the filter 2.
- Clean the inside of the filter head using a brush immersed in clean diesel oil.
- Refit a new filter lubricated with clean diesel beforehand (◀ FILTER ELEMENTS AND BELTS).
- Reconnect the wiring harness 1.
- Open bleed screws 3 and 4.
- Turn on the lift truck's ignition with the ignition key.
- Close the bleed screws 3 and 4 as soon as the diesel flows free of air.



REPLACE

Transfer box oil

Place the lift truck on level ground with the engine stopped and the transfer box oil still warm.

⚠ IMPORTANT ⚠

Dispose of the drain oil in an ecological manner.

- Remove access panel 1.
- Place a container under drain plug 2 and unscrew the plug.
- Remove level and filling plug 3 to ensure correct drainage.
- Refit and tighten the drain plug 2 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).
- Fill up with oil (◀ LUBRICANTS AND FUEL) through filler hole 3.
- The level is correct when the oil level is flush with the edge of the hole.
- Check for any possible leaks at the drain plug.
- Refit and tighten the level and filling plug 3 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).
- Refit the access cover 1.



REPLACE


Front axle differential oil

Place the lift truck on level ground with the engine stopped and the still warm differential oil.

⚠ IMPORTANT ⚠

Dispose of the drain oil in an ecological manner.

- Place a container under drain plug 1 and unscrew the plug.
- Remove level and filling plug 2 to ensure correct drainage.
- Refit and tighten the drain plug 1 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).
- Fill up with oil (↩ LUBRICANTS AND FUEL) through filler hole 2.
- The level is correct when the oil level is flush with the edge of the hole.
- Check for any possible leaks at the drain plug.
- Refit and tighten the level and filling plug 2 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).



REPLACE

Hydraulic return oil filter cartridge


Stop the engine and release the pressure from the systems by operating the hydraulic controls.

⚠ IMPORTANT ⚠

Raise the boom and place the boom safety wedge on the rod of the lifting cylinder (↩ 1 - INSTRUCTIONS AND SAFETY RECOMMENDATIONS: LIFT TRUCK MAINTENANCE INSTRUCTIONS).

Thoroughly clean the outside of the filter and its surroundings before any operation to prevent any risk of polluting the hydraulic system.

- Remove cap 1.
- Place a container under hydraulic return oil filter.
- Unscrew the cover 2.
- Wait a few seconds for the oil to flow into the container.
- Slowly take out filter cartridge assembly 3 and 4.
- Separate the head 3 from the filter cartridge 4 with a twisting motion.
- Refit the head onto a new cartridge (↩ FILTER ELEMENTS AND BELTS).
- Fit the assembly in place and re-tighten cover 2.
- Put the cap 1 back.



REPLACE

Hydraulic fluid tank filter cap

Place the lift truck on level ground with the engine stopped.

- Unscrew plug 1, remove and replace the filter 2 with a new one (⇐ FILTER ELEMENTS AND BELTS).
- Refit and tighten the filter 2 (tightening torque 2,21 ±0,37 ft-lbs 3 ±0,5 N.m).
- Refit the filler plug 1.



REPLACE

Cab fan filter

INTERNAL CAB VENTILATION FILTER

- Remove the protective grid 1.
- Remove the cab ventilation filter and replace it with a new one (⇐ FILTER ELEMENTS AND BELTS).
- Refit the protective grid.



CHARGE

12 V battery

⚠ IMPORTANT ⚠

Operate the battery cut-off no less than 30 seconds after having switched off the ignition with the ignition key.

Handling a 12V battery can be dangerous. Take the following precautions:

- *Wear protective goggles.*
- *Keep the 12V battery horizontal.*
- *Never smoke or direct a naked flame toward the batteries.*
- *The batteries are not charged in an explosive environment.*
- *Do not leave the battery charger connected during an electrical storm.*

In the event of electrolyte being spilled onto the skin or splashed in the eyes, rinse thoroughly with cold water for 15 minutes and call a doctor.

To prolong battery life, MANITOU recommends fully recharging the 12 V battery a few months before the start of the winter season.

- Open the engine hood.
- Disconnect the 12 V battery in the following order: negative (-) terminal first, then positive (+) terminal.
- Fully charge the battery.
- Reconnect the 12 V battery in the following order: positive (+) terminal first, then negative (-) terminal.
- Close the engine hood.

CHECK

Hoses and differential pressure hoses for the exhaust particle filter "DPF" **

CHECK

Exhaust gas recirculation piping "EGR" **

CHECK

Intake hose **

CHECK

****Exhaust manifold**

CHECK

Fork wear *

**** Engine service, consult your dealer.**

*** Consult your dealer.**

🔧 1000H - PERIODIC SERVICE - EVERY 1000 HOURS OF SERVICE OR 2 YEARS

ALSO PERFORM THE 500 HOUR PERIODIC MAINTENANCE OPERATIONS.

CHECK

Safety belt

⚠️ IMPORTANT ⚠️

*Under no circumstances must the lift truck be used if the seat belt is defective (fixing, locking, cuts, tears, etc.).
Immediately repair or replace the safety belt.*

SEAT BELT WITH TWO ANCHORING POINTS

- Check the following points:
 - Fixing of the anchoring points on the seat.
 - Cleanness of the strap and the locking mechanism.
 - Triggering of the locking mechanism.
 - Condition of the strap (cuts, curled edges).

REELED SEAT BELT WITH TWO ANCHORING POINTS

- Check the points listed above together with the following points:
 - The correct winding of the belt.
 - Condition of the reel guards.
 - Roller locking mechanism when the strap is given a sharp tug.

NOTE: After an accident, replace the seat belt.

CLEAN

Fuel tank

Place the lift truck on level ground with the engine stopped.

⚠️ IMPORTANT ⚠️

While carrying out these operations, do not smoke or work near a flame.

Never try to carry out a weld or any other operation by yourself, this could provoke an explosion or a fire.

- Inspect the parts of the fuel circuit and the tank liable to leak, both visually and by touch.
- In the event of a leak, contact your dealer.
- Place a container under drain plug 1 and unscrew the plug.
- Open the fuel filler access panel 2 with the ignition key.
- Remove the filler plug 3 to ensure correct drainage.
- Rinse with ten litres of clean diesel through filler hole 4.
- Refit and tighten the drain plug 1 (tightening torque 21 - 29 ft-lbs 29 - 39 N.m).
- Fill the fuel tank with clean diesel filtered through the filler port.
- Refit the filler plug.
- Close access panel 2.



REPLACE

Alternator belt


⚠ IMPORTANT ⚠

Check the belt tension again after the first 20 hours of service.

REMOVING THE BELT

- Undo screws 1 and remove radiator protection grill 2.
- Loosen screws 3 by two to three thread turns.
- Swivel the alternator assembly so as to free belt 4.
- Pass belt 4 behind radiator propeller 5 to remove it and replace with a new one (⇐ FILTER ELEMENTS AND BELTS).

NOTE: Take advantage of belt removal to check the correct operation of the pulleys and bearings (noise, rubbing, play, etc.).



REFITTING THE BELT

- Refit a new alternator belt (⇐ FILTER ELEMENTS AND BELTS). Ensure that it is properly seated in the grooves of each pulley.
- Adjust the belt tension between the crankshaft pulley and the alternator pulley (22,03 lbs / 98 N). The clearance should be about 0,3 to 0,4 in (7 to 9 mm).
- Swivel the alternator assembly so as to obtain the required belt tension.
- Retighten screws 1 (tightening torque 16 ft-lbs ±1,6 ft-lbs 22 N.m ±2,2 N.m).
- Refit the radiator protection grill 2.

REPLACE

Engine crankcase ventilation filter

- Open the engine cover.
- Carefully clean the outside of the filter and its holder, to prevent dust from getting into the system.
- Disconnect the hose 1 at the filter.
- Unscrew the cover 2.
- Take out the filter 3 and discard it together with the seal of the cover 2.
- Refit a new seal on the cover and insert a new filter (⇐ FILTER ELEMENTS AND BELTS).
- Put back the cover 2 and tighten by hand only and lock by a quarter turn.
- Reconnect hose 1.



REPLACE


Dry air filter cartridge

In case of use in a heavily dust laden atmosphere, there are pre-filtration cartridges, (⇐ FILTER ELEMENTS AND BELTS). Also, the checking and cleaning periodicity of the cartridge must be reduced (up to 250 hours in a very dusty atmosphere and with pre-filtration).

⚠ IMPORTANT ⚠

Change the cartridge in a clean location, with the engine stopped. Never operate the lift truck with the air filter removed or damaged.

- Open the engine cover.
- Loosen the locks and remove cover 1.
- Gently remove the cartridge 2 to reduce dust falling as far as possible.
- Leave the safety cartridge in place.
- Carefully clean the following parts with a damp, clean lint-free cloth.
 - The inside of the filter and cover.
 - The inside of the filter inlet hose.
 - The gasket surfaces in the filter and in the cover.
- Check pipes and connections between the air filter and the engine and the connection and state of the clogging indicator on the filter.
- Before fitting check the condition of the new cartridge (⇐ FILTER ELEMENTS AND BELTS).
- Insert the cartridge in the filter axis and push the cartridge pressing against the outer edge and not the centre.
- Reassemble the cover, guiding the valve downwards.



REPLACE

Coolant

These operations are to be carried out as necessary or every 2 years at the beginning of winter. Place the lift truck on level ground with the engine stopped and cold.

⚠ IMPORTANT ⚠

The engine does not contain any anti-corrosion elements and must be filled throughout the year with a mixture containing 25% ethylene glycol-based antifreeze.

DRAINING THE LIQUID

- Open the engine cover.
- Remove access panel 5.
- Place a container under the radiator drain plug 1 and unscrew the plug.
- Remove filler plug 2 from the expansion tank and fully open the heating control to ensure correct drainage.
- Let the cooling circuit drain entirely while ensuring that the ports do not get clogged.
- Check the condition of the hoses as well as the fastening devices and change the hoses if necessary.
- Rinse the circuit with clean water and use a cleaning agent if necessary.

FILLING WITH COOLANT

- Refit and tighten the radiator drain plug 1 (tightening torque 15 ft-lbs ±1.5 ft-lbs 20 N.m ±2 N.m).
- Slowly fill the circuit with coolant (⇐ LUBRICANTS AND FUEL) up to the middle of the expansion tank 3 by the filler hole 4.
- Refit the filler plug 2.
- Run the engine at idle for a few minutes.
- Check for any possible leaks.
- Check the level and refill if necessary.



REPLACE


Rear axle differential oil

Place the lift truck on level ground with the engine stopped and the still warm differential oil.

⚠ IMPORTANT ⚠

Dispose of the drain oil in an ecological manner.

- Place a container under drain plug 1 and unscrew the plug.
- Remove level and filling plug 2 to ensure correct drainage.
- Refit and tighten the drain plug 1 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).
- Fill up with oil (☞ LUBRICANTS AND FUEL) through filler hole 2.
- The level is correct when the oil level is flush with the edge of the hole.
- Check for any possible leaks at the drain plug.
- Refit and tighten the level and filling plug 2 (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).



REPLACE

Front wheel reducer oil

REPLACE

Rear wheel reducer oil

Place the lift truck on level ground with the engine stopped and the reducers' oil still warm.

⚠ IMPORTANT ⚠

Dispose of the drain oil in an ecological manner.

- Drain and change the oil of each wheel reduction gear.
- Place drain plug 1 in position A.
- Place a container under the drain plug and unscrew the plug.
- Let the oil drain fully.
- Place the drain port in position B, i.e. in a level port.
- Fill up with oil (☞ LUBRICANTS AND FUEL) through level hole 1.
- The level is correct when the oil level is flush with the edge of the hole.
- Refit and tighten the drain plug (tightening torque 25 - 36 ft-lbs 34 - 49 N.m).



CHECK	Silentblocks **
CHECK	Valve lash **
CHECK	Injectors **
CHECK	Exhaust gas recirculation cooler "EGR" **
CHECK	Casing gas recycling valve **
CHECK	Brake system pressure *
CHECK	Boom pad wear *
CHECK	Condition of wiring harnesses and cables *
CHECK	Lights and signals *
CHECK	Warning indicators *
CHECK	Condition of the rear-view mirrors *
CHECK	Cabin structure *
CHECK	Frame structure *
CHECK	Attachment carriage *
CHECK	Condition of attachments *
EPLACE	Brake fluid *
BLEED	Brake circuit *
ADJUST	Brake *

**** Engine service, consult your dealer.**

*** Consult your dealer.**

🔄 2000H - PERIODIC SERVICE - EVERY 2000 HOURS OF SERVICE OR 4 YEARS

ALSO PERFORM THE 500 HOUR AND 1000 HOUR PERIODIC MAINTENANCE OPERATIONS.

CHECK

Wheel nut tightening torques

- Check the condition of the tyres, to detect cuts, blisters, wear, etc.
- Check the tightening torque of the wheel nuts with a torque wrench.
 - Front wheels: 465 ± 70 ft-lbs (630 ± 94 N.m)
 - Rear wheels: 465 ± 70 ft-lbs (630 ± 94 N.m)


REPLACE

Dry air filter safety cartridge

⚠ IMPORTANT ⚠

The safety cartridge replacement frequency is given for information only. It must be changed every second time the dry air filter cartridge is changed.

- For the dismantling and refitting of the cartridge (< 1000 HOURS: REPLACE Air filter cartridge).
- Remove the dry air filter safety cartridge 1 carefully, to minimise dust fall.
- Clean the gasket surface on the filter with a damp, clean lint-free cloth.
- Check the condition of the new safety cartridge before fitting (< FILTER ELEMENTS AND BELTS).
- Insert the cartridge in the filter axis and push the cartridge pressing against the outer edge and not the centre.



REPLACE

Hydraulic oil

REPLACE

Brake accumulator unit filter

Place the lift truck on level ground with the engine stopped.

⚠ IMPORTANT ⚠

Raise the boom and place the boom safety wedge on the rod of the lifting cylinder (↖ 1 - OPERATING AND SAFETY INSTRUCTIONS: LIFT TRUCK MAINTENANCE INSTRUCTIONS).

Before any intervention, thoroughly clean the area surrounding the drain and filler plugs.

Dispose of the drain oil in an ecological manner.

Use a very clean container and funnel and clean the underside of the oil drum before filling.

DRAINING THE OIL

- Place a container under drain plugs 1 and unscrew them.
- Remove the filler plug 2 to ensure correct drainage.

REPLACING THE BRAKE ACCUMULATOR UNIT FILTER



- Remove the cover plate 3.
- Unscrew plug 4, remove and replace the filter with a new one (↖ FILTER ELEMENTS AND BELTS).
- Refit and tighten the plug 4 (tightening torque 51 - 59 ft-lbs 70 - 80 N.m).
- Refit cover plate 3.

FILLING WITH OIL

- Clean and refit the drain plugs 1 (tightening torque 21 - 29 ft-lbs 29 - 39 N.m).

NB: For machines that have one, check that the grounding lug 7 on the drain plug 1 is firmly in place.

- Fill up with oil (↖ LUBRICANTS AND FUEL) through filler hole 5.
- Observe the oil level on dipstick 6, the oil level should be at the level of the red dot.
- Check for any possible leaks at the drain plugs.
- Refit the filler plug 2.



CHECK	Radiator *
CHECK	Transmission pressures *
CHECK	Steering *
CHECK	Steering swivel joints *
CHECK	Brake pad and brake disk wear *
CHECK	Condition of boom assembly *
CHECK	Bearings and bushings *
CHECK	Condition of hoses and flexible pipes *
CHECK	Condition of cylinders (leakage, rods) *
CHECK	Hydraulic circuit pressures *
CLEAN	Air conditioning (OPTION) *
REPLACE	Compressor belt (Air Conditioning OPTION) *

*** Consult your dealer.**

➔ ④ 3000H - PERIODIC SERVICE - EVERY 3000 HOURS OF SERVICE OR 6 YEARS

ALSO PERFORM THE 500 HOUR AND 1000 HOUR PERIODIC MAINTENANCE OPERATIONS.

CHECK **Turbocharger** **

CHECK **Exhaust gas recirculation system "EGR"** **

CLEAN **Exhaust particle filter "DPF"** **

**** Engine service, consult your dealer.**

CLEAN

"Stationary lift truck" exhaust purification

⚠ IMPORTANT ⚠

Exhaust purification is an automated procedure activated by the operator when the following indicator lamps are displayed:



- Park the lift truck in a safe and adequately ventilated place.
- Check the following points:
 - forward/reverse selector in neutral,
 - parking brake applied,
 - boom angle less than 5°,
 - accelerator pedal released,
 - hand throttle not used (option),
- Check that the fuel level is sufficient.
- Start the lift truck and run the engine for a few minutes to bring it up to its operating temperature.
- Press the top of switch 1 for more than two seconds to begin the regeneration procedure.
- Lighting of the indicator lamp plus a beep confirms the start of the "stationary lift truck" exhaust purification procedure.
- The "wait" display will flash throughout the 'stationary lift truck' exhaust purification.
- Otherwise, "notice" will be displayed for 3 seconds indicating a fault in the procedure. In this event check the positioning of the lift truck and contact your dealer if necessary.
- At the end of the procedure, indicator lamps + go out.
- During the procedure the engine speed increases to approx. 1800 rpm, and the indicator lamp comes on when the exhaust particle filter gases reach a high temperature.



⚠ IMPORTANT ⚠

The exhaust sublimation procedure must only be stopped if absolutely necessary.

The procedure stops automatically if the operator:

- activates the hydraulic control joystick,
- engages forward or reverse gear,
- switches off the engine,
- or pressing on the top of the switch 1.

- The time taken for exhaust purification varies (between 15 and 30 minutes) according to several criteria, such as:
 - the level of clogging of the filter,
 - the ambient temperature,
 - the fuel quality and type of engine oil,
 - the number of exhaust particle filter automatic regeneration requests previously cancelled.
- The engine will return to its initial idling speed to indicate that the procedure has finished.

⚠ IMPORTANT ⚠

Once the exhaust sublimation procedure is completed, leave the engine idling for a few minutes to lower the temperature before switching off the ignition.

REPLACE

Wheels

For this operation, we advise you to use the MANITOU hydraulic jack Part No. 505507 and the MANITOU safety support prop Part No. 554772.

⚠ IMPORTANT ⚠

In the event of a wheel being changed on the public highway, secure the lift truck vicinity:

- Stop the lift truck, if possible on firm, level ground.
- Stop the lift truck (☞ 1 - OPERATING AND SAFETY INSTRUCTIONS: DRIVING INSTRUCTIONS UNLADEN AND LADEN).
- Switch on the hazard warning lights.
- Immobilise the lift truck in both directions on the axle opposite to the wheel to be changed.
- Unlock the nuts of the wheel to be changed.
- Place the jack under the flared axle tube, as near as possible to the wheel and adjust the jack.
- Raise the wheel until it is clear of the ground and place the safety support under the axle.
- Completely unscrew the wheel nuts and remove them.
- Free the wheel by reciprocating movements and roll it to the side.
- Slip the new wheel on the wheel hub.
- Hand-tighten the nuts, grease them if necessary.
- Remove the safety support and lower the lift truck with the jack.
- Tighten the wheel nuts with a torque wrench (☞ 2000H - PERIODIC SERVICE - EVERY 2000 HOURS OF SERVICE OR EVERY 4 YEARS) for the tightening torque.



REPLACE

Battery failure

⚠ IMPORTANT ⚠

Operate the battery cut-off for a minimum of 30 seconds after having switched off the ignition with the ignition key.
Handling and servicing a battery can be dangerous, take the following precautions:

- Wear protective goggles.
- Keep the battery horizontal.
- Never smoke or work near a naked flame.
- Work in a well-ventilated area.

- In the event of electrolyte being spilled onto the skin or splashed in the eyes, rinse thoroughly with cold water for 15 minutes and call a doctor.

- Open the engine cover.
- Bring a backup battery of the same type as that of the lift truck, together with battery cables.
- Connect the backup battery according to the correct polarity with the (-) on the engine earth 1 and the (+) on the (+) of starter 2.
- Start the lift truck and remove the cables as soon as the engine is running.

⚠ IMPORTANT ⚠

Raise the boom and place the boom safety wedge on the rod of the lifting cylinder (⚠ 1 - OPERATING AND SAFETY INSTRUCTIONS: LIFT TRUCK MAINTENANCE INSTRUCTIONS).

- Remove the protective casing 3.
- Change the battery 4.



ADJUST

Front headlights

RECOMMENDED SETTING

(as per standard ECE-76/756 76/761 ECE20)


Adjustment of -2 % of the dipped beam harness relative to the horizontal axis of the headlight.

ADJUSTMENT PROCEDURE

- Place the unladen lift truck in the transport position and perpendicular to a white wall on flat, level ground.
- Check the tyre pressures (⚠ 2 - DESCRIPTION: TYRES).
- Place the forward/reverse selector in neutral.

CALCULATING THE HEIGHT OF THE DIPPED BEAM (H2)

- h1 = Height of the dipped beam in relation to the ground.
- h2 = Height of the adjusted beam.
- l = Distance between the dipped beam and the white wall.



(For machine with "LONGITUDINAL STABILITY LIMITER AND WARNING DEVICE")

According to the use of the lift truck, the device may require to be periodically reset.











This operation can be easily performed by means of the following procedure.

- Provide a fork carrier or a bucket and a load corresponding to at least half the lift truck's rated capacity.
- Preferably perform the reset when the lift truck is still cold (before it is used) or ensure that the temperature of the rear axle is not more than 50°C.
- Place the lift truck on flat, level ground with the wheels straight.

⚠ IMPORTANT ⚠

Strictly adhere to the boom positioning instructions. Two beeps and lighting of the fault indicator lamp  informs you these instructions have not been following. If in doubt consult your dealer.

When the reset is completed, check the operation of the longitudinal stability limiter and warning device (⏱ 10H - DAILY SERVICE OR EVERY 10 HOURS OF SERVICE).

<p>STEP 1 ENTRY</p> <p>↓</p>	 <p>→</p> <p>Simultaneously press and hold down the "BUCKET" MODE  and TEST  buttons.</p> <ul style="list-style-type: none"> - Without attachments. - Boom fully retracted and raised. - Two beeps will sound and all the LEDs will flash twice to confirm the start of the procedure.
<p>STEP 2</p> <p>↓</p>	 <p>→</p> <ul style="list-style-type: none"> - Without attachments. - Carriage tilted fully backwards. - Boom fully retracted and in the down position a few centimetres off the ground. <p>→ Short press the test button. </p>
<p>STEP 3</p> <p>↓</p>	 <p>→</p> <ul style="list-style-type: none"> - With the fork carrier or the bucket and a load (keep boom retracted to allow all other hydraulic movements). - Boom fully retracted and in the down position a few centimetres off the ground. <p>⚠ IMPORTANT ⚠</p> <p>Always keep the load as close to the ground as possible during this operation.</p> <ul style="list-style-type: none"> - Hold down the disable the "aggravating" hydraulic movement cut-off button  (indicator lamp lit), and telescope the boom until the rear wheels leave the ground. <p>NOTE: This stage consists in unloading the rear axle. It can be done using a jack but without bearing on the rear axle.</p> <p>→ Short press the test button. </p> <p>→ Two beeps will sound and all the LEDs will flash twice to confirm the end of the procedure.</p>
<p>STEP 4 EXIT</p>	 <p>→</p> <ul style="list-style-type: none"> - After completing the resetting procedure, the lift truck is in an overloaded condition. Retract the telescope to restore the situation. - All LEDs lit. - A continuous audible beep. 

↻ OCCASIONAL OPERATION

TOW OR WINCH

Lift truck

⚠ IMPORTANT ⚠

If the lift truck is not on level ground, chock it so that it does not descend the slope.

The lift truck must be towed very slowly (less than 5 km/h) and for as short a distance as possible (less than 100 m).

For towing a lift truck, the high pressure limiters must be unlocked to avoid damaging the hydrostatic transmission, and the parking brake on the front axle must be released.

- Switch on lift truck ignition.
- Set the forward/reverse selector to neutral.
- Release the hand brake.

UNLOCKING THE HIGH PRESSURE LIMITERS

- Open the engine cover.
- Loosen nuts 1 on the hydrostatic pump by no more than three turns.

RELEASING THE PARKING BRAKE ON THE FRONT AXLE

- Unscrew the screws 2 on the front axle, remove the shims 3 and fully re-tighten the screws 2.

TOWING


- Switch on the hazard warning lights.
- Since there will be no steering or braking hydraulic assistance, operate the steering and pedal slowly, avoiding sudden or jerky movements.
- After towing, re-tighten nuts 1 (tightening torque 51 ft-lbs 70 N.m).
- Unscrew the screws 2, refit the shims 3 and re-tighten the screws 2 (tightening torque 70 - 85 ft-lbs 95 - 115 N.m).



SLING

Lift truck

- Take into account the position of the lift truck centre of gravity for lifting.
- A = 3-11 ft-in (1200 mm) B = 3-7 ft-in (1100 mm)
- Place the hooks in the fastening points 1 provided.



⚠ IMPORTANT ⚠

Ensure that the safety instructions associated with the flatbed are complied with before loading the lift truck and that the driver of the carrier vehicle is informed of the dimensions and the weight of the lift truck (≤ 2 - DESCRIPTION: CHARACTERISTICS).

Ensure that the platform is of sufficient size and load capacity for transporting the lift truck. Check also the allowable ground contact pressure of the platform relative to the lift truck.

⚠ IMPORTANT ⚠




For lift trucks equipped with a turbo-charged engine, block off the exhaust outlet to avoid rotation of the turbo shaft without lubrication when transporting the vehicle.

LOADING THE LIFT TRUCK

- Block the wheels of the platform.
- Attach the loading ramps to the platform in such a way as to give the shallowest possible ramp angle for the lift truck.
- Load the lift truck parallel to the platform.
- Stop the lift truck (≤ 1 - OPERATING AND SAFETY INSTRUCTIONS: DRIVING INSTRUCTIONS UNLADEN AND LADEN).

STOWING THE LIFT TRUCK

- Fix the chocks to the platform at the front and at the back of each tyre.
- Also fix the chocks to the platform on the inside of each tyre.
- Secure the lift truck to the platform with sufficiently strong ropes to the anchoring points 1 provided.
- Tighten the ropes.



4 - OPTIONAL ADAPTABLE ATTACHMENTS FOR THE RANGE

4 - OPTIONAL ADAPTABLE ATTACHMENTS FOR THE RANGE

<u>INTRODUCTION</u>	4-3
<u>PICKING UP THE ATTACHMENTS</u>	4-4
<u>TECHNICAL SPECIFICATIONS OF ATTACHMENTS</u>	4-6
<u>ATTACHMENT GUARDS</u>	4-10

INTRODUCTION

- Your lift truck must be used with interchangeable equipment. These items are called: ATTACHMENTS.
- A wide range of attachments is available, guaranteed by MANITOU and designed to fit your lift truck perfectly.

⚠ IMPORTANT ⚠

*Only attachments approved by MANITOU can be used with their lift trucks (↪ TECHNICAL SPECIFICATIONS OF ATTACHMENTS).
The manufacturer cannot be held responsible for any modifications or adaptations to attachments without its knowledge.*

- The attachments are delivered with a load chart concerning your lift truck. The operator's manual and the load chart should be kept in the places provided in the lift truck. For standard attachments, their use is governed by the instructions contained on this notice.

⚠ IMPORTANT ⚠

*Maximum loads are defined by the capacity of a lift truck taking account of the attachment's mass and centre of gravity.
Should the attachment have a lower capacity than the lift truck, never exceed this limit.*

- Some particular uses require the adaptation of the attachment which is not provided in the price-listed options. Optional solutions exist, consult your dealer.

⚠ IMPORTANT ⚠

Depending on their size, certain attachments may, when the boom is lowered and retracted, come into contact with the front tyres and cause damage to them if excavation is activated in the direction of the discharge.

TO PREVENT THIS RISK, EXTEND THE TELESCOPE TO A SUFFICIENT EXTENT FOR THE PARTICULAR LIFT TRUCK AND ATTACHMENT SO THAT THIS CONTACT IS NOT POSSIBLE.

SUSPENDED LOAD

⚠ IMPORTANT ⚠

Suspended loads MUST be handled with a lift truck designed for that purpose (↪ 1 - OPERATING AND SAFETY INSTRUCTIONS: LOAD HANDLING INSTRUCTIONS: H - PICKING UP AND PUTTING DOWN A SUSPENDED LOAD).

PICKING UP THE ATTACHMENTS

1 - ATTACHMENT WITHOUT HYDRAULICS AND HAND LOCKING DEVICE

FITTING AN ATTACHMENT

- Ensure that the attachment is in a position facilitating the locking to the carriage. If it is not correctly oriented, take the necessary precautions in order to move it safely.
- Check that the locking pin is in position in the bracket (Fig. A).
- Place the lift truck with the boom lowered in front of and parallel to the attachment, and tilt the carriage forwards (Fig. B).
- Bring the carriage under the locking tube of the attachment, slightly raise the boom, tilt the carriage backwards in order to position the attachment (Fig. C).
- Lift the attachment off the ground to facilitate locking.

MANUAL LOCKING


- Take the locking pin on the bracket (Fig. A) and lock the attachment (Fig. D). Do not forget to fit the cotter pin.

MANUAL UNLOCKING

- Proceed in the reverse order to MANUAL LOCKING, taking care to refit the locking pin in the bracket (Fig. A).

REMOVING THE ATTACHMENT

- Proceed in the reverse order to FITTING AN ATTACHMENT, taking care to store the attachment flat on the ground and in the closed position.



2 - HYDRAULIC ATTACHMENT AND MANUAL LOCKING DEVICE

FITTING AN ATTACHMENT

- Ensure that the attachment is in a position facilitating the locking to the carriage. If it is not correctly oriented, take the necessary precautions in order to move it safely.
- Check that the locking pin is in position in the bracket (Fig. A).
- Place the lift truck with the boom lowered in front of and parallel to the attachment, and tilt the carriage forwards (Fig. B).
- Bring the carriage under the locking tube of the attachment, slightly raise the boom, tilt the carriage backwards in order to position the attachment (Fig. C).
- Lift the attachment off the ground to facilitate locking.

MANUAL LOCKING AND CONNECTION OF THE ATTACHMENT

⚠ IMPORTANT ⚠

Make sure that the rapid connectors are clean and protect the holes which are not used, with the caps provided.



- Take the locking pin on the bracket and lock the attachment (fig. D). Do not forget to fit the cotter pin.
- Stop the engine and keep the ignition on the lift truck.
- Release the pressure in the attachment hydraulic circuit by operating switch 1 on the distributor lever backwards and forwards 4 or 5 times.
- Connect the quick-release couplers according to the logic of the attachment's hydraulic movements.

MANUAL RELEASE AND DISCONNECTION OF THE ATTACHMENT

- Proceed in the reverse order of paragraph MANUAL LOCKING AND CONNECTION OF THE ATTACHMENT, taking care to refit the locking pin in the bracket.

REMOVING THE ATTACHMENT


- Proceed in the reverse order to FITTING AN ATTACHMENT, taking care to store the attachment flat on the ground and in the closed position.



TECHNICAL SPECIFICATIONS OF ATTACHMENTS


STANDARDISED TILTING FORK CARRIAGE

	PFB 25 N MT-1020 S2	PFB 25 N MT-1260 S2
PART NO.	571958	571959
Rated capacity	2300 kg	2300 kg
Width	1020 mm	1260 mm
Ground	71 kg	80 kg




STANDARDISED SIDE-SHIFT CARRIAGE

	TDL 2T5 L1020 FEM2	TDL 2T5 L1260 FEM2
PART NO.	751370	751371
Rated capacity	2300 kg	2300 kg
Side-shift	2x100 mm	2x100 mm
Width	1020 mm	1260 mm
Ground	54 kg	67 kg




STANDARDISED FORK

	PART NO.	415835
Section		125x40x1200 mm
Ground		76 kg




LOAD BACK REST

	PART NO.	555320	570518
Width		1020 mm	1260 mm
Ground		31 kg	35 kg




FLOATING FORK CARRIAGE

PART NO.	TFF 29 MT-1040
Rated capacity	2900 kg
Width	1040 mm
Ground	285 kg




FLOATING FORK

PART NO.	211919
Section	125x40x1200 mm
Ground	62 kg




BUILDING BUCKET

PART NO.	CBC 650 L1850
Rated capacity	676 l
Width	1850 mm
Ground	320 kg




LOADING BUCKET

PART NO.	CBR 730 L1850
Rated capacity	735 l
Width	1850 mm
Ground	330 kg




MULTIPURPOSE BUCKET DISPLAY

PART NO.	CB4X1-700 L1950
Rated capacity	700 l
Width	1950 mm
Ground	640 kg




CONCRETE BUCKET (ADAPTABLE ON FORKS)

PART NO.	BB 500 S4 654409
Rated capacity	500 l/1300 kg
Width	1100 mm
Ground	205 kg




CONCRETE BUCKET WITH SPOUT (ADAPTABLE ON FORKS)

PART NO.	BBHG 500 S4 751464
Rated capacity	500 l/1300 kg
Width	1100 mm
Ground	235 kg




SPOUT BUCKET (ADAPTABLE ON FORKS)

PART NO.	GL 600 S2 174373
Rated capacity	600 l/1440 kg
Ground	290 kg



JIB


PART NO.	PC 50 708544
Rated capacity	5000 kg
Ground	120 kg



ATTACHMENT GUARDS


FORK GUARD

PART NO. 227801



FORK BLOCK FOR FLOATING FORK CARRIAGE

PART NO. 261210



BUCKET PROTECTOR

Always ensure that the width of the protector you choose is less than or equal to the width of the bucket.

Width	PART NO. 206734	206732	206730
	1375 mm	1500 mm	1650 mm
Width	PART NO. 235854	206728	206726
	1850 mm	1950 mm	2000 mm
Width	PART NO. 223771	223773	206724
	2050 mm	2100 mm	2150 mm
Width	PART NO. 206099	206722	223775
	2250 mm	2450 mm	2500 mm

